Spirit Wireless Earbuds 73003

INSTRUCTIONS

- 1. Contents of package: Earphones, charging cable, instructions, earbuds.
- **2. Boot:** Hold the power button in until the lights on the earphones are flashing red and blue, then release power button.

3.Instructions for pairing the earphones with the mobile device.

- (1). Turn on earphone, when red and blue lights flash means paring. Search for the earphone in the list of available bluetooth units then connect. If you have previously paired your mobile device with the earphones, the devices will connect automatically.
- (2). How to connect two mobile devices to one set of earphones:(some devices don't support this function)

After Initiating paring mode, two mobile devices may be searched and connected to the earphones simultaneously. If one device have previously connected to the earphones, please disconnect it and then proceed to reconnect both d evices simultaneously.

4. Earphone key introduction

1)Answer Key

On/off button, hold in for an extended period to turn on or off the device By pressing the button once an incoming call may be received.

If In a phone conversation, pressed the button to decline an incoming call.

If listening to music it may pause and start the music.

Double click to redial the latest caller

(2).Plus key

Press once to return to the previous song.

Hold in to raise the volume

If the phone is In camera mode, press twice to take a picture. (Please note that some mobile devices do not support this function)

(3) Minus key

Click once to move to the next song

Hold in to lowervolume

5. Lamp indicators

- (1). Pairing mode; red and blue lights flash alternately,
- (2). Normal operation: blue light slow flash, once every 5 seconds
- (3). Low battery, red light slow flash, twice every 5 seconds
- (4). Battery is charging, red light is on continuously
- (5).Battery full, red light off.

6. Performance parameters

- (1). Bluetooth protocol version V4.2 (head set, hands-free, a2dp)
- (2). Communication range, 8-10 meters
- (3).Battery capacity 3.7V/55mAh lithium battery,
- (4). Playback battery time, up to 2.5 hours

- (5). Stand-by time, up to 12 hours
- (6). Charging time, less than 90 minutes.
- (7). Operating temperature, within-40 to degrees Celsius

7. FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.

△ Warning

- (1).DO NOT use the product while charging.
- (2).DO NOT continually charge this product for more than two hours
- (3).DO NOT disassemble or heat above 60"c(140F)or incinerate.