

24960-DI - MANUAL BLUETOOTH WIRELESS HEADPHONES - Black

FRONT

PACKAGE CONTENTS

• 1* Noise Isolation Headphone • 1* Micro USB Charging Cable • 1* Auxiliary Cable

PRODUCT SPECIFICATIONS

- Wireless Range: 10M
- Battery: 3.7V/ 400 mAh
- Music Play Time: Up to 4 hours
- Built-in Microphone
- Micro SD Card Input

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by CJ Global is under license. Other trademarks and trade names are those of their respective owners.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

GTECH is distributed by **CJ Global Inc.**
All rights reserved. 2010 Maple Ave Fair Lawn NJ 07410

GTECH

Noise Isolation Wireless Headphones



 **Bluetooth®**

User Manual

ITEM 24960-DI

Thank you for purchasing the CJ Tech Noise Isolation Wireless Headphones. Immerse yourself in a world of crystal-clear sound while disconnecting from the outside world with these stylish and oversized wireless headphones. These high-performance headphones have a foldable design making them easy to store and the perfect on-the-go accessory. Experience the ultimate comfort with the super soft headphone cushions. The built-in microphone allows you to take calls and speak hands-free while the controls on the headphone can adjust song selection and volume.

BACK

DEVICE LAYOUT



CHARGING & POWER UP YOUR SPEAKER

- 1) Using the included Micro USB charging cable, connect the end with Micro USB connection into the headphones and the other end to a USB Power Source 5V and up to 3.0 Amps (not included). A red LED light will turn ON when charging the headphones and when the battery is fully charged the light will turn OFF.
- 2) Charge the headphones for approximately 4 hours.
- 3) Turn ON the headphones with the POWER button on the Right Headphone.
- 4) Turn OFF the headphones by press the same POWER button.

BLUETOOTH® PAIRING / VOLUME CONTROL/ SONG SELECTION

Turn ON the headphones and you will hear a voice prompt that the Bluetooth® device is ready to pair. Make sure the Bluetooth® is turned ON in your smartphone settings and search for "CJT Headphones" and select it. You will then hear a prompt that the headphones are connect successfully and you can start to play music wirelessly from your smartphone!

- To increase the volume long press the "+" button.
- To decrease the volume long press the "-" button.
- To skip/forward to the next song short press the "+" button.
- To rewind to the previous song short press the "-" button.

Note: you can also control the music song volume and selection from your device.

PLAYING MUSIC FROM A MICRO SD CARD

Insert a Micro SD Card loaded with music and you can now play music through the speaker from the memory card.

- To increase the volume long press the "+" button.
- To decrease the volume long press the "-" button.
- To skip/forward to the next song short press the "+" button.
- To rewind to the previous song short press the "-" button.

AUDIO LINE IN MODE

The headphones also have an auxiliary input where you can connect the included 3.5 mm auxiliary cable to listen to music wired with these headphones. **Note:** this will connect to smartphones with aux input and any other devices with this input.

ANSWERING PHONE CALLS FROM THE HEADPHONES

When there is an incoming call, press the PHONE/PLAY button to answer the call and the PHONE/PLAY button again to end the call.

- To increase the volume long press the "+" button.
- To decrease the volume long press the "-" button.

CLOSED: 11 x 14 cm / OPEN: 22 x 14 cm