

成品尺寸	80x80mm
展开尺寸	80x480mm
公差	±1mm

单位:mm

4 Cannot connect to your Wi-Fi network.

Make sure you entered the correct Wi-Fi password during the Wi-Fi setup. Check whether there are any Internet connection problems. If the Wi-Fi signal is too weak, reset your Wi-Fi router and try again.

5 How many cameras can I control?

TuyaSmart app can control an unlimited amount of devices in an unlimited amount of locations. Your router may have a limit of how many devices can be connected to one router.

System Requirements

- Mobile device running iOS® 8 or higher or Android™ 4.1x or higher
- Existing Wi-Fi Network

Technical Specifications

- Audio: Internal Speaker and Microphone
- Storage: supports up to 128G Micro SD card (not included)
- Wi-Fi: IEEE 802.11b/g/n, 2.4GHz(not compatible with 5GHz Wi-Fi networks)

Note

- This manual is applicable to all series of SC002-WO2 V (X).
- Electrical symbol \approx means DC(direct current).
- Operating conditions-10°C(14°F)~45°C(113°F), less than 95% RH

CE Notice:



Product name: Smart Camera
Model number: SC012-WK2
working frequency: 2412M-2472MHz
Max Power RF: 17.03dBm EIRP

Parameter Item	Minimum value	Classical value	Maximum value	Unit
RF Average Output Power: 802.11b, 2.4GHz Mode	14.0	14.0	14.0	dBm
RF Average Output Power: 802.11g, 2.4GHz Mode	14.0	14.0	14.0	dBm
RF Average Output Power: 802.11n, 2.4GHz Mode	14.0	14.0	14.0	dBm
Frequency error	-20	0	20	ppm
EMC/RF Emissions: FCC Part 15.107(a) Mode 15.107(a)	-18	-18	-18	dBm
EMC/RF Emissions: FCC Part 15.107(a) Mode 15.107(a)	-18	-18	-18	dBm
EMC/RF Emissions: FCC Part 15.107(a) Mode 15.107(a)	-18	-18	-18	dBm

CE Products with the CE marking comply with the Radio Equipment Directive (2014/53/EU), the Electromagnetic Compatibility Directive (2014/30/EU), the Low Voltage Directive (2014/35/EU) – issued by the Commission of the European. Compliance with these directives implies conformity to the following European Standards:
EN300328 V2.2.2
EN301489-1 V2.1.1 EN301489-17 V3.1.1
EN62368-1:2014+A11:2017
EN55032:2015+AC:2016(ClassB);
EN55035:2017
EN62311:2008

WEEE



This product must not be disposed of as normal household waste, in accordance with EU directive for waste electrical and electronic equipment (WEEE-2012/19/EU). Instead, it should be disposed of by returning it to the point of sale, or to a municipal recycling collection point.

FCC Notice:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The users manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. In cases where the manual is provided only in a form other than paper, such as on a computer disk or over the Internet, the information required by this section may be included in the manual in that alternative form, provided the user can reasonably be expected to have the capability to access information in that form.

(b) For a Class B digital device or peripheral, the instructions furnished the user shall include the following or similar statement, placed in a prominent location in the text of the manual:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF exposure warning

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure

Adapter:

AC/DC adapter SKU type	Shenzhen Keye Power Supply Technology Co., Ltd.	KA1517 1000000010	Input: 100-240V~ 50/60Hz, 0.35A Max; Output: 5VDC, 1000mA Max. REC.	CE: 60958-1 2009-A2-2013 EN 60950-1 2004-A2-2013	Report No: 65.216.15.006.03 Issued by TUV SUD Certification and Testing China Co. Ltd. Shenzhen Branch
AC/DC adapter SKU type	Shenzhen Keye Power Supply Technology Co., Ltd.	KA1517 1000000010	Input: 100-240V~ 50/60Hz, 0.35A Max; Output: 5VDC, 1000mA Max. REC. <td>CE: 60958-1 2009-A2-2013 EN 60950-1 2004-A2-2013</td> <td>Report No: 65.216.15.006.03 Issued by TUV SUD Certification and Testing China Co. Ltd. Shenzhen Branch</td>	CE: 60958-1 2009-A2-2013 EN 60950-1 2004-A2-2013	Report No: 65.216.15.006.03 Issued by TUV SUD Certification and Testing China Co. Ltd. Shenzhen Branch

SMART WI-FI CAMERA USER MANUAL

Please read the instruction manual carefully before using the product

Thank you for purchasing Smart Camera. Get started using your new devices by downloading TuyaSmart, one convenient app that manages everything straight from your phone. Easily connect to your home Wi-Fi and control multiple devices from the touch of your fingertips

What's in the Box


- Smart Camera x1
- USB Cable x1
- User Manual x1
- Mounting Bracket x1 *
- Adapter x1 *
- Screw bag x1 *
- Punched sticker x1 *

*: Different products have different accessories, please refer to physical packing.

Get Ready

- Know your Wi-Fi network and password
- Make sure your mobile device is running iOS® 8 or higher or Android™ 4.1x or higher
- Make sure you're connecting to a 2.4GHz Wi-Fi network (It can't connect to 5GHz networks)

1 Download the TuyaSmart app from App Store or Google Play.



2 Register an account on your TuyaSmart app



STEP 1.
Enter your mobile phone number or email address.




STEP 2.
Enter the verification code and create a password.

3 Plug in

How do I reset my device?

- Press the Reset Button (as Pic 1) for several seconds until camera starts to beep.

- **Optional:** Insert Micro SD card as shown in Pic 2.



Pic 1



Pic 2

4 Add device

- Open TuyaSmart APP, click "+" at the top right corner of the page "HOME", then select "Smart Camera".
- Make sure the indicator light on the device is flashing red quickly, then press "Next Step".

- Enter your "Wi-Fi network and password", click "OK".



4 Add device

- Read the instruction about "Scan with the camera", click "Continue".



- Scan the QR Code on your phone with camera. Heard a prompt tone, click "Heard the beep".



4 Add device

- When the indicator light on the device turns from flashing red light to steady green light, the network configuration is complete.



*Please refer to the specific APP interface if there are any difference.

Frequently Asked Questions

1 Can I share with family and friends?

Yes, you can share your cameras with family and friends who will have access to view the camera and control your bulbs, plugs, and other devices. In the app, press the Profile button and click on the "Home Management" button, and you will be able to give or revoke sharing permissions. In order to share, the other user should already have downloaded the app and registered a new account.

2 What's the Wireless Range?

The range of your home Wi-Fi is heavily dependent on your home router and the conditions of the room. Check with your router specifications for exact range data.

3 The device appears offline or unreachable?

Make sure your Wi-Fi router is online and in range. Make sure you have the latest app functionality by clicking "Check for firmware update" in your device settings.

版本	物料编号	变更者	变更时间	版本升级原因描述
1.0		马何兵	20200327	原始版本

空白料号	/	客户 中性-涂鸦智能	产品名称	智能摄像机-摇头机	物料名称	SC012-WK2-V2智能摄像头(摇头机)-中性英文说明书	设计	马何兵
材质	105g铜版纸		型号	SC012-WK2-V2	物料编号		审核	徐明亮
颜色	白		设计编码	TUYA.SC012-WK2-V2.SMS.TYZX.WH.01			时间	20200327
加工工艺	风琴8折页,正反印刷							
印刷色	四色印刷							