## **EXHIBIT C - EUT INTERNAL PHOTOGRAPHS**

**EUT – Uncover View** 



**EUT – Uncover View** 




**EUT – Uncover View** 




**EUT – Uncover View** 









EUT – Mainboard Uncover View



EUT – Subboard Top View



**EUT – Subboard Bottom View** 



**EUT – 2.4G&5.8G TX ANT View** 







**EUT – BLE ANT View** 




**EUT – BLE Chip View** 




**EUT – 2.4G&5.8G Chip View** 



**EUT – Control Board Top View** 




**EUT – Control Board Bottom View** 




**EUT – Control Board Top View** 




**EUT – Control Board Bottom View** 






**EUT – GPS Board Bottom View** 



**EUT – GPS ANT View** 



EUT – Battery Top(small) View







**EUT – Battery Bottom(big) View** 

86 87 88 89 90 91 92 93 94 8 9 22 01 2 3 4 5 6 7 8 9 23 01 2 3 4 5 6 7 8 9



EUT - Battery Label(big) View

WARNING SA

In the Comment of the sign and comment of the Battery of the Battery