
0911-14 Reclaim RPET Wireless Charging Writing Pad



How to use

USING THE WIRELESS CHARGER

- Make sure your phone is compatible for wireless charging.
- Connect source to wireless charger via USB port, press the button to work when you use.

Then put your wireless charging enabled device on the wireless charging surface.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Warning Statements: This equipment complies with FCC radiation exposure limits Set forth for an uncontrolled environment. This equipment shall be installed and operated with Minimum distance 20cm between the radiator&body.

WARNING!

- Do not vigorously shake, hit or throw the product.
 - If the power bank is not used for long time, please charge/discharge it once every three months to ensure the service life of the product.
 - Some phone cases may block the wireless charging.
 - Do not place other materials, like metal objects, magnets, and magnetic stripe cards, between the mobile device and the wireless charger pad.
 - Check your mobile device's battery percentage using the charging icon displayed on the screen of your phone.
 - When the mobile device is not placed on the charging surface accurately, your mobile device may not charge properly.
 - If you use the wireless charger in areas with weak network coverage, you may lose your network reception.
 - Please do not expose this device to moisture or heat sources.
 - This is not a toy, not suitable for children under the age of 7.
-