

Item No: AFCS01



AVATARCONTROLS

Bluetooth Speaker (User Manual)

www.avatarcontrols.com



User Manual

Thank you for choosing the Bluetooth Speaker by AvatarControls. This product is part of the Freecube series and will function with the AvatarControls Freecube USB power Socket Base or independently on its own. For the best experience with your Bluetooth Speaker, please read the user manual carefully before use. The user manual includes an introduction to the product, detail directions and as well as important safety information.

Packing List:

Bluetooth Speaker * 1
User Manual * 1


Product Appearance:



Specification :

- SNR : 89DB
- Micro USB Input : 5V/1A
- Input Voltage : 5V/24V DC
- Built in Battery: 2200mAh
- Audio Power Output : 5W*2
- Bluetooth Connection Distance: ≤32.8ft (≤10m)
- Working Temperature: 14°F ~ 140°F (-10°C ~ 60°C)
- Dimensions(WxDxH) : 4.6 x 4.6 x 2.5 in (116 x 116 x 63mm)

How to use:



1. Assembly

- The Bluetooth Speaker can be placed on any layer and any direction of the Freecube. The Bluetooth Speaker can be used once the metal connection is placed on the Freecube. The Freecube will automatically charge the speaker while in use.

2. External powered

- The Bluetooth Speaker can be used independently without the Freecube USB power Socket Base. A micro USB cable can be used to supply the power and charge the battery. In external powered mode, if the machine is turned off, the indicator light will show the battery's charging state by illuminating a red light.

3. Battery powered

- The Bluetooth Speaker comes with a built-in battery, which allows the speaker work independently for 4-12 hours.

4. Bluetooth music playback

- Search and pair "Freecube" Bluetooth settings on your phone. Once the connection is successful, you can start using it.

5. TF Card music playback

- Insert TF card, the speaker will automatically start playing music files stored in the TF card. If the bluetooth is connected at the same time, you can easily switch between TF card mode and Bluetooth mode by double clicking the play button.

Attention:

- Don't hit Bluetooth speaker body.
- Don't contact benzene, diluent and other chemicals.
- Don't get close to magnetic and electric field.
- Avoid direct rays or heating appliances.
- Don't disassemble, repair and rebuild.
- Please properly classify and dispose of waste packaging, batteries, old electronic products.

Operation Instruction:

Function	Operation	Indicator light
Turn on	Press "▶ "	Green
Turn off	Press "▶ " and Hold for 2s	Off
Play	Press "▶ "	Green
Pause	Press "▶ "	Green Flashing
Next	Press "▶ "	No change
Previous	Press "◀ "	No change
Volume Up	Press & Hold "▶ "	Beep Sound
Volume Down	Press & Hold "◀ "	Beep Sound
Disconnect Bluetooth	Press & Hold "▶ " & "◀ "	Beep Sound
Switches Mode	Double Click "▶ "	Voice prompts

Note: The device has Bluetooth mode and TF card mode. You can play audio files transmitted by Bluetooth in Bluetooth mode. You can also play MP3 and WAV files stored in TF card while in TF Card mode.

Troubleshooting:

Problem	What to do
No power (Battery Mode)	The state of battery may be in protection mode or discharged. Please charge it and it is recommended to use the speaker after 2 hours charging.
No sound from your Bluetooth speaker	<ul style="list-style-type: none"> • Power on the speaker. • Make sure the speaker is in Bluetooth mode or TF card mode. • Increase the volume on the speaker, your mobile device and music source. • Move your mobile device closer to the speaker and away from any interference or obstructions. • Use a different music source. • Pair another mobile device. • If two mobile devices are connected, pause your other mobile device first. • On your mobile device: <ul style="list-style-type: none"> - Turn off and on the Bluetooth feature. - Remove the speaker from the Bluetooth menu. Pair again. • Clear the speaker's pairing list. • Reset the speaker. • Check your mobile device for compatibility. Refer to your mobile device owner's guide.

Problem	What to do
Poor sound quality	<ul style="list-style-type: none"> • Use a different music source • Pair another mobile device. • Disconnect the second device. • Move your mobile device closer to the speaker and away from any interference or obstructions.
No music plays from TF card	The speaker only supports music in MP3 and WAV formats. Other formats of music are not supported.
The Bluetooth Speaker does not respond when the power supply is connected	Push the reset button to return the Bluetooth Speaker to its original factory settings.
After a few hours of charging, the battery does not perform for the expected time.	Please make sure the music function is off during charge. The charging time will be extended while playing music.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, Human proximity to the antenna shall not be less than 20cm (8 inches) during normal operation.

Made in China

Warranty Card

User Name: _____
Address: _____
Contact: _____
Order Date: _____

Guarantee Clause:

- Within 7 days since goods are sold, if there is performance failure, commodity itself and the outer package is complete (no scratches), can replace the sample type of goods, not including man-made damage.
- The goods are guaranteed for one year from the date of sale. The accessories are not covered by the warranty.
- The warranty service will be only effective under normal use.
- All the man-made damage, disassembly, stripping, improper use etc, is not covered by warranty.
- The warranty card must be provided when ask for warranty. Failure to provide this card or alter the card without permission, the company has privilege to refuse warranty.