一、Remote control

二、   Remote control function description

2.1、   Code function:

A、Press the flashlight button，enter into code state；Bounce

button,exit the code state。

   B、 the code is ok，then 3 timing indicators slow flash（2Hz) 2 times。

2.2、Keyboard：Press the corresponding key to output corresponding key value, the key always press the signal output, release the key, the signal stops output.The corresponding key values are shown below:

0x01	0x02	0x03
0x04	0x05	0x06
0x07	0x08	0x09
0x0a	学习	0x0c
0x0d	0x0e	0x0f
0x10	0x11	0x12

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.