



.oukitel.

K6000 Plus

Quick Guide



FCC 🗘

<u>o</u>.

Getting to know your mobile

-P/L sensatior

Volume

On/off

OUKITEL

The contents of this manual may differ in certain respects from the description of your phone depending on its software version and your telephone operator





How to use the phone keys

Receive Notification LED

Car

In any screen, In any screen, Tap " ⊃ ", to return to previous screen or to exit the application. Tap " ⊃ ", to return to the main menu. Tap " ■ ", to display/clear all recent apps Tap the "on/off" button, to turn on an off the screen and block the screen. Long press "on/off" to shut down or to restart your mobile. Press and hold the "on/off" button and then press the volume down key to take a screen capture.

Language

Tap the settings icon. Scroll down and tap the "Language and input", then choose language in the field "language"

warmth.

Making Calls

Pressing the button of "People", email. message or any telephone number on the phone then you make a phone call. Or make a phone then you make a phone call. Or make a phone call by using the dial keyboard in the "Dialing" application program.

Message

Tap the "Messaging" icon. then you can send a message to other user. Input names and telephone numbers on the "Receiver" field, or choose someone in the contact list, then press the "sending" button after inputting the message. Please press the " \bigoplus " button if you want to send a photograph,

Input and edit

The OUKITEL mobile will have some recommendation when you are inputting. If you want to edit a text, please choose the text and then press it for several seconds, move the insetting point or using the select all, cut and copy ways



Retaining clip and moving

Tap the "Camera" icon to open the camera, switch to video mode. Tap" Tap" , ready video clips important moment in your life at any time.

Enjoy the colorful photos

Tap the "Galler" icon to open the atlas . Feel free to browse photographs, memories moving moment. View a photo, tap" S "to enter the edit mode, you can crop photos, adjust color filter effects, such as increased landscaping operations.

Send Gmail Tap the "Email" icon

After setting the e-mail account, you can send and receive messages via mobile phone, you can keep in touch with friends or clients at any times anytime and anywhere



Gmail

Enjoy Google Play Music

Record colorful moments

Tap the "Camera" icon to open the camera.

of intelligent beauty, HDR, panorama shot,

smile mode automatically identify. Voice

camera features allow small gathering of

friends, family photo to add more fun and

OUKITEL mobile support a variety of pictures

Tap the "Music" icon. You can play songs by Artists, Albums, Songs and other models





Google Play Music

Please read this safety information carefully so that you can use your phone in complete safety

1. Children : Be very careful with children and your phone. A mobile phone contains a number of detachable parts. Take great ca . Cinicet is be very careful with characteria and your piones. A moore pione contains a number of detactable parts. Take great care when children are in close proximity to the phone. The phone contains a mail parts that could be swallowed or cause choking. If your phone is equipped with a camera or lighting device, do not use it too near children or animals.

- 2. Hearing : Prolonged listening at full power using a lightweight headset or headphones can damage your hearing. Reduce the volume to the lowest possible level when listening to music or conversations. Avoid high volumes over extended periods.
- 3. Driving : Take care when driving. Driving requires maximum attention at all times in order to minimise the risk of accidents. Using a mobile phone can distract the user and result in an accident. You must fully comply with the local regulations and laws in force regarding the uso i coll phones whilst driving. You are not allowed to use the phone whilst driving. A hands-free ki should not be regarded as an alternative solution. Flying : Turn your phone off when flying. Remember to turn your phone off when you are in a plane (GsM + Bluetooth) as it may cause interference.
- 4. Hospitals : Turn your phone off near any medical devices. It is extremely dangerous to leave a phone switched on near medical devices as it may be prior on new or ne New or new inside a professional garage.
- 5. Electronic implants and pacemakers : Users who wear a pacemaker or who are fitted with an electronic implant must hold the phone on the opposite side to their implant as a precaution when making a call. If you notice that your phone is causing interference with a pacemaker, switch it off immediately and contact the manufacturer of the pacemaker for advice on what action to take. 6. Fire hazard : Do not leave your device near heat sources such as radiators or cookers. Do not leave your phone charging near

- flammable materials as there is a real risk of fire. . Contact with liquid : Do not expose the phone to liquid or touch it with wet hands : any damage caused by water may be irreparable. 8. Use only OUKITEL-approved accessories. The use of unauthorised accessories may damage your phone or cause a safety risk. 9. Do not destroy the batteries and chargers. Never use a battery or charger that has been damaged, keep batteries away from magnetic objects as the latter might cause a short-circuit between the positive and negative terminals of your batteries and magnetic objects as the natient implificates a short-circuit outween the positive and inegrative eliminatis or your batteries and permanently destroy the battery or hone. As a general rule, you should not expose the batteries to very high or low temperatures (below 0° co above 45° c). Differences in temperature may reduce battery autonomy and service life. 10. Shocks and impact : Handle and use your phone with the utmost care. Protect your phone : shocks and impact may damage it, some
- parts of your phone are madefrom glass and might break if the phone is dropped or is subject to severe impact. Avoid dropping your nhone. Do not touch the screen with sharp objects
- I. Electric solver to an actual multi advant multi appropriate
 II. Electric shock: Do not try to dismantle your phone as there is a very real risk of electric shock.
 I. Maintenance: If you want to clean your handset, use a dry cloth (do not use a solvent, such as benzene, or alcohol).
 I. Recharge your phone in a well welliated area. Do not recharge your device when it is resting on a soft surface.
 I. Damage to magnetic strips : keep your phone away from credit cards as they may damage the data on the magnetic strips.

[ES] Seguridad

Para utilizar este teléfono en plenas condiciones de seguridad, lee atentamente las siguientes consignas de seguridad

1. Niños : Presta especial atención a los niños. Los teléfonos móviles contienen numerosas piezas sueltas, por lo que deberás prestar especial atención cuando un niño esté en contacto con un teléfono móvil. Este producto contiene pequeñas piezas que pueden ser ingeridas

atención cuando un niño esté en contacto con un teléfono móvil. Este producto contiene pequeñas piezas que pueden ser ingeridas o provocar la asfixia en caso de ingesitón accidental. si lu teléfono cuenta con cámara fotográfica o un dispositivo de iluminación, no los utilices demasiado cerca de los ojos de niños o de animales. 2. Audición : La escucha prolongada a fuerte potencia a través de cascos o auriculares puede provocar daños en la audición. Trata de regular el volumen al minimo necesario cuando estés escuchando de música o durante una llamada. Evita la escucha prolongada a volumen elevado. 3. Al volami: e se cauto mientas conduces. La conducción exige una atención extrema e ininterrumpida, reduciándose asi el riesgo de accidentes. Utilizar un teléfono móvil puede distraer la atención del usuario y conducirle a un accidente. Es esencial respestar escru-pu§asmente la legislación y las formativas locales en vigor en materia de utilización de letáfonos nainatámicos al volante. Por consiguienta está prohibido hacer uso de teléfono conduciendo, y la utilización de un kit manos libres no puede considerarse una solución. En avión : Apaga tu teléfono en el avión. No olvides apagar tu teléfono cuando te encuentres en un avión (CsM + Bluetooth), ya que podrian producirse interferencias.

 En hospitales: Apaga tu teléfono cuando haya próximo cualquier dispositivo médico. Es muy peligroso poner en marcha un teléfono habiendo próximo un dispositivo médico. Esto puede provocar interferencias con dichos dispositivos. Por consiguiente, han de respetarse todas las consignas y avisos en hospitales o centros de salud. No olvides apagar tu teléfono en las estaciones de servicio. No utilices tu móvil en una gasolinera, en la proximidad de combustibles. Es peligroso utilizar tu teléfono en el interior de un taller de reparación. 5. Implantes electrónicos y marcapasos : Las personas que tengan un implante electrónico o un marcapasos deben adoptar la precaución de colocar el teléfono en el costado opuesto al implante durante una llamada, si percibes que tu teléfono provoca interferencias con un marcapasos, apaga inmediatamente el teléfono y ponte en contacto con el fabricante del marcapasos o con tu médico con el fin de informarte sobre qué conducta adoptar.

6. Riesgos de incendio : No dejes tu teléfono próximo a fuentes de calor como un radiador o cocina de gas. No recargues tu teléfono cerca de materias inflamables (el riesgo de incendio es incuestionable). Contacto con líquidos: Evita todo contacto del teléfono con líquidos o con manos moiadas. El aqua puede provocar daños irreparables.

- 8. Utiliza exclusivamente accesorios homologados por OUKITEL. La utilización de accesorios no homologados puede deteriorar tu teléfono o
- No manipules las baterias ni los cargadores. Nunca utilices una batería o cargador dañados. No pongas en contacto con las baterías objetos magnetizados, ya que existiria riesgo de cortocircuito entre los bornes + y de las baterías así como de dañar la batería o el telefono de forma de las baterías en el telefono de forma irremediable. En términos generales, no expongas las baterías a temperaturas muy bajas o muy elevadas (inferiores a 0°C o superiores a 45°C). Esas diferencias de temperatura pueden reducir la autonomía y vida de funcionamiento de las baterías.
- Caidas o inclución de la consecta dela consecta de la consecta dela consecta dela consecta de la c
- 12. Mantenimiento si deseas limpiar tu teléfono, utiliza un trapo seco (nunca disolventes, como el benceno, ni alcohol).
- Har manimumo de control maginar de control de la control de la control de control de control de la co