

OUKITEL

Mobile Phone

User Guide

Foreword

- The manual is specially designed to guide you how to use the phone.
- We reserve the right not to inform user, when modifying function, interface and appearance of product.
- Due to software upgrade and other factors, the description and the actual product is different, please the actual product shall prevail.
- Please follow the normal steps to shut down, install the card in the right direction to avoid damage to the card or phone.

Safety Tips

- In order to use your phone safely and effectively, please read the following information carefully before using the phone.
- Please turn down the volume to prevent irreversible damage to your hearing before answering the call.
 - Please turn off your phone in the place where you are prompted to turn off or put a ban on the phone (such as airports, gas stations, hospitals, etc.).
 - Keep your phone and all accessories away from static electricity, dust and water.
 - Avoid exposure to excessive cold or heat (under -20°C or over 60°C), moisture or caustic environments.
 - Do not place your phone near flames, lit cigars or cigarettes.
 - Do not drop, throw or bend the phone.
 - Do not put the phone with the computer disk, credit card, travel card or other magnetic objects, Otherwise, the information stored on the disk or credit card may be affected by the phone.
 - Do not use your phone during thunderstorms, so as not to be struck by lightning or other damage.
 - Please do not disassemble and repair the phone and accessories without authorization.
 - Turn off your phone in areas with a potentially explosive atmosphere** (e.g. petrol stations and also areas where the air

2

contains dust particles, such as metal powders).

- Turn off your phone in an aircraft.**
The use of mobile phones in an aircraft may be dangerous for the operation of the aircraft, disrupt the mobile phones network and may be illegal.
- Turn off your phone in hospitals, clinics, other health care centers and anywhere else where you may be in the close vicinity of medical equipment.**

- Keep away from personal medical device.**
If you have a pacemaker, please always keep the phone more than 15 cm from your pacemaker when the phone is switched on, in order to avoid potential interference. Do not carry the phone in a breast pocket. Use the ear opposite to the pacemaker to minimize the potential interference. Turn off your phone if you suspect that interference is taking place.
- Driving Safe.**
Avoid using your phone while driving and obey all regulations that restrict the use of mobile phones while driving. If you want to use your mobile phone, please leave the driveway and stop.

- Keep your phone and all accessories out of the reach of children.**
Keep your phone and all accessories out of the reach of small children. Small parts may cause choking or serious injury if swallowed.

Precautions on Accessories

You should only use Manufacturer Authentic Accessories, as the use of any other accessories may damage your phone and may be dangerous, and will make all guarantees for your phone null and void.

- Charger: Make sure the charger is connected to the power source within the specified voltage range.** In order to avoid the danger of electric shock, please remove it from the power supply before cleaning it. The charger is forbidden to be used in outdoor or wet environments. Do not replace the charger's wires and plugs.
- Battery:** Use specified charger only. Make sure the charge is at a temperature of 0 °C to +45 °C.
Please remove the charge or USB cable in time when charging is

3

completed.

If the phone, charger or other accessories are not work, please bring the phones and accessories to the nearest professional maintenance department authorized by our company. The maintenance department will assist you, and arrange repairs if necessary. Do not incinerate, do not deform or open the battery, do not short circuit the battery, so as to avoid an explosion. When battery is abandoned, please deal with the battery according to the local regulations on disposal of waste electronic products, and can not be treated as ordinary urban waste.

Getting started

> SIM card and T-flash card

SIM card: The product is a SGM phone. You can do something without SIM card. But the communication function can only be used with SIM card. If NO SIM card, you can only make the emergency call (such as: 112—in Europe, 999—in UK)

[Tips:] The device allows dual SIM standby but only one SIM operating at any moment.

T-flash card: the phone support T-flash card expansion, the capacity up to 32GB.

> Keys Definition

Keys	Function
Left soft key	Press the key to select the options on the screen. Longpress the key to unlock keys.
Right soft key	Select the options on the screen.
Dial key	Make or answer a call.
Confirm and navigation keys	Confirm key: press it to select or confirm an option, long press it to activated SOS Up key : to Audio player, Down key: to Camera, Left key : to Write message, Right key: to Profiles
Hang-up/Exit/Power/Lock	End a call; Return to home screen; Hold to turn on/ off the phone. Press it to lock keys on home screen.

4

Number keys: 1 ~ 6	keys: Press a key to enter a digit; Long press a numeric key to dial the number in First Aid List.
Number keys: 7, 9, 0	Press a key to enter the corresponding digit.
8 key	Press the key to enter digit 8; Long press the key to start recording.
Star key	Press * key to enter * sign; Long press to switch */+/p/w.
# key	Press the key to enter # sign; Long press the key to switch between General mode and Silent mode.

> Turn on/ off:

Long press **power key** to turn on/ off the phone. If you have set the SIM pin or phone lock, you should enter the password when turning on.

> Enter text

Your phone supports a number of text entry methods, English input, Spanish input, numeric input and symbol input.

> Phonebook

You can browse contacts by **Up/ Down key** in phonebook. You can add new contact to phonebook. And you can view, send SMS, call, edit, delete, copy, add to blacklist and other operation to select the contact, and manage your phonebook by **Phonebook settings**.

> Messaging

You can use the **Message** menu to send text message. Following are the submenus:

Menu	Function
Write message	To create and edit new SMS.
Inbox	Store and manage received messages.
Drafts	You can save unsent and edit incomplete messages
Outbox	Store and manage sending failed messages.
Sent messages	Store and manage sent messages.
SMS settings	You can set SIM options(on SMS), sms black list, Memory status, text msg. counter, Save sent message, Preferred storage and so on.

5

> Call center

It includes **Call history** and **Call settings**.

You can view and manage the call log, includes Missed calls, Dialed calls, Received calls, All calls, and Delete call logs in "Call history" submenu.

Call settings includes **SIM call settings** and **Advanced settings**.

You can set Call waiting, call divert, Call barring, Line switching, You can set Blacklist, Auto redial, IP dial, Call time reminder, Auto call record, Answer mode in Advanced settings menu.

> Multimedia

Camera: You can take photos as desired by using your phone.

Image View: You can browse and manage images in your phone. And you can set the photo as wallpaper.

Video recorder: You can record your video by using your phone. The recorded video is only in AVI format. You can set the video recorder by "Options" menu. (Include Anti-flicker video quality)

Video player: Play and manage video files in your phone. Using the following keys to control playback:

Keys	Function
* key or # key	To adjust volume.
Right soft key	Return to the previous menu.
Confirm key	Pause and resume playback
Left key or Right key	Press the navigation key to select previous or next video file.
Up key	To full screen mode.
Down key	To stop playback.
Power key	Return to the Home screen.

[Note] Your phone can only play low definition videos that compatible with your phone's screen size.

Audio player: You can play and manage songs in **Music folder** on your memory card. During playback, you can pause/play, next/previous song, adjust volume and other operations. The key's definition is similar to video player. Press **Up key** to switch repeat playing, press **Down key** to turn on/ off shuffle.

Sound Recorder: You can record your audio by using your phone. Make sure T-flash card is inserted to your phone before

6

recording.

FM radio: You can listen to your favorite FM broadcast. You can also manage Channel list, Manual input, Auto search and other operations.
File manger: You can use and manage your files and folders in your memory card and your phone.

> Seetings

Profiles: The profiles are defined for 3 scenes: **General**, **Silent** and **Outdoor**. They consist of the settings for ringtone, volume, and others. With preset profiles, you can easily adjust the settings for incoming calls and messages as desired.

Phone settings: You can set the following Settings: Time and date, Schedule power on/ off, Language, Pref.input method, Display, Shortcuts, Dedicated key, Flight mode and Misc. settings

Dual SIM settings: You can set reply call/ message or transfer data by SIM1/SIM2.

Security settings: This menu allows you to use passwords or pin lock to protect your phone.

Network settings: Select the network for your phone (service subscription dependent). **Automatic** search mode is recommended. And you can select the preferred GPRS transfer mode.

Services: This menu allows you access to services provided by the operator.

Restore settings: Restore your phone settings to the default values. You need to enter your phone lock password (0000 by default).

> Organizer

Bluetooth: Support Bluetooth headset and file transfer via bluetooth.

Submenu	Definition
Power	Turn on/ off the Bluetooth function.
Visibility	Make your phone visible to other Bluetooth devices.
My device	View connected devices and search new device.
My name	View and edit your bluetooth name.

Talking Mobile

Function	Definition
Mainmenu speak	Turn on/ off the function of broadcasting menu

7

	name in the mainmen.
Call this number	Turn on/ off the function of broadcasting number in phonebook.
Keypad tone	Turn on/ off the function of broadcasting number, when pressing a numeric key.
Incoming Call Notify	Turn on/ off the function of broadcasting number, when there is an incoming call.
Volume	Set the volume.

[Note] Talking Mobile function is off in silent mode.

First Aid Settings

Function	Definition
Mode	Turn on/ off the SOS function.
First Aid List	Set SOS number.(Total:6)
First Aid SMS	To edit SMS for help.
First Aid Auto Held	Turn on/ off the function of auto answer when the number is call in First Aid List.
Readme	The description of the First Aid Function.

[Note]

- 1) Long press Confirm key in Home screen to dial the numbers that have set in First Aid List and send SMS to these numbers.
- 2) If mode is off, you can **do not dial** by long press a number key in Home screen.

Other Tools

Tools	Functional Definition
Alarm	Provide 5 alarms for you. You can set them according to your needs.
Calendar	You can easily view the date at any time, and browse other dates by navigation keys.
Calculator	You can use Calculator to perform simple calculations.

8

"Three Guarantees" for Product Quality No.

User's Certificate of "Three Guarantees"

NAME	TEL	
ADDRESS		
POSTCODE	PURCHASE DATE	
PURCHASE NO.	DATE of PRODUCTION	
NO. of MAINFRAME		ORIGINAL OF CHINA
NO. of BATTERY		
NO. of CHARGER		
IMEI/ESN NO. of MAINFRAME		
Access-to-Network NO.		
BATTERY SN		
BATCH NO. of BATTERY		
DISTRIBUTOR		
ADDRESS	TEL	
ADDRESS		
SELLER	STAMP	

NOTICE

1. Please fill in this form carefully, and make sure stamp by the shop, or it will be invalid.
2. Please take care of this form and the invoice, which is the certificate of "Three Guarantees".
3. Please keep in contact with our sale service, our engineer will answer your questions in timely.

9

OUKITEL
CERTIFICATION
DATE of PRODUCTION _____
MODEL _____
INSPECTORS _____
Shenzhen Yunji Intelligent Technology Co.,LTD

10

Emergency call

If any emergency arises, dial 112/911 (or other emergency call number) for emergency help. Due to the nature of cellular networking, the success of emergency call is not guaranteed.

FCC Warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue.

Device types L1 (FCC ID: 2ANMU-L1) has also been tested against this SAR limit. The highest reported SAR values for head, body-worn accessory are 0.66 W/kg, 0.67 W/kg respectively. The Max simultaneous SAR is 0.73W/kg. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.