







User Manual and Warranty

S STORY

SIMPLE TOUCH CONTROL TO OPERATE ALL FUNCTIONS

Functions vary depending on your phone, tablet

CONTROL -O— INDICATOR —O

MICROPHONE -

S STORY

HARGING PORT

Play time

Recharge time

SPECIFICATIONS

35.8 x 21.8 x 24 mm (LxWxD)(earbuds)

59.6 x 28 x 49.7 mm (LXWXH)(charging case)

Bluetooth profiles A2DP, HSP, HFP, AVRCP Connectivity class Bluetooth Class 2 (10 meter) High performance driver 2 x Ø8 mm 20 Hz - 20 kHz Frequency response Sensitivity 90dB +/- 3dB at 1kHz Impedance Micro USB charging Charging method

Lithium-ion battery Battery type Battery capacity 2 x 30 mAh (earbuds) 350 mAh (charging case) Total 15 hours (Earbuds playtime is

Dimensions

PERATE YOUR EARBUDS

Bluetooth Connection

source (music player, smartphone, laptop or | turn to steady blue. (Support single earbud other Bluetooth equipped device that can use) take out from the charging box. When take last Bluetooth device it was paired with. out both earbuds form the charging box at the same time. The LED indicator light will ours and the charging case can provide flash between red and blue, and the left (varies by volume level and audio content) | and right earbuds will be paired successfully. Approx.1 hours (earbuds) At this time, it can be connected to the Approx. 1.5 hours (charging case) Bluetooth equipped device. Make sure Bluetooth is enabled on your audio source


and in a few moments 'MUVEACOUSTICS:-

FREE' will appear on your list of possible Bluetooth connections. Press 'pair' or To use Bluetooth for your audio connection, | 'connect' on your device and after the first pair FREE earbuds with your audio , connection is made, the indicator light will

act as audio source). Make sure FREE From now on, when you turn on FREE earbuds is fully charged and turn it on by earbuds, it will automatically search for the

Earbuds Battery Charging

Put the earbuds into the charging box, it will Please use the cable provided to recharge the automatically shut down and start charging.



Charging Case Battery Charging

charging case. It will take 1.5 hours to fully charged.



GUIDANCE

Function	Button	Audio	LED	Fun
Turn On & the pairing mode	Take out the earbuds from the charging	N/A	Red/Blue light flashing	Inco
Pairing success	box	2 tones	Blue light	End
Play / pause	Press the touch control area twice	N/A	N/A	Refu
Turn Off	Put the earbuds into the charging	N/A	LED lights turn off	Voic

0	(11010)		_,		01 210	(11010)	_
unction	Button	Audio	LED] , [Function	Button	Α
coming all	Press the touch control area twice	N/A	N/A		Earbuds battery charging	N/A	N
nd a call	Press the touch control area twice	N/A	N/A		Earbuds battery fully charged	N/A	N
efuse coming all	Press & hold the touch control area for 2 seconds	N/A	N/A		Charging case battery charging	N/A	N
oice ssistant epend on the nnected device)	Press & hold the touch control area for 2 seconds	1 tone	N/A		Charging case battery fully charged	N/A	N

L GUIDANCE | OPERATIONAL GUIDANCE

Function	Button	Audio	LED
Earbuds battery charging	N/A	N/A	Red light goes on constantly (Charging case: Green light goes on constantly)
Earbuds battery fully charged	N/A	N/A	Blue light goes on constantly (Charging case Green light keeps on for 10 seconds)
Charging case battery charging	N/A	N/A	Blue light flashing constantly
Charging case battery	N/A	N/A	Blue light goes on constantly

THE COMMUNIT

· contests

access to new products launch



www.muveacoustics.com/community

封面 (cover) 封底 (back cover)

Thank you for trusting MUVEACOUSTICS with delivering you excellence in sound. We encourage you to connect with us and become a part of our community!

SCAN THE OR CODE YOU WILL FIND INSIDE. SHARE WITH US YOUR PRODUCT EXPERIENCE.

www.muveacoustics.com



MUVEACOUSTICS®

SOUND THAT INSPIRES

muveacoustics

MuveAcoustics

MuveAcoustics

hazard. Not suitable for children under age three. Set a low volume setting before using the earbuds. Long-term exposure to loud music or sounds may cause hearing damage. It is best to avoid high volume levels when using these earbuds, especially for extended periods • Do not use these earbuds when operating a motor vehicle, a bicycle, machinery or where

Contains small parts which may be a choking

your inability to hear outside sounds may present a danger to you or others.

Using these earbuds limits your ability to hear

Please use caution when using these earbuds. • Do not drop, sit on, or allow the earbuds to be immersed in water.

This symbol indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment.

Unsuitable for children under three years because it might, for instance, contain

To prevent possible hearing damage, do not listen at high volume levels for long periods.

noises around you, regardless of listening volume.

The input voltage to the product is 5V 1A. For your safety, please always use

appropriate 5V input charger/Adapter to charge the product. DO NOT USE Quick

Charging USB Adapter to charge the product, as it might damage the product. Only charge the product at ambient temperatures between 10 deg °C / 50 deg °F and 40 deg °C / 104 deg °F.

Do not heat above 70 deg °C / 158 deg °F, eg. Do not expose to sunlight or throw into Switch off the product after use.

Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during

the time the user using this product. In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development.

FCC Statement NOTE: This equipment has been tested and

found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC | Regrient or relocate the receiving antenna. reasonable protection against harmful and receiver. interference in a residential installation. This - Connect the equipment into an outlet on a radio frequency energy and, if not installed connected. may cause harmful interference to radio

communications. However, there is no guarantee | Changes or modifications not expressly approved that interference will not occur in a particular by the party responsible for compliance could void

and used in accordance with the instructions, | - Consult the dealer or an experienced radio/TV

installation. If this equipment does cause the user's authority to operate the equipment. harmful interference to radio or television | This device complies with Part 15 of the FCC Rules. reception, which can be determined by turning Operation is subject to the following two conditions: the equipment off and on, the user is | (1) this device may not cause harmful interference, encouraged to try to correct the interference by and one or more of the following measures: (2) this device must accept any interference

Rules. These limits are designed to provide '- Increase the separation between the equipment ' The device has been evaluated to meet general RF

equipment generates uses and can radiate | circuit different from that to which the receiver is technician for help.

received, including interference that may cause undesired operation. exposure requirement. in portable exposure condition

ONE-YEAR LIMITED WARRANTY

MUVEACOUSTICS FREE earbuds have been

subjected to a thorough series of tests to ensure the highest level of dependability. It is unlikely that you will experience any problem, but if a defect should become apparent during the use of this product, MUVEACOUSTICS warrants to the original purchaser that this product will be free from defects in material and workmanship for a period of 12 months from the date of your

original purchase from an authorized dealer. If a

defect covered by this warranty occurs,

replace the product purchase at no repair charge (postage charges will apply). If a replacement is necessary and your product is no no months warranty policy, please contact

professional or commercial purposes.

longer available, a comparable product may be substituted at the sole discretion of MUVEACOUSTICS.

tear, abusive use or misuse, modification, tampering or by any other cause not related to Zeeva Electronics Private Limited. either materials or workmanship. This warranty All rights reserved. does not apply to product used for any industrial,

MUVEACOUSTICS, at its option, will repair or \bot CUSTOMFR **SERVICES** For service on any defective under 12

Email: consumersupport@zeeva.com This warranty does not cover normal wear and _ Keep all relevant information for future reference

901-902. Trade World C wing Kamla Mill Compound, Senapati Bapat Marg. Lower Parel West. Mumbai-400013

20202905

Sign up now for · special offers events



(back

(front)

55 mm(W) 3 mm(W) thickness of bookle