

封面 (cover)

封底 (back cover)

662 mm(W)

PMS 281 U

07July 2020

PO 20200306
Halipu version

70 mm(H)



Thank you for trusting MUVEACOUSTICS with delivering you excellence in sound. We encourage you to connect with us and become a part of our community!

SCAN THE QR CODE YOU WILL FIND INSIDE. SHARE WITH US YOUR PRODUCT EXPERIENCE.

www.muveacoustics.com



MUVEACOUSTICS®
SOUND THAT INSPIRES



Bluetooth Connection

Devices with Bluetooth 5.0 wireless technology or above, such as Bluetooth wireless technology equipped computers, smartphones, tablets and MP3 players. To use Bluetooth for your audio connection pair EDGE 2PRO with your audio source (music player, smartphone, laptop, or other Bluetooth equipped device that can act as a source of music). First turn on your Bluetooth connection on your device, then press and hold the On/Off button for 3 seconds until you hear "pairing". The EDGE 2PRO is in pairing mode. The blue and red Sync LED will blink. Make sure Bluetooth is enabled on your audio source and in a few moments "MUVEACOUSTICS:EDGE 2PRO" will appear on your list of possible Bluetooth connections. Press "pair" or "connect" on your device and when the connection is made you will hear "your device is connected". You are paired. From now on, when you turn on EDGE 2PRO, it will automatically search for the last Bluetooth device it was paired with.

Battery Level and Charging

EDGE 2PRO comes with lithium-ion polymer battery. For best results, fully charge EDGE 2PRO before use. It will take 1.5 hours to fully charged. When the battery voltage is low, red light replaces blue light with voice notification "battery low" every 5 seconds. EDGE 2PRO will automatically shut off, after disconnected or no pairing with Bluetooth enabled device for 5 minutes or when the battery power level is very low.

Please use the cable provided to recharge the earphones. Red LED light up during charging and it will turn blue once fully charged.

SAFETY INSTRUCTIONS

Warnings

- Contains small parts which may be a choking hazard. Not suitable for children under age three.
- Set a low volume setting before using the earphones.
- Long-term exposure to loud music or sounds may cause hearing damage. It is best to avoid high volume levels when using these earphones, especially for extended periods.
- Do not use these earphones when operating a motor vehicle, a bicycle, machinery or where your inability to hear outside sounds may present a danger to you or others.

Cautions

- Using these earphones limits your ability to hear noises around you, regardless of listening volume.
- Please use caution when using these earphones.
- Do not drop, sit on, or allow the earphones to be immersed in water.



This product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment.



Unsuitable for children under three years because it might, for instance, contain small parts.



To prevent possible hearing damage, do not listen at high volume levels for long periods.



The input voltage to the product is 5V 1A. In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger / adapter for charging the product. Only charge the product at ambient temperatures between 10 deg °C / 50 deg °F and 40 deg °C / 104 deg °F. Do not heat above 70 deg °C / 158 deg °F, eg. Do not expose to sunlight or throw into fire. Switch off the product after use. Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product. In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development.

FCC Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
*Increase the separation between the equipment and receiver.
*Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio / TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.



FCC ID: 2ANVW-MA1020

MUVEACOUSTICS ONE-YEAR LIMITED WARRANTY

MUVEACOUSTICS EDGE 2PRO earphones have been subjected to a thorough series of tests to ensure the highest level of dependability. It is unlikely that you will experience any problem, but if a defect should become apparent during the use of this product, MUVEACOUSTICS warrants to the original purchaser that this product will be free from defects in material and workmanship for a period of 12 months from the date of your original purchase from an authorized dealer. If a defect covered by this occurs, MUVEACOUSTICS, at its option, will repair or replace the product, purchase at no repair charge (postage charges will apply). If a replacement is necessary and your product is no longer available, a comparable product may be substituted at the sole discretion of MUVEACOUSTICS.

This warranty does not cover normal wear and tear, abusive use or misuse, modification, tampering or by any other cause not related to either materials or workmanship. This warranty does not apply to product used for any industrial, professional or commercial purposes.

CUSTOMER SERVICE



For any service or technical queries, please contact our service team on the below email.



Email: consumersupport@zeeva.com

Keep all relevant information for future reference

Imported and distributed by Zeeva Electronics Private Limited. All rights reserved

901-902, Trade World C wing Kamla Mill Compound, Senapati Bapat Marg, Lower Parel West, Mumbai-400013

20200306

INCLUDES:
EDGE 2PRO Wireless In-Ear Earphones
Micro USB Charging Cable
An Universal Size Ear Hooks
Extra Ear Cushions
User Manual & Warranty



User Manual and Warranty MA-1020

60 mm(W) 2 mm(W)

面 (風琴摺) Front
底 Back

FEATURES





EAR CUSHIONS REMOVAL

REMOVE THE EAR CUSHION TO REPLACE WITH THE ONE THAT FITS BETTER YOUR EARS.



HOW TO CHARGE YOUR EDGE 2PRO



PRODUCT SPECIFICATIONS

Bluetooth 5.0
HFP, HSP, A2DP, AVRCP
Connectivity class Bluetooth Class 2 (10 meter)
High performance driver 2 x 10mm
Frequency response 20 Hz - 20 kHz
Sensitivity 95+/- 3 dB
Impedance 32 Ohm
Signal to noise ratio ≥57 dB
Battery type Lithium-ion polymer battery
Battery capacity 60 mAh
Play time up to 7 hours
(varies by volume level and audio content)
Recharge Time about 1.5 hours
Charging method Micro USB charging
Dimensions 580 x 25 x 25mm

OPERATIONAL GUIDANCE

Function	Button	Audio	LED
Turn on & the pairing mode	Press and hold the On/Off button for 3 seconds	Power On	Blue light goes on for 1 second
Pairing success	N/A	Your device is connected	Blue light goes on constantly
Turn off the earphone	Press and hold the On/Off button for 3 seconds	Power Off	Red light goes on for 1 second
Disconnect Bluetooth connection	N/A	Your device is disconnected	N/A

OPERATIONAL GUIDANCE

Function	Button	Audio	LED
Phone call in progress	N/A	N/A	N/A
Redialling (last call)	Press the On/Off button twice	N/A	N/A
Incoming call	Press the On/Off button once	N/A	N/A
Refuse incoming call	Press and hold the On/Off button for 2 seconds	N/A	N/A
End a call	Press the On/Off button once	N/A	N/A

OPERATIONAL GUIDANCE

Function	Button	Audio	LED
Play / pause	Press the On/Off button once	N/A	N/A
Listening music	N/A	N/A	Blue light flashing once every 5 seconds
Increase volume	Press "*" button repeatedly	with maximum volume alert	with maximum volume alert
Decrease volume	Press "-" button repeatedly	N/A	N/A

OPERATIONAL GUIDANCE

Function	Button	Audio	LED
Previous song	Press and hold the "-" button for 1 second	N/A	N/A
Next song	Press and hold the "+" button for 1 second	N/A	N/A
Battery level is low	N/A	Battery Low	Red light flashing once every 5 seconds
Battery charging mode	N/A	N/A	Red light goes on constantly
Battery has been fully charged	N/A	N/A	Blue light goes on constantly

OPERATIONAL GUIDANCE




JOIN THE COMMUNITY

SIGN UP to receive
· Special Offers!
· Access to Events!
· Contests!
· News on new products launched



www.muveacoustics.com/community



摺法示意圖