

BTSP03
Bluetooth Speaker

Content


1. Notes
2. Product packing content
3. Features
4. Buttons & Slots
5. Power on/off
6. Pair to other Bluetooth devices
7. Charging mode
8. FAQ
9. Warranty Card

Notes


- Please use and store this product at room temperature
- Do not expose this product to rain or wet conditions
- Do not throw and drop this product to avoid product damage
- Do not self-dismantling, repair and transform the product
- Do not use chemical solvent cleaning the product
- Please don't arbitrarily discarded or placed the lithium battery in the fire in order to avoid the risk of explosion
- Long time high volume may cause hearing impairment, please adjust the volume appropriately when listening, especially for long time listening.

- ① Note: Improper battery replacement may cause explosion, only replace with same or equivalent battery
- ② Don't expose the battery to sunlight, fire or excessive heat

Packing content




1 Speaker unit: 1pc



2 USB charging /data cable 1pc



3 Rope: 1Pc



4 User manual/Warranty card 1pc

Features

- Playback music via Bluetooth connection
- Support Bluetooth one button reconnection
- Support mp3, WMA, WAV format audio files playback
- Support TWS

Parameters


Appearance	
External interfaces	Micro USB interface
Product size	W80×D80×H37 (mm)
Speaker net Weight	206g (Including battery inside)
Basic parameters	
Product type	Portable Bluetooth speaker
Speaker driver	Inside magnetic trumpet
Volume control mode	Buttons
Bluetooth Version	Bluetooth 4.2+EDR
Power supply	Built-in 800mAh rechargeable lithium battery

Technical parameters	
Output power	3W THD = 10%
Frequency response	100Hz-20KHz
USB specification	USB2.0, compatible with USB1.1
Charging time	DC5V=1A around 2 hours
Audio playing time	Around 6 hours at Mid-volume

Functions	
File format	MP3, WMA, WAV
Micro SD card playback	Support
Bluetooth playback	Support
Card reader	Support
Bluetooth Reconnection	Bluetooth one button reconnection

Buttons & Slots


Buttons Instruction
Previous /Vol- : Short press to previous song, press and hold to decrease the volume.



Next/Vol+ : Press to next song, press and hold to increase the volume.

Power key:
Press and hold 2 seconds to power on /off
Short press to switch the mode when the speaker is powered on.

Pause /Play:
Short press : Pause/play. Press and hold to disconnect the Bluetooth device when the Bluetooth paired , short press to reconnect the Bluetooth device when the Bluetooth disconnected.



Reset hole :
If the speaker halted, press this hole with steel sticker to restart the speaker.

USB Slot :
Charging

Power on /off

1 Press and hold 2 seconds to power on /off

Press and hold 2 seconds to power on voice prompt ring , white LED light up and flashing, the speaker is on ,press and hold 2 seconds to power off voice prompt ring, the white LED light goes out, the speaker is off.

Pair to other Bluetooth devices

1 Bluetooth connect

Turn on the Bluetooth function of other Bluetooth devices , and start to scan the speaker , when "HEYDAY SPEAKER 03" appears in the list , press to connect.

2 Bluetooth connected and playback

After connecting successfully , the beeps up, LED light continuous white , you can select music from the Bluetooth devices and play, the LED light continuous white when the speaker playback.

1.If necessary , please input "0000" and press to pair.

2.The speaker can reconnect the last paired device(if this device's Bluetooth is on) when power on , no need to scan and pair again.


3 Disconnet Bluetooth device

If the speaker connected the device , press and hold [] to disconnect the Bluetooth , and then the speaker is discoverable for Bluetooth scanning , the white LED light flashing fast , disconnecting beeps up.

4 Bluetooth device reconnect

If the Bluetooth device disconnected , and need to reconnect , you just need to short press [] to reconnect the last connected playback device , and play the recent files ,the LED light continuous white, the LED light slowly flash when pause.

Charging mode



2 Speaker charging

Charging the speaker by using the data cable which includes in accessory to connect computer. Also can use USB adapter (over DC 5V=1A) to charge the speaker. The LED light continuous red when charging, the red LED light goes out when charging completed.

Kind reminder :

If no use the speaker for a long time, please charge it first .

The speaker will power off in 10 minutes automatically, if no Bluetooth connection, no TWS playback pause.

FAQ

Problems	Settlement
Failed to connect many times	1.Restart the speaker 2.If needed, please input passcode "0000"
discontinuities appears when playback	1.check if the Bluetooth device is out of the valid distance, or there is block between speaker and Bluetooth devices .
No sound when play	1.Check the speaker's volume 2.Check if the speaker is on mute or pause
Can not power on	1.Please reset the speaker by pressing the reset hole

Warranty Card

Please fill up this "warranty card" after purchasing this product

Date of purchase: _____

Name: _____

Address: _____

Telephone: _____

Authorized dealer stamp: _____

Dealer address: _____

Dealer: _____

Phone: _____

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID:2AO23-BTSP03