

USER MANUAL

Inspur Software Group Ltd
No. 2877 Kehang Rd., Jinan, Shandong, 250104, P.R. China
Tel: (+86) 4008122330
Fax: (+86) 0531-85105300
[http: //www.inspur.com](http://www.inspur.com)

Contents

1. Introduction	3
Safety Precautions	3
2. Appearance	5
3. Connection.....	6
Direct connection with TV	6
Connection with TV via HDMI cable	6
4. Remote Controller	7
Key Function	7
Notes	7
Pairing.....	7
5. Operation Instructions.....	9
Contents in the box	9
Specifications.....	9
Network Connecion.....	9
6. Troubleshooting	9
7. Third party software declaration.....	10
8. Special Notes	11

1.Introduction

Dear Subscriber,

Thank you for purchasing the product from Inspur Software Group Ltd.

The information provided are for guidance only, the company reserves the right to change the specs without notice.

Please read this manual carefully before using this product.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

Safety Precautions

- 1 Only place the device on stable surfaces, and ensure the device ventilation and avoid direct sunlight.
- 2 When installing this unit, make sure to leave space around the unit (at least 10cm at top, 10cm at rear and each side).
- 3 Do not disassemble the device without permission in case of any device failure, Please contact call center when you find any problems.
- 4 Keep the device away from electrical appliances with strong electric or magnetic fields while installation, such as microwave oven, refrigerator and mobile phones.
- 5 Do not install the device on a flammable object, such as foam material, etc.
- 6 Do not put the device close to flame, such as lighted candles, electric heater in operation, etc.
- 7 Do not expose the device to water dripping or splashing environment, and never place something filled with liquid on it, such as vases, etc.
- 8 Keep power plug clean and dry, and never use damaged power wire.
- 9 Do not place any object on the power plug or power wire, to ensure that the power plug can be easily plugged out.
- 10 Only use a water-dampened soft-cloth to clean the surface of this product.
- 11 Keep hands dry when plugging in and plugging out connection cables.
- 12 To avoid visual impairment, do not look directly at IR (Infrared Radiation) of the remote controller.
- 13 Do not allow children to use the device or play with small accessories without watching,
- 14 Please use the device at temperature from -10°C to 40°C.

- 15 Applies to areas below the altitude of 5000 only.
- 16 Applies to tropical climates.
- 17 Please disconnect power and unplug power wire in the following conditions:
 - Liquid flowing inside the case accidentally,
 - Abnormal situations such as smoking, peculiar smell, abnormal sound, etc.
 - Before cleaning the device,
 - During thunderstorm or lightning weather,
 - When the unit is unused for long periods of time.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

2.Appearance




3.Connection

Direct connection with TV




Connection with TV via HDMI cable



4. Remote Controller

Key Function

1. [red] Power on/Standby
2. [▲] Next channel; move up in the list
3. [◀] Decrease volume; move left in the list.
4. [OK] Display current program list or to select setting
5. [▶] Increase volume; move right in the list.
6. [▼] Previous channel; move down in the list.
7. 【🏠】 Enter the main launcher
8. 【↶】 Back to the last menu
9. 【☰】 Enter the menu
- 10.【-VOL】Decrease the volume of TV
- 11.【VOL+】Increase the volume of TV
12. 【🎤】 Voice control




Notes


The remote controller has paired with the device via Bluetooth, you can use the remote controller to control the HDMI Dongle directly. If the remote controller is lost or broken and other cases that you need to replace it, please pair the remote controller with the device again.

Pairing


1. Press the “🏠” and “☰” key for 5 seconds until the red light flashes, the flashing state means “pairing”.
2. The device will detect the nearby remote controller, and once the Bluetooth is detected, it will remind you whether or not to connect to the new Bluetooth remote controller.



3. When indicating the reminder, the device will pair with the new Bluetooth remote controller automatically if no operation occurs within ten seconds.



4. After indicating “connect succeed”, the Bluetooth RC can be used normally.



5. Operation Instructions

When you use the device for the first time, please follow the steps below.

Contents in the box

Once you open the box, you will find the following items:

NO.	DEVICE
1	HDMI DONGLE
2	RC
3	User Manual
4	Power adapter

Specifications

Adapter Output Voltage	DC,5V/2A
Working Temperature	-10 ~ 40°C
Operational Humidity	5%-90% (RH)

Network Connection

The HDMI dongle must connect to an existing WiFi network. If you have a wireless network, enter the settings, select the wireless network, and press the OK key, enable wireless mode, then select your WiFi, enter the password and click the link button to connect to the network.

As long as the network was connected, press the home button to enter the client, you can enjoy the rich video.

6. Troubleshooting

1. No image, no sound

- The power adapter is not connected well, please reconnect.
- The TV is not switched to the correct source, please switch to the correct HDMI source

- The HDMI cable is connected incorrectly, please reconnect.
2. Only sound, no image
 - The HDMI cable is connected incorrectly, please reconnect.
 - The brightness of the TV or HDMI Dongle is adjusted to the minimum, please adjust the brightness.
 3. Only image, no sound
 - The TV or HDMI Dongle has been set into the mute mode, please press the **【mute】** button to turn on the sound.
 - The sound of the TV or HDMI Dongle is adjusted to the minimum, please adjust the volume.
 4. The image is paused or indicate “buffering”
 - The signal quality of wireless network is poor, please connect to the network with better quality.
 - The server is adjusting the program source.
 5. Indicates that the network can not be connected
 - The wireless network is blocked, please check the network connection.
 - The device is not authorized, please contact your network operator.
 6. The remote controller is insensitive
 - The battery inside the remote controller is not enough or the battery is not installed properly. Replace the battery or install the battery properly.
 - There is an obstacle between the remote controller and the HDMI Dongle, please avoid the obstacle.
 - The remote controller is out of the effective range of receipt, please use the remote controller within the effective range.
 - There are other interference signals, please try to avoid interference of other signals when controlling the device.
 - Ensure that the remote controller has been paired successfully with the HDMI Dongle.

7. Third party software declaration

These third party software and applications provided via this product are owned by all third parties, our company does not provide any guarantee for these third party software and applications as we do not own the intellectual property rights of them. Our company will not provide support to these software and applications, nor assume any responsibility for the functionality of these software and applications.

Third party software and application services may be interrupted or terminated. Our company does not guarantee that any content or service can be maintained its availability during any time. The third party transmits content or services through the network and transmission tools which are out of our control scope. Within the bounds of the relevant law, our company has made it clear that we will not assume any responsibility for the interruption or termination of any content or service provided by this product. Our company does not assume any

responsibility for any legality, quality, and any other aspects of any software, images, videos or software and other third party works that you have personally installed on this product. You are solely responsible for any consequences arising from your installation of the Software or uploading, downloading any of the foregoing third party works, including installing software which is not compatible with this product.

8.Special Notes

1. All designs in the manual are only used to describe the operation, not as the basis for testing the product.
2. The designs in the manual may be different from the product, please subject to the actual sales.
3. Our company reserves the right to change the performance of the product without notice.
4. Please use our standard accessories and accessories to avoid damage to the device.