LANDSHARK.



KEEPING IT CHILLED BLUETOOTH[®] LIGHT UP SPEAKER

BC

 \mathbf{x}

User's Manual

FOR ITEM: MA105-LSK

IMPORTANT SAFETY PRECAUTIONS

When using your Keeping It Chilled Bluetooth Light Up Speaker, basic safety precautions should always be followed, including the following:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR SPEAKER.

2. Clean using a soft cloth or paper towel.

3. Do not allow children or the infirm to play with your speaker without adult supervision.

4. Do not expose your speaker to excessive heat, flames or fire.

5. Always press all buttons or switches carefully. Do not manhandle your speaker.

6. Do not use in extremely dry environments, as this can lead to static discharge during usage.

7. Do not expose your speaker to temperatures above 40°C.

8. Do not attempt to repair this product yourself. Contact a qualified service center if your speaker is in need of service.

9. Do not drop, puncture or expose your speaker to excessive trauma.

10. Your speaker is not intended for commercial use.

11. Do not place near objects that generate a strong magnetic field.

12. Unplug this device when not in use for long periods of time or during lightning storms.

	BATTERY WARNING: -The device is equipped with an integrated lithium ion battery. The battery cannot be replaced. Do not attempt to remove the battery from the device. -Do not dispose of in fire or expose to excessive heat. -Do not crush, puncture, incinerate, or short circuit external contacts. -Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for further information.
--	---

INTRODUCTION

Thank you for purchasing the LandShark Keeping It Chilled Bluetooth Light Up Speaker, item MA105-LSK. You can use your speaker with most smartphones and Bluetooth devices to stream music wirelessly. In addition, your speaker is perfect for use at the beach or by the bar, as the attached ice bucket can hold ice, cans and bottles. In order to get the best results when using this device, please read this manual first before using.

PACKAGE CONTENTS

-LandShark Keeping It Chilled Bluetooth Light Up Speaker, item MA105-LSK.


- -USB Charging Cable
- -User's Manual with Warranty Information

SPECIFICATIONS


Bluetooth Specification: V4.2 (Only support EDR,BDR modes.EDR(&DPSK) and BLE mode has been shielding by Software.) Bluetooth Range: Up to 33 feet (10 meters) Power Supply: DC 5V, (USB) Battery Type: Lithium Ion Battery Charge Time: Approximately 3-4hours Play Time: Approximately 4hours at 80% volume Dimensions: 24.8x 23.5 x 29.2cm

*Applicable at 50% of maximum volume. Results will be lower when volume is higher.

A QUICK LOOK AT YOUR DEVICE



CHARGING YOUR SPEAKER



--A charged battery will lose its capacity if it is not used on a regular basis.

--Make sure the rubber charging port cover is securely closed once charging is complete and before use.


Important: To avoid a complete discharge of the battery, charge your speaker at least once every six months.

4. The LED Indicator Light turns red while the speaker is charging then turns off once charging is complete.


(red) = Charging

○(off) = Charging Complete

BLUETOOTH PAIRING




1. Press and hold the Power Button to power on your speaker.



2. The LED Indicator Light will turn blue and flash rapidly to indicate that your speaker is in pairing mode.




3. Go to the Bluetooth settings menu on your phone. Make sure that Bluetooth is turned on. Connect to the device listed as "MA105."



 The LED Indicator Light will remain blue and flash slowly to indicate that your speaker is paired with your phone.


USING YOUR SPEAKER



 To power on or power off your speaker, press and hold the Power button. If you have already paired your speaker to your Bluetooth device, they will automatically remain paired each time you power on your speaker.



You can adjust volume and playback settings on your phone or connected audio device. You can also tap the Power button to play or pause music.



3. Your speaker emits soothing ambient lights. Quickly tap the Power button twice in order to change the color of these lights and the pace in which they flash.



4. The ice bucket can be unscrewed from the rest of your speaker. Your speaker is splashproof, but should not be submerged in water or used in extremely wet environments

MAINTENANCE AND CARE

-Before using your speaker, inspect the ports to make sure that they are clear of dust and debris before charging.

-Use a soft cloth to clean your speaker. Never use any harsh chemicals or detergents. Make sure your speaker is dry before charging.

-When your speaker is not in use, it should be stored in a cool, dry place.

-Never tug or yank on the USB charging cable while it is connected to your speaker. Connect and disconnect cables as carefully as possible.

-Never expose your speaker to high temperatures, or extreme cold.

-Please recycle or dispose of your speaker properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your speaker for further information.



FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.