

SACKit®

WOOFit Go

BLUETOOTH SPEAKER



Bluetooth speaker



Water repellent



Rechargeable



Changeable front



Stereo pairing



Hands-free calling

Quick start guide

1. Oplad højttaleren i minimum 2 timer
2. Tænd højttaleren på Power knappen
3. Tænd for Bluetooth på den enhed, som du vil forbinde til højttaleren
4. Vælg "WOOFit Go" i Bluetooth-indstillingerne på din enhed
5. Start afspilning af musik fra din enhed
6. Nyd musikken og dans

Forbind to WOOFit Go højttalere

Hvis du har to WOOFit Go højttalere kan du forbinde dem som stereopar på følgende måde:

1. Tænd begge højttalere på Power knappen
2. Tryk tre gange på Power knappen for at få WOOFit Go i pairing mode (indikationslyset blinker grønt ved korrekt pairing mode). Dette skal du gøre på begge højttalere
3. Højttalerne forbindes i løbet af få sekunder. Indikationslyset lyser grønt ved korrekt forbindelse.

Brugermanual

Læs brugsanvisningen før du tager produktet i brug. Hent brugermanual online på følgende link:

sackit.dk/support

Her kan du downloade brugermanualen og gemme den til senere brug. I brugermanualen finder du instruktioner og vigtige sikkerhedsoplysninger.

Quick start guide

1. Lad opp høyttaleren i minimum 2 timer
2. Slå på høyttaleren med Power knappen
3. Slå på Bluetooth på den enheten, som du vil koble høyttaleren til
4. Velg "WOOFit Go" i Bluetooth-innstillingene på din enheten din
5. Spill av musikk fra enheten din
6. Nyt musikken og dans

Koble to WOOFit Go høyttalere sammen

Hvis du har to WOOFit Go høyttalere kan du koble dem sammen som stereopar på følgende måte:

1. Slå på begge høyttalere med Power knappen
2. Trykk tre ganger på Power knappen for å få WOOFit Go i pairing mode (inndikasjonsslyset blinker grønt ved korrekt pairing mode). Dette skal du gjøre på begge høyttalere
3. Høyttalerne kobles sammen i løpet av få sekunder. Indikasjonsslyset lyser grønt ved korrekt kobling

Brukermanual

Les instruksjonene før du bruker dette produktet. Last ned bruksanvisningen på følgende link:

sackit.no/support

Her kan du laste ned bruksanvisningen og oppbevare den for senere bruk. I bruksanvisningen finner du instruksjoner og viktig sikkerhetsinformasjon.

Quick Start Guide

1. Charge the speaker for at least 2 hours
2. Turn on the speaker using the Power Button
3. Turn on Bluetooth on the device you want to connect to the speaker
4. Choose "WOOFit Go" in the Bluetooth settings on your device
5. Start playing music from your device
6. Nod your head and dance

Connect two WOOFit Go speakers

If you have two WOOFit Go speakers it is possible to create a stereo pair:

1. Power on both speakers
2. Click the Power button three times to enter pairing mode (the indication light will flash green in correct pairing mode). Repeat this for both speakers
3. The speakers will connect in a few seconds. A green light indicates correct connection.

User manual

Read the user manual thoroughly before using the product.

Download user manual online at:

sackit.eu/support

Please download the user manual and save it for future use. In the user manual, you will find instructions and important safety information.

Quick start guide

1. Es dauert min 2 Stunden bis die Lautsprecher vollständig aufgeladen sind
2. Drücken Sie den Power Button
3. Paaren Sie das gewünschte Gerät mit Ihrem Lautsprecher, indem Sie die Bluetooth-Empfangsbereitschaft aktivieren
4. Wählen Sie "WOOFit Go" in Ihrem Display
5. Starten Sie die Musik
6. Jetzt können Sie Ihre Lieblingsmusik genießen

Zwei Lautsprecher verbinden

Bei zwei „WOOFit GO“ Lautsprecher, haben Sie die Möglichkeit diese zu verbinden:

1. Beide Power Button drücken
2. Drücken Sie 3 Mal auf den Power Button um den Paarungsmodus zu aktivieren (Bei korrekter Paarung erscheint eine grüne Leuchtanzeige). Entsprechend muss dieses, auf beiden Lautsprechern ausgeführt werden
3. Die Lautsprecher werden innerhalb weniger Sekunden miteinander verbunden. Bei einer korrekten Verbindung erscheint eine grüne Leuchtanzeige

Bedienungsanleitung

Lesen Sie bitte diese Bedienungsanleitung vor Gebrauch sorgfältig durch. Laden Sie die Bedienungsanleitung unter folgendem Link herunter:

sackitshop.de/support

Hier können Sie die Bedienungsanleitung herunterladen und für späteren Gebrauch aufbewahren. In der Bedienungsanleitung finden Sie technische Beschreibungen und wichtige Sicherheitshinweise.

Technical specifications

- 3,7V rechargeable Li-Ion battery with 950mAh
- Battery life: 5 hours at maximum volume, 9,5 hours at 50% volume
- Charging via included micro USB cable
- Bluetooth version 5.0
- Output power: 1x3W
- Frequency bands: 2402-2480MHz
- Power transmitted: Maximum 10dBm
- Operating temperature range: 0-35 ° C/32-95 ° F
- LED indicator
- Stylish Danish design. Measurements: 105x91 x 45mm
- Weight: 225g

Hereby, SACKit ApS declares that the radio equipment type WOOFit Go is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <http://SACKit.eu/support>.

Safety information

- A. Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type
- B. batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like

To prevent overheating, please do not install the speaker in enclosed spaces. Be sure to set aside at least 10cm around the product for ventilation. The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains, etc.

Do not place this device in or close to sources of excessive heat or fire. (Such as: candles, fireplaces or direct sunlight)

This product contains a battery. The product cannot be discarded as general living garbage. Please understand the local classification about collecting the provisions of battery. The correct disposal of the battery helps to avoid the potentially negative impact on the environment and human health.



This symbol, affixed to the product or its packaging, indicates that the product must not be processed with household waste. It must be brought to an electric and electronic waste collection point for recycling and disposal. By ensuring the appropriate disposal of this product you also help in preventing potentially negative consequences for the environment and human health. The recycling of materials helps preserve our natural resources. For further information regarding the recycling of this product, please contact your municipality, local waste disposal centre or the store where the product was purchased.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.