

User Manual Bluetooth Speaker Model: BW-A51. Includes QR code, logo, and dimensions (80mm).

Accessories: Cable for charging, USB, 3.5 Audio Cable, User manual. Mise sous tension: Appuyer brièvement sur le bouton d'alimentation pendant 5 secondes pour allumer l'émetteur Bluetooth.

Bluetooth Geräte Speicher: Der BW-A51 kann nicht automatisch mit dem Bluetooth-Gerät verbinden. Technische Daten: Bluetooth Spezifikation Bluetooth 4.2 A2DP, HFP, AVRCP.

Risoluzione dei problemi: Se il collegamento al dispositivo fallisce. Per la tua salute: Evitare la luce diretta del sole o un lungo periodo con l'altoparlante in un ambiente caldo.

アクセサリ: Bluetooth BW-A51 充電ケーブル、USBケーブル、3.5オーディオケーブル。電源を入れる: 電源ボタンを3秒長押しするとBW-A51が電源が入ります。

1 2. Accessories: Bluetooth A2DP, AVRCP, HFP, AVRCP. Powering On: Long press the power button for 3 seconds to turn on the BW-A51.

Mémoire de l'Appareil Bluetooth: Écoutez de la musique à un niveau de volume élevé pendant que l'appareil Bluetooth est allumé. Caractéristiques: Spécification Bluetooth Bluetooth 4.2 A2DP, HFP, AVRCP.

Störungsuche: Wenn nicht mit Gerät paaren kann. Gesundheit-Warnung: Meist auf einen hohen Niveau bringe Zeit hören sind Ihre Trommelfelle überlastet.

Accessori: Cavo USB per ricarica, Cavo USB in 3.5 Conn. Audio. Encendido: Pulsar el botón de encendido durante 3 segundos para encender / apagar el emisor Bluetooth.

Bluetoothデバイスメモリー: Bluetoothデバイスに自動的に再接続できます。仕様: Bluetooth仕様 Bluetooth 4.2 A2DP, HFP, AVRCP.

Bluetooth Device Memory: The BW-A51 can automatically reconnect to the last Bluetooth device it was paired to. Specifications: Bluetooth Specification Bluetooth 4.2 A2DP, HFP, AVRCP.

Dépannage: Écoutez de la musique à un niveau de volume élevé pendant que l'appareil Bluetooth est allumé. Avertissement de santé: Ne laissez pas l'altoparlant fonctionner à un volume élevé pendant de longues périodes.

Accessori: Cavo USB per ricarica, Cavo USB in 3.5 Conn. Audio. Accensione: Premere il tasto di accensione per 3 secondi per accendere / spegnere il diffusore Bluetooth.

Memoria del dispositivo Bluetooth: El BW-A51 puede volver a conectarse automáticamente al último dispositivo Bluetooth con el que se emparejó. Apagado automático: Si se ha dejado el dispositivo conectado, el altavoz se apagará automáticamente después de 5 minutos.

トラブルシューティング: Bluetoothが再接続できません。健康に関する警告: Bluetoothスピーカーを長時間にわたって高い音量で再生すると、耳の聴覚機能が低下する可能性があります。

Troubleshooting: Unable to pair to device. 1. Check the volume settings of the paired mobile device. 2. The battery may be low, please recharge the speaker.

Zubehör: Bluetooth BW-A51 充電ケーブル、USBケーブル、3.5オーディオケーブル。Einschalten: Zum Ein-/Ausstellen die BW-A51 der Power-Taste für 3 Sekunden lang drücken.

Memoria di Dispositivo Collegato: Il BW-A51 può ricollegarsi automaticamente all'ultimo dispositivo Bluetooth a cui è stato collegato prima. Specifiche: Specifica di Bluetooth Bluetooth 4.2 A2DP, HFP, AVRCP.

Solución de problemas: No se puede conectar al dispositivo. Advertencia de salud: Evitar la luz directa del sol o un largo periodo con el altavoz en un ambiente caliente.

健康に関する警告: Bluetoothスピーカーを長時間にわたって高い音量で再生すると、耳の聴覚機能が低下する可能性があります。安全上の注意: Bluetoothスピーカーを直射日光や高温の環境に長時間さらすことは避けてください。

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.