



Overseer • Instruction Manual

Product Example Front View of Camera



- 1 -

Product Example Rear View of Camera



- 2 -

Installation Steps

1. Use the screw sets to mount the camera to the stand, you can then install the stand to the wall or ceiling or other desirable locations.



2. The Overseer can also be placed directly on the ground.
3. Connect the power cords.
4. The status indicator light should be showing a stable red light. This would mean the overseer is powered on correctly. You can then start the process of connecting it to the internet through your mobile App.

- 3 -

Set Up Internet Connection


1. Search for the "Alcidae" App in Google Play or App Store or scan the QR Code below.



2. Register and log into account.
3. Ensure that your mobile phone is connected to the 2.4 GHz Wi-Fi network that you wish to set up the device on.

- 4 -


4. When the status indicator light is showing a stable red, hit on the plus button and input your Wi-Fi credentials to connect device to the internet.



5. Wait for the status indicator light to start from slowly blinking blue to rapid blinking blue.

- 5 -

6. When the device name shows up on the device list, hit "Add" to add the device.



7. Input the device name that you wish to use for identifying the device.

Reset Internet Connection

After changing the device internet environment, press on the reset button for six seconds until the device sounds "reset success". Follow the same procedure as setting up internet connection to proceed with placing the new Wi-Fi settings.

- 6 -

Implication of Status Indicator Light

Step1 Stable Red means the device is powered up and activating.



Step2 Blinking Red per second means the device is waiting for internet connection.



Step3 Blinking Blue per second means the device is connecting with your internet router.



Step4 Blinking Blue per 0.25 seconds means the device is connected to the internet and connecting with our cloud service platform.



Step5 Stable Blue means the device is connected to the internet and our platform and ready for providing service.



- 7 -

Product Introduction

Packing List:

- Overseer x1
- Stand x1
- Adaptor x1
- Charging Cable x1
- Instruction Manual x1
- Screw Sets x1

Technical Specifications

Product Name: Alcidae Overseer
 Product Model: H1
 Power Input: 5V/1A
 Resolution: HD 1080P
 Camera Angle: 150°
 SD Card Support: Max Support 64G
 Cloud Service: Global Coverage
 Working Power: 5W/Max
 Working Temperature: 0° - 40° C
 Working Humidity: <90%
 Wi-Fi Standard: 802.11 b/g/n

- 8 -

Warranty Card

Customer Information (Please be sure to provide accurate and true information for us to fulfil promised purchase warranty)

Name _____ Phone Number _____

Email _____ Zip Code _____

Contact Address _____

Product Information

Name _____ Model _____

Color _____ Model Serial Number _____

Required Service:

Return Replace Maintenance

Brief Description

Date _____ Request Received Personnel _____

- 9 -

Purchase Warranty

Alcidae Inc Warranty Policy

1. 7 days return period: Within 7 days of purchase if you encountered any issues with our product, you are eligible for a full refund or product replacement with valid purchase receipt.

2. 15 days return period: Within 15 days of purchase if you encountered any issues with our product, you are eligible for a product replacement with valid purchase receipt.

3. 12 months maintenance period: Within 12 months of purchase if you encountered any issues with our product, you are eligible for our product repair and maintenance service with valid purchase receipt.

- 10 -

Outside of Warranty Policy

Alcidae Inc Warranty Policy

1. Request without a valid warranty card and purchase receipt.
2. Outside of warranty time period.
3. Determined as malfunction or damage caused by user product misuse.
4. Damage or malfunction caused by force-majeure circumstances.
5. Damage of the device exterior.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause

- 11 -

harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
--Reorient or relocate the receiving antenna.
--Increase the separation between the equipment and receiver.
--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
--Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

- 12 -



Website: www.alcidae.com
 Email: support@alcidae.com
 Phone: 415-936-3628
 Facebook: www.facebook.com/alcidaein
 Store: www.alcidae.com/product/garager