













Charge Fast, Live More



Anker 333 Wireless Charger (3-in-1 Station)
QUICK START GUIDE



	Apple	iPhone 12 mini, iPhone 12, iPhone 12 Pro, iPhone 12 Pro Max, iPhone 11, iPhone 11 Pro, iPhone 11 Pro Max, iPhone XS, iPhone XS Max, iPhone XR, iPhone X, iPhone 8, iPhone 8 Plus, iPhone SE2 (7.5W fast charge)
	Samsung	S10, S10+, S10e, Note 10, Note 10+, S20, S20+, S21, Note 9, Note8, S9, S9+, S8, S8+ (10W fast charge)
	Google	Pixel 4, Pixel 4 XL (11W fast charge)
	Other devices	5W
	Apple	Airpods with wireless charging case
	Samsung	Galaxy Buds/Galaxy Buds Pro/Galaxy Buds+
	Apple	Apple Watch Series 1-6/Apple Watch SE

