

如何打开钥匙 查看产品标签 How to open the shell and show the Label location



包括：
its includes these parts



1. Front cover
2. Emergency key
3. battery
- 4 and 5. back cover

第一步：用手摁下钥匙顶端的PUSH 键，钥匙顶端的备用钥匙可以轻松拉出。

Step 1: press the push button on the top of the key, the Emergency key on the top can be pulled out easily.



第二步，用备用钥匙轻轻插入钥匙壳背面的顶端缝隙，稍微用力转动备用钥匙，就可以把这个遥控打开。

Step 2: use the emergency key Insert the top gap on the back of the key case and turn the emergency key slightly to turn on the remote control.



第三步，这样就打开了这个钥匙，很容易看到产品标签，这个钥匙不会经过超声波处理。

Step3: now the key was opened .and we can easy to see the label here. The key will not be processed by ultrasonic wave.

