
MANUAL FOR BLUETOOTH TABLE SPEAKER **MODEL NO.: BT-Z1**



Thank you for purchasing BT-Z1, the Table Speaker. In order to make the best use of this product and to use it safely, please read the instruction manual carefully and keep it for future reference

1.Power On/Off

A) Long press [POWER] button, you can hear the voice prompt "Power On" from speaker, the speaker will enter Bluetooth mode as default, and give voice prompt "Paring", then smart phone and other devices can be

B) Long press [POWER] button, the speaker will be turned off, you can hear the voice prompt "Power Off" from the speaker.

2.AUX Auto Switch

Inset AUX plug on the back panel, AUX mode will be switched on automatically, the green LED will light. The Bluetooth mode, and the blue LED will be switched off:

After take out AUX plug, the Bluetooth mode will be switched on automatically, then you can hear the voice prompt "Paring"

3.Bluetooth Connection and Play

A) When the speaker is in Bluetooth mode, it will automatically switch to Paring state, the blue LED light will slowly sparkle, the Bluetooth device name is "BT-71"

B) The speaker will pair with smart phone by Bluetooth technology, the speaker will give audio prompt "Connected" after pairing, the blue LED will always light. If failed, the blue LED light will sparkle slowly.

C) When playing music after connected with smart phone via Bluetooth technology, the speaker will pause if shortly press [Play/Pause/phone], it will play after shortly press [Play/Pause/phone] again.

D) When this speaker is connected with smart phone, long press the button [Play/Pause/phone], the speaker will switch off the connection with the pairing mobile phone, another smart phone can connect "BT-Z1" by Bluetooth technology. E) The distance between smart phone and speaker is ≥ 10m.

4.Call via Bluetooth

F) When a call comes in, the speaker will give audio prompt "Incoming call" if connected with Andriod smart phone. If connected with Iphone, it will give audio prompt" cell phone rings". shortly press the

[Play/Pause/phone] button to answer the phone, speak to the MIC, the other party can hear a clear call. Short press again to hang up, and long press to declined.

G) Double press [Play/Pause/phone] button to dialing the phone number of the last call in record

5. Voice Prompt:

A) POWER ON: Connect the power supply (voice prompt when the speaker turns on).

B) POWER OFF: Shut off the power supply (voice prompt when the speaker turns off).

C) Paring: Paring (enter Bluetooth mode from AUX, and back to Bluetooth mode)

D) Connected: pairing successfully, back to Bluetooth model and successfully pairing again. E) Disconnected Paring: the Bluetooth is disconnected (the phone

disconnect Bluetooth/ long press [Play/Pause/phone] to disconnect Bluetooth).

F) Incoming call: When a call comes in, the speaker will give audio prompt "Incoming call" if connected with Andriod smart phone. If connected with Iphone, it will give audio prompt" cell phone rings". G) Low Battery: Voice prompt of low battery

6. Volume Control

A) Press (+) button to increase the volume (30 levels in total, 20 levels by default when speaker turn on)

B) Press [-] button to decrease the volume (30 levels in total, 20 levels by default when speakers turn on)

7. Automatic Power Off

After Power on the speaker, if no Bluetooth connection, no LINE IN signal, or disconnect the Bluetooth after 10 minutes, the speaker will automatic power off, the speaker will give "POWER" OFF" voice prompt.

8.USB Charging

When the speaker is power on, or connect A/C adapter, the USB port 2.1A/1A can charge for Iphone and Android mobile phone at the same time; When the speaker turn off, the USB port can not charge for external devices.

2

9.Wireless charging (Optional)

The charging coil of the wireless charging devices (The mobile phone which can support Qi standard of wireless charging) need to aim at the wireless charging mark that in the middle of the table speaker, when the speaker power on or insert the adapter. You can hear the voice prompt "Di" after connected with the devices for wireless charging.


10.Low Battery prompt and Charging

A) When the battery capacity is low, the speaker automatically issues "Low Battery" voice prompt to remind the user that the speaker need to be charged; If the user does not charge, the speaker will be automatically


B) After connect A/C adapter to DC port, the red LED light will bright, the speaker start to charging, the red light will put out when fully charged.

Warning: Please use the original A/C adapter for charging, if not, it may caused charging slow or can not charging, when severe, A/C adapter will be burned out or other accident occurred!


DESCRIPTION OF PART



3



4



2.PIAY/PAUSE/PHONE 3.VOLUME-

5.MIC 6.LED

7.USB 2.1A / USB 1A 8.Charging LED


9.DC IŇ

4.VOLUME+

10.AUX

11.RESET

ASSEMBLE STEPS



1. Open the gift box, put the speaker on the table and the fixing hole

2. Take one from wooden tripod and match it with one fixing hole.

Rotate it clock 4. To fix the left two with the same procedure.

5. The wooden tripod is well fixed. 6. Put the speaker on the ground.

Warning:

1. The maxium bear weight of this product is 5kg, the consumers couldn't put any item more than 5kg on this product, otherwise, the consumers will bear the damage to this product by themselves.

2. This product couldn't be used as seat, no matter audult, or children, couldn't sit on this product, otherwise, the consumers will have to bear by themselves the damage to this product, and the damage to your health.

5

FCC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body