


INSTRUCTION MANUAL



	Functions
seconds	Turn speaker on
BT and AUX	Turn speaker off
	Enter or exit TWS mode
	Play or pause
I with the volume	Adjust volume
nds	Skip to next/previous track
	Answer or end the call
n for 2 seconds	Reject an incoming call
n in stand-by	Redial last-outgo- ing-called number
	Discount DY

3	Instructions	•
aker on	Press and hold the power button of both speakers for 2 seconds	P
aker off	Press and hold the power button of any speaker for 2 seconds	1.
exit TWS mode	Double-click the power button of the home speaker	3.
ause	Short-press the multi-function button of any of the two speakers	4.
lume	Short-press the volume + / - of any of the two speakers (synchronized with the volume of the iPhone, not Android)	N
ext/previous	Press and hold volume + / - of any of the two speakers	
r end the call	Short-press the multi-function button of the home speaker	١.
incoming call	Press and hold the multi-function button of the home speaker for 2 seconds	
st-outgo- d number	Double-click the multi-function button of the home speaker in stand-by	
ct BT	Press and hold the multi-function button of any of the two speakers for 2 seconds	

1-800-864-CLUB (2582) Mon-Fri 9AM - 5PM (PST)

WHERE THE PARTY BEGINS™

support@qfxusa.com Mon-Fri 9AM - 5PM (PST)