

# Wireless Stereo Speaker

NAME : Coke Wireless Stereo Speaker - Instruction

ITEM NO. : TRACoke03822

DATE : 7-24-2023

## Actual size

### Front

<p>QUICK START GUIDE WIRELESS STEREO SPEAKER</p> 	<p>QUICK START GUIDE WIRELESS STEREO SPEAKER</p> <p><b>⚡ Charge the speaker before using it for the first time.</b></p> <p><b>EASY PAIRING (first time pairing)</b> Make sure the speaker is turned on before attempting to pair it with a smart phone or tablet. Your speaker will automatically enter pairing mode. Blue LED indicator, will start flashing. The speaker will "beep" when it is ready to connect. From your smart phone or tablet, find a list of nearby devices and choose "Coke-Can Speaker". The blue indicator will turn solid blue when pairing is complete!</p> <p>Now you can play your favorite music.</p> <p><b>PAIRING YOUR SPEAKER</b> Your speaker will work best if it is within 30 ft. of your smart device. You may experience sound briefly cutting off if you are out of range or if your wireless connection is weak. Make sure wireless is enabled on your smart phone or tablet before starting the pairing process.</p>	<p>QUICK START GUIDE WIRELESS STEREO SPEAKER</p> <p><b>SPECIFICATIONS</b></p> <table border="0"> <tr><td>Wireless Version:</td><td>5.1</td></tr> <tr><td>Speaker:</td><td>3W</td></tr> <tr><td>Operation Range:</td><td>Up to 33ft (10m)</td></tr> <tr><td>Play Time:</td><td>Up to 3 hours</td></tr> <tr><td>Battery Capacity:</td><td>300mAh</td></tr> <tr><td>Frequency response:</td><td>100HZ-18KHZ</td></tr> <tr><td>Signal Noise Ratio:</td><td>≥85dB</td></tr> <tr><td>Charging Time:</td><td>Up to 2 Hours</td></tr> <tr><td>FCC ID:</td><td>2A00Y-24278</td></tr> </table> <p><b>WARNING</b> Keep away from water and moisture. Keep away from heat sources. Do not disassemble.</p>	Wireless Version:	5.1	Speaker:	3W	Operation Range:	Up to 33ft (10m)	Play Time:	Up to 3 hours	Battery Capacity:	300mAh	Frequency response:	100HZ-18KHZ	Signal Noise Ratio:	≥85dB	Charging Time:	Up to 2 Hours	FCC ID:	2A00Y-24278
Wireless Version:	5.1																			
Speaker:	3W																			
Operation Range:	Up to 33ft (10m)																			
Play Time:	Up to 3 hours																			
Battery Capacity:	300mAh																			
Frequency response:	100HZ-18KHZ																			
Signal Noise Ratio:	≥85dB																			
Charging Time:	Up to 2 Hours																			
FCC ID:	2A00Y-24278																			

### Back

<p>QUICK START GUIDE WIRELESS STEREO SPEAKER</p> <p><b>MEDIA KEY FUNCTIONS</b></p> <table border="0"> <tr><td>On/Off Switch</td><td>• Turn left to turn off • Turn right to turn on</td></tr> <tr><td>Next/Vol+</td><td>• Turn left - next track • Hold left - Volume up</td></tr> <tr><td>Prev/Vol-</td><td>• Turn right - previous track • Hold right - Volume down</td></tr> <tr><td>Play/Pause</td><td>• Press - to play/pause music • Press and hold - change to different reproduction modes</td></tr> </table> <p><b>USB Port</b> Listen to your music stored on a flash drive. Music will play once the flash drive is inserted into the USB port.</p> <p><b>Micro SD</b> Insert the TF card into TF slot. Music will play once the card is inserted.</p> <p><b>Auto Reconnect</b> If the speaker is off, while connected to the phone, it will reconnect when the speaker is turned back on and in range.</p> <p><b>AUX Mode</b> To play music in AUX mode, connect the USB cable (included) to the speaker. The speaker will function as a sound amplifier.</p> <p><b>Charging</b> Connect the USB cable (included) into the USB port on the speaker. Red light indicates speaker is charging. Once its fully charged, the light will turn off.</p>	On/Off Switch	• Turn left to turn off • Turn right to turn on	Next/Vol+	• Turn left - next track • Hold left - Volume up	Prev/Vol-	• Turn right - previous track • Hold right - Volume down	Play/Pause	• Press - to play/pause music • Press and hold - change to different reproduction modes	<p>QUICK START GUIDE WIRELESS STEREO SPEAKER</p> <p><b>FCC STATEMENT</b> This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p><b>FCC INSTRUCTIONS FOR A CLASS B DIGITAL DEVICE OR PERIPHERAL</b></p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the</p>	<p>QUICK START GUIDE WIRELESS STEREO SPEAKER</p> <p>instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> <li>• Reorient or relocate the receiving antenna.</li> <li>• Increase the separation between the equipment and receiver.</li> <li>• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</li> <li>• Consult the dealer or an experienced radio/TV technician for help.</li> </ul> <p>This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.</p>
On/Off Switch	• Turn left to turn off • Turn right to turn on									
Next/Vol+	• Turn left - next track • Hold left - Volume up									
Prev/Vol-	• Turn right - previous track • Hold right - Volume down									
Play/Pause	• Press - to play/pause music • Press and hold - change to different reproduction modes									

2.97"

8.38"

8.38"