

User Manual

FC (E ROHS E C)


Made in China


Overview


This is a slim and elegant wireless charging pad which allows you to freely charge your Qi-enabled devices.

Please read this manual before using the device to ensure safe and proper use.

Device layout








Applicable devices

- 1. Mobile devices that support standard wireless charging
- Mobile devices that support fast wireless charging
- 3. Mobile devices that require a wireless charging adapter

Using the wireless charger

Connect a charger to the wireless charger

When the charger(5V/2A, 9V/1.67A) is correctly connected to the wireless charger, the indicator light flashes red, blue and red and then off in 3 seconds.




Indicator light identification

The indicator light alerts you to the wireless charger's status.

Color	Status
Red->Blue->Red(off in 3 seconds)	When connected to a power outlet
Blue	When charging
Off(Blue)	When fully charged
Flashes red	When not charging properly due to a general error

2. Place a supported mobile device in the centre of the charging

Check the charging icon displayed on the mobile devices's screen for the charging status.



Package contents

Wireless charger Micro USB charging cable User manual

Specifications

Input: 9V/1.67A 5V/2A

Power: 10W

carrying out cleaning.

Attention:

Charging distance: 3mm-8mm Charging efficiency: ≥76% Dimensions: ⊄97mm*5mm

3.Use the wireless charger within 0-45℃.

interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

- 4.Use the included USB charging cable or your original charging cable.
- 5.It's normal to get your mobile device warm during charging.

1.Keep the wireless charger dry and away from water or any

2.Disconnect the wireless charger from power source before

- 1. A Quick Charge adapter must be used for fast wireless
- 2. It will charge better when you align your device to the sweet point of the wireless charger.
- 3. If your case is thick, remove it before placing your device on the wireless charger.

Warning:

Do not place foreign materials, such as metal objects, magnetic stripe cards, between the mobile device and the wireless charger. The mobile device may not charge properly or may be damaged due to overheating.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. Theselimits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment of and on, the user is encouraged to try to correct the interference by one or more of the following

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is

