

2. The earphones fail to connect with a previously paired Bluetooth device.

-Ensure the source device's Bluetooth is switched on; -Turn the Bluetooth feature off and then on. -Delete "Dual S6-1" from the Bluetooth list on your device and pair again.

3. Poor connection.

-Move your Bluetooth device closer to the earphones; -Try moving to a different area in case of any interference.

Care & Maintenance

1. To extend the lifetime of the battery, we recommend that you recharge your earphones at least once a month. 2.Please use the charger provided to charge the earphones. Use of other low-quality chargers may lead to issues. 3.Do not use any abrasive detergent to wipe or clean the earphones.

4.Keep the earphones within a range from 0°C - 45°C (32 °F to 113°F) all the time.

5.Avoid using the indicator close to the eyes of children or animals.

6.Never disassemble or modify your earphones for any reasons to avoid any issues.



Notice



This product is designed and manufactured with high quality materials and components, which This product is designed and manufactured with can be recycled and reused.



This symbol means the product must not be discarded as household waste and the transformer that the symbol means the symbol. discarded as household waste, and should be delivered to an appropriate collection facility for recycling.

Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.



NUTE: This equipment has been tested and found to comply all the limits for a class is by the device, provide the pert is of the LCDM is no. These limits for a set of the limit of the l

6