



User Manual



1. Button (ON / OFF)
2. Charge LED Indicator
3. Bluetooth LED Indicator (Blue)
4. - Button
5. + Button
6. pick-up Button
7. play/pause Button
8. MIC Hole
9. Micro USB socket (Under Rubber Seal Cover)
10. Vacuum Cupule
11. Speaker

Congratulations on your shower speaker! This item enables you to listen to all your favorite songs in the shower or any other place in great sound quality via Bluetooth!

About the rechargeable Battery & Charging

Regarding the lithium rechargeable battery this Bluetooth Speaker has an internal, non-user-replaceable battery. For best results, the first time you use this Bluetooth Speaker, let it charge for about 2 - 3 hours or until the "Charge LED (2)" Indicator light switches off.

To maintain the battery life and performance:

- Never fully deplete the battery
- Charge the item at least every 3 months even when not using the item

To recharge the built-in battery:

Connect the Bluetooth Speaker's "Micro USB socket (9)" with the Computer's USB through the USB cable. The "Charge LED (2)" Indicator will turn red, indicating that the battery is charging.

The "Charge LED (2)" Indicator will turn Off when the rechargeable battery is fully charged. Please disconnect the USB cable once the battery is full.

Switching on the device

- Press and hold the " (1)" button to switch On the device. A series of tones will sound from speaker. And the "Bluetooth LED (3)" indicator will blink blue rapidly.
- Next activate the Bluetooth function in your mobile device the device will go into Bluetooth searching mode automatically.
- Your mobile device should show "Laud Shower Cube" in the list, select it for pairing. Wait for a few seconds as the devices will connect with each other. In case you need to enter a code, enter 0000
- If pairing has been successful, a voice will announce from the speakers and the "Bluetooth LED (3)" indicator will start blinking each 3 - 4 seconds.
- You can now select the song on your device that you want to play.
- Press and hold the " (1)" button to turn Off the device when it is not in use.
- Note: the device will turn Off automatically in about 8 minutes if all Bluetooth connections are outside its reach.

Disconnect from paired device

- Press and hold the " (7)" button to switch to new "Searching / Pairing" mode, the paired device will disconnect.
- You can choose "Disconnect" from Bluetooth paired devices list on your mobile device.
- In this case: the Bluetooth Speaker will turn back into "Searching / Pairing" mode in seconds, a series of tones will sound and the "Bluetooth LED (3)" indicator will start blinking in Blue.
- Now you can search for new devices.

Auto re-connect with paired device and New pairing

- Every time you turn On the Bluetooth speaker power; it will firstly searching for the mobile device, which has been paired previously Laud Shower Cube and still in record. The Bluetooth Speaker will re-connect this mobile device as priority if it is in Bluetooth searching device mode.
- If not found in some seconds, the Bluetooth Speaker then is turn into new pairing mode internally.
- Now you can process for new mobile device pair.

Bluetooth Music Playing Control Function

- While playing music, press " (7)" button to pause the music. To resume the music press it again.
- Press and hold the " (5)" button to increases the volume level.
- Press and hold the " (4)" button to decrease the volume level.
- When maximum or minimum volume is reached, a series of tones will sound.
- Press the " (5)" button once to go to the next song.
- Press the " (4)" button once to go to previous song.

Hands Free Function

- When there is an incoming call while listening to music you can pick up the call with the speaker
- The ringing sound will announce.
- The music will pause automatically.
- Press " (6)" button to pick up the call.
- Now you have speak using the hands free function on the Bluetooth speaker.
- Press " (6)" button again to hang up the call when finished.
- The paused music will start to play automatically.
- Press and hold " (6)" button for 3 seconds to ignore the incoming call.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Important

- Do not place naked flames, such as lighted candles on or near the product.
- Do not place objects filled with liquids, such as vases on or near the product.
- Do not use or store this product in a place where it is subject to direct sunlight, heat, excessive dust or vibration.
- Do not keep or store this product in wet conditions for long period.
- Do not clean this product with water or other liquids.
- Do not block or cover the slots and holes in the product.
- Do not push foreign objects into the slots or holes in the product.
- Do not attempt to open this product yourself. There are no user serviceable parts inside.
- Do not allow children access to plastic bags. Safety instructions
- Before using this product, read and follow all warnings and instructions.
- This product is not intended for use by young children. Young children should be properly supervised.
- This product is intended for household use only and not for commercial or industrial use.
- Do not expose to dripping or splashing.
- No naked flame sources, such as lighted candles, should be placed on the product.
- Ventilation should not be impeded by covering ventilation openings with items such as newspapers, table cloths, curtains and the like.
- Make sure the unit is adjusted to a stable position. Damage caused by using this product in an unstable position or by failure to follow any other warning or precaution contained within this user manual will not be covered by warranty.

Warning

- Never remove the casing of this apparatus.
- Never place this apparatus on the other electrical equipment.

Note

- If at any time in the future you should need to dispose of this product please note that: All batteries and accumulators need to be removed from this product (Removal of Waste Batteries and Accumulators).
- Always bring your product to a professional to remove the built-in battery. Laud Shower Cube.