

Bluetooth Speaker

All-in-One Karaoke System with Bluetooth® and HiFi Playback



Instruction Manual
Please read this manual carefully before using the device.



Thank You

We hope you have many enjoyable days of listening to music. Thank you for choosing us for your entertainment needs. We are confident you will be satisfied with our products and services. We have a lot of new products in store and will be happy to help with your purchase. Please contact our customer support team for more information. We are here to help you with any questions. Thank you for choosing us for your entertainment needs.

In the Box

Assembly is simple and easy. You can assemble it in about 10 minutes. Follow the instructions in the manual and you will be ready to enjoy your new Bluetooth speaker. The package includes the following items:

- 1 x Bluetooth Speaker
- 1 x USB Cable
- 1 x AUX Cable
- 1 x Power Adapter
- 1 x User Manual



Connecting Power

The speaker has an integrated rechargeable battery. It can be used as a portable speaker or connected to a power source. Please read the instructions carefully before using the speaker. The battery is located on the bottom of the speaker. To connect the speaker to a power source, follow the steps below:

1. Turn on the power button.
2. Connect the power cable to the power source.
3. Connect the power cable to the speaker.

Using Bluetooth® Mode

The speaker can be used in Bluetooth mode. To connect to a Bluetooth device, follow the steps below:

1. Turn on the Bluetooth button.
2. Select the device to connect to.
3. Confirm the connection.

Pairing a Device with Bluetooth®

Bluetooth® is a wireless technology standard for exchanging data over short distances. To pair a device with the speaker, follow the steps below:

1. Turn on the Bluetooth button.
2. Select the device to connect to.
3. Confirm the connection.

Bluetooth® Speaker Controls

Function	Control
Power On/Off	Power Button
Volume Up/Down	Volume Buttons
Bluetooth On/Off	Bluetooth Button
AUX Input	AUX Button
USB Input	USB Button

Using USB Music Mode

The speaker can be used in USB Music Mode. To connect to a USB device, follow the steps below:

1. Turn on the USB button.
2. Connect the USB device to the speaker.

Using the AUX Input Connector

The speaker can be used in AUX mode. To connect to an AUX device, follow the steps below:

1. Turn on the AUX button.
2. Connect the AUX cable to the speaker.

Warnings and Precautions

Please read the following warnings and precautions carefully before using the speaker. Failure to follow these instructions may result in damage to the speaker or personal injury.

- Do not use the speaker near water.
- Do not touch the speaker when it is hot.
- Do not use the speaker near flammable materials.

Troubleshooting Guide

If you experience any issues with the speaker, please refer to the following troubleshooting guide for solutions.

Problem	Resolution
Speaker not working	Check power source and volume.
Bluetooth not connecting	Restart Bluetooth on both devices.
Low battery	Charge the battery.

Specifications

Model	BT-SPEAKER-001
Power	5W
Bluetooth Version	4.2
Frequency Response	20Hz - 20kHz

Support

If you have any questions or need assistance, please contact our customer support team. We are here to help you with any issues. Contact information is provided below.

Customer Support
Email: support@company.com
Phone: 1-800-123-4567