各个小面是60x86mm

172x180mm止囱

172x180mm背面





VIVITAR

Important Safety Precautions

When using your Vivitar Bluetooth Headphones, basic safety precautions should always be followed, including the following

- READ ALL INSTRUCTIONS BEFORE USING YOUR HEADPHONES.
 Do not use your headphones near water. Clean using a dry or slightly moist cloth.
 Do not lose your headphones near water. Clean using a dry or slightly moist cloth.
 Do not allow ohlidien or the infirm to play with your headphones without adult supervision.
 Do not expose your headphones to excessive heat, flames or fire.
 Always press all buttons or switches carefully Do not manihandle your headphones.
 Do not use in extremely dry environments, as this can lead to static discharge during usage.
 Do not expose your headphones to temperatures above 40°C. Keep out of direct sunlight.
 Do not attempt to repair this product yourself. Contact a qualified service center if your headphones are in need of service.
 Do not drop, puncture or expose your headphones to excessive traims.
 They our headphones are not intended for commercial use.
 Lynlight list device when not in use for long periods of time or during lightning storms.
 Do not place near objects that generate a strong magnetic field.







BATTERY WARNING: BAT LEKT WARNING:

The device is equipped with an integrated lithium ion battery. The battery cannot be replaced. Do not attempt to remove the battery from the deviceDo not dispose of in fire or expose to excessive heat.

Do not crush, puncture, incinerate, or short circuit external contacts. Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for further information.

Introduction

Thank you for purchasing your Vivitar Bluetooth Headphones, item SS69-BT-TA. You can use your headphones with most smartphones and Bluetooth devices to stream music and enjoy hands-free calling. In order to get the best results when using this device, please read this manual first before using.

Package Contents

FOR ITEMS: SS69-BT-TA/BT-69-BG/BT-69-GG/BT-69-W

-Vivitar SS69-BT-TA Bluetooth Headphones -Micro USB Charging Cable -User's Manual with Warranty Information


Specifications

Frequency Range: 20Hz-20KHz Bluetooth Range: Up to 33 Feet (10 Meters) Charging Input: DC 5V Battery Type: Lithium Polymer Battery Charge Time: Approximately 2 Hours

A Quick Look at Your Device



Charging Your Headphones





4. The LED indicator light turns red while the headphones are charging. It turns blue

1. The included USB charging cable has a Micro USB plug and a standard

(red) = Charging

(blue) = Charging Comple



2. Insert the USB charging cable's Micro USB plug into the charging port



Charging takes 1-2 hours. Unplug when

Important: To avoid a complete discharge of the battery, charge your


Pairing Your Headphones with a Bluetooth



Press and hold the power button to power on your headphones.



Go to the Bluetooth settings menu on your phone.
 Make sure that Bluetooth is turned on.
 Connect to the device listed as "SS69-BT-TA"



2. The LED indicator light will alternately flash red and blue to indicate that your headphones are in pairing me



4. The LED indicator lights will turn blue to indicate that your headphones are paired with your phone. Note that the light will blink slowly anytime music is playing

Using Your Headphones

- Powering Your Headphones On and OFF

 1. Press and hold the power button in order to power on your headphones. If you have paired your headphones to your Bluetooth device previously, they will automatically remain paired each time you power
- 2. Press and hold the power button in order to power off your headphones

 Play/Pause Button : Press to play or pause a track. NOTE: You can adjust volume and playback settings on your phone or connected audio device

vering a Call: Quickly press the Answer button to answer an incoming call

Ending a Call: Quickly press the Answer Call button to end a call.

To use your headphones with devices that are not Bluetooth enabled, plug one end of a standard 3.5mm audio cable into the Auxiliary Port on your headphones. Plug the other end into the

Maintenance and Care

-Before using your headphones, inspect the ports to make sure that they are clear of dust and debris before

-Use a soft cloth to clean your headphones. Never use any harsh chemicals or detergents. Make sure your

-When your headphones are not in use, they should be stored in a cool, dry place

-Never tug or yank on the charging cable while it is connected to your headphones. Connect and disconnect

-Never expose your headphones to high temperatures, extreme cold, high humidity or excessive moisture or

-Please recycle or dispose of your headphones properly based on the laws and rules of your municipality Contact local recycling facilities and/or the manufacturer of your headphones for further information.



FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more

- -- Increase the separation between the equipment and receiver
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is
- -- Consult the dealer or an experienced radio/TV technician for help.

Vivitar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period

What Is Not Covered by Warranty
Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering,

To Obtain Warranty Service and Troubleshooting Information Call 1-800-592-9541 in the U.S. or visit our website at www.vivitar.com.

o receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaired.

Vivitar One Year Warranty (continued)

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY, DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION -ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, OR SAKAR INT. BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRAN-TIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies. This product is manufactured, distributed and sold by SAKAR International, Inc. All other trademarks are the property of the respective owner, who has not sponsored, endorsed or approved this product.

VIVITAR