



METRO GO
Wireless Headphones



Instruction Manual

Please read this manual carefully before using the product

Contents

Introduction·	
2. Package Contents -----	2
Product Diagram -----	2
4. How to Use -----	3
4.1 General functions -----	3
4.2 Pairing to mobile phone -----	4
4.3 Charging your headphones ----	5
5. Product Specifications -----	6
6. FAQ -----	7

1. Introduction

Congratulations, and thank you for choosing the Metro Go Bluetooth Wireless Headphone. This manual will help you operate the Metro Go Bluetooth Wireless Headphone, but first you should familiarize yourself with the Bluetooth® functionality of your mobile phone, or other device, before using the Metro Go Bluetooth Wireless Headphone.

Safety Rules

1. Please follow the rules depicted in this manual closely to ensure your safety. Before using the product, we would strongly encourage you to read through the user manual.

2. Be wary of any edges, uneven surfaces, metal parts, accessories and its packaging to prevent any possible injury or damage.

3. Do not modify, repair, or dismantle the product. Doing so may result in fire, electric shock, or complete breakdown of the product. All of which are not covered under warranty.

4. Do not use any diluent or volatile liquid to clean the product.

5. Do not use the product in hazardous locations.

2. Package Contents

1 x Wireless Bluetooth

Headphones


1 x Micro USB Cable

1 x Instruction Manual



3. Product Diagram

- (1) Vol -/Previous Track
- (2) Multi-Function Button
- (3) Vol +/Next Track
- (4) Micro USB Charging Port
- (5) 3.5mm Jack



4. How to Use

4.1 General Functions

Desired Result	Required Action
Turn on & Enter the pairing mode	Press and hold the Multi-Function Button.
Pairing	Use a Bluetooth-enabled mobile phone or other Bluetooth-enabled device to perform necessary pairing actions.
Turn off	Press and hold the Multi-Function Button.
Charging	Plug the Micro USB plug into the micro USB charging port.
Answering a Call	Press the Multi-Function Button to answer phone calls, press again to end the call. Press twice to redial.
Play / Pause Music	Press the Multi-Function Button to play music and press it again to pause music.
Vol-/ Previous Track	Briefly press the “-” button to turn down the volume. Press and hold to go back to the previous song.
Vol+/ Next Track	Briefly press the “+” button to turn the volume up. Press and hold to move to the next song.

4.2. Pairing to a Mobile Phone

To use your Bluetooth® headphones, you must first pair your headphones with a phone. Once your Bluetooth® headphones are paired to mobile phone, they will remain paired and automatically recognize each other when within range.

Pairing to a Bluetooth® Enabled Mobile Phone

1. Turn on your phone and ensure the Bluetooth function is activated.
2. Press and hold the call key for 3 seconds. When the red and blue lights are flashing, you've entered into pairing mode.
3. Search for Bluetooth® devices on your phone by following the phone's instructions. (Refer to your phone's user manual for more information.)
4. After a few seconds, the phone will list "AGH-9002BT" as a discovered device. Select it and follow your phone's instructions to begin pairing.
5. Once successfully paired, the indicator light will flash blue.

4.3 Charging your Headphones

1. Use the Micro USB cable provided with these headphones.
2. Connect the Micro USB plug to the Micro USB charging port on the headphones.
3. Connect the USB plug to a USB port on a computer or wall adapter to activate charging.

NOTE: Be sure to charge the headphones for a full 3 hours prior to initial use.



Warning:

- You must select a qualified charger from a regular manufacturer.
- You must charge the Bluetooth headphones if it has not been used for more than 12 months.

5. Product Specifications

Driver Diameter	40mm
Frequency Range	20Hz-20KHz
Sensitivity	95dB +/-3 dB
Impedance	32ohms
Bluetooth [®] Version	5.0
Power Supply	Lithium Battery
Battery Capacity	200mAh
Receiver Distance	10m (max)
Charging Time	2 Hours
Playing Time	6 Hours

6. FAQ

1. Why is there no power even when the Headphones are turned on?

Answer: Ensure the battery has been charged for up to 2 hours before initial use.

2. There is no sound during playback.

Answer: Check the connection between the headphones and the phone or computer. If the connection is not established, please connect again. Make sure the headphones have been paired with your Bluetooth-enabled device.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.