


**dpnao<sup>®</sup>**

## **Wireless Smart Speaker**



**YW-011**

# IMPORTANT SAFETY INSTRUCTIONS

**These instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.**

1. The unit should not be used near water.
2. The unit should be situated so that its location or position does not interfere with its proper ventilation.
3. The unit should be situated away from heat sources.
4. The unit should be connected to a power supply only of the type described in the Operating instructions or as marked on the appliance.
5. This unit should be serviced by qualified service personnel when:
  - \* The power supply cord or plug has been damaged.
  - \* Objects have fallen into or liquid has been spilled into the enclosure.
  - \* The unit has been exposed to rain.
  - \* The unit has been dropped or the enclosure damaged.
  - \* The unit exhibits a marked change in performance or does not operate normally.
6. Do not use attachments not recommended by the product manufacturer.
7. Service methods not covered in the operating instructions should be referred to Qualified service personnel.




## **FCC Warning:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:- Reorient or relocate the receiving antenna.- Increase the separation between the equipment and receiver.- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.-Consult the dealer or an experienced radio/TV technician for help.NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## **FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.


# LOCATION OF CONTROLS



1	Mic mute Button	Press to talk with Alexa.
2	Volume Button	Adjust volume level
3	Mic Button	Press to mute Alexa
4	Light indicator	Light indicator
5	WPS Button	Connect to WIFI
6	DC-in Jack	DC connect

# QUICK SETUP GUIDE

1




1. Plug a power cord behind a wireless speaker. Then, Download "dnpao" app from mobile phone.

2




2. Follow APP instruction. Then, setup a network and access to Amazon account.

3



3. Press "WPS" button behind a wireless speaker during Wi-Fi setup connection.


4



When Wi-Fi is connecting, blue light will flash. Please wait 10-15 seconds to finish a connection.


4. After setup finished, a light will show blue color light at the top of wireless speaker.

5




Near field

For Near field: Press "🎤" button on wireless speaker. And talk to Alexa.















Far field



For Far field: Say "Alexa" and ask a question to wireless speaker.

## LIGHT INDICATOR

MIC mute					
Standby					
Listening					
Thinking					FLASH
Talking					FLASH
Exception					
Notification					

## HOW TO PLAY

### Near field:

1. Press "🎤" mic button. Then a light will show blue and hear a "do" sound.
2. Ask a question to wireless speaker. For example: "Alexa, What time is it?"
3. Wireless speaker will think your question, all light will flash.
4. After 1-3 seconds, a wireless speaker will answer. A purple light will flash.

### Far field:

1. Ask a question to wireless speaker. For example: "Alexa, What time is it?"
2. Then a light will show blue and hear a "do" sound.
3. Wireless speaker will think your question, all light will flash.
4. After 1-3 seconds, a wireless speaker will answer. A purple light will flash.

## SPECIFICATION

### POWER REQUIREMENT

Main Unit      AC - DC adaptor    Input: AC 120V ~ 60Hz  
Output: DC 12V 