




Follow us on Facebook

Note 15

Quick Guide

[EN]






Insert the cards

Slot 1: TF Card

Slot 2: Nano SIM

Slot 3: Nano SIM



Note:

- 1) Do not use a hand-cut card or wrong type card in case of card slot getting damaged.
- 2) Insert the card when the phone is power off.
- 3) TF card is up to 64GB.

Network Bands:

GSM: B2/3/5/8(1900/1800/850/900)

WCDMA: B1/2/5/8(2100/1900/850/900)

Face Unlock:

Setting>Face Unlock

Network Connection

WiFi: Setting>Network & Internet>WiFi

Hotspot:Setting>Network & Internet>

Hotspot&tethering




Legen Sie die Karten ein

Steckplatz 1: TF Karte

Steckplatz 2: Nano SIM

Steckplatz 3: Nano SIM



Hinweis:

- 1) Verwenden Sie keine handgeschnittenen Karten oder Karten vom falschen Typ, falls der Kartensteckplatz beschädigt wird.
- 2) Setzen Sie die Karte ein, wenn das Telefon ausgeschaltet ist.
- 3) TF-Karte ist bis zu 64GB.

Netzwerkbander

GSM: B2/3/5/8(1900/1800/850/900)

WCDMA: B1/2/5/8(2100/1900/850/900)

Gesichts Entsperrung:

Einstellung > Face UnLock

Netzwerkverbindung

WiFi: Einstellung > Netzwerk & Internet > WiFi

Hotspot: Einstellung > Netzwerk & Internet >

Hotspot-Tethering

[FR]

