




Label PRK001002:



Label Size is 50.8mm x 38.1mm (2"x1.5")


Location: Label should be placed inside the opening in the damping pad on the bottom of the enclosure, at the time of device assembly.

Label Location





Label PRK002001:



Label Size is 50.8mm x 38.1mm (2"x1.5")

Location: Label is placed in the recess on the bottom of the enclosure, at the time of device assembly.

