

尺寸: 100x85mm

## 产品说明书

—Product description—




YK-Q71

夹耳式蓝牙耳机

### 产品规格

蓝牙版本: V5.3
通话时间: 约6小时
音乐播放: 约6小时
待机时间: 800小时
通话距离: >10m
耳机充电容量: 300MAH
充电电池容量: 300MAH
耳机充电时间: 约2小时
频率范围: 2.4GHz-2.48GHz
支持协议: USB, AAC, SBC, EDR, LL

### 多功能键



## User Manual

—Product description—




YK-Q71

Clip on Wireless headset

### Product version

Wireless Version: V5.3
Talk time: about 6 hours
Music playing: about 6 hours
Standby time: 80 hours
Communication distance: 10m
Charging time of headset: about 1 hour
Headset battery capacity: 300MAH
Battery capacity of charging source: 300MAH
Frequency characteristic: 2.4GHz-2.48GHz
Support protocols: USB, AAC, SBC, EDR, LL

### Multiple function key



接听/播放/接听+下键挂断
上一曲/播放/接听+下键向下曲目切换
下一曲/播放/接听+下键向下曲目切换
音量加/接听+音量耳罩按钮
音量减/接听+音量耳罩按钮
接听电话/接听+音量耳罩按钮
接听电话/接听+音量耳罩按钮
接听电话/接听+音量耳罩按钮
接听电话/接听+音量耳罩按钮
接听电话/接听+音量耳罩按钮
接听电话/接听+音量耳罩按钮
接听电话/接听+音量耳罩按钮

**开机/关机**  
1. 长按电源键5秒以上，耳机将自动开机并进入待机状态。  
2. 长按电源键5秒以上，耳机将自动关机。

**如何重置**  
取出耳机并取下耳罩，将耳机放入充电盒，长按电源键5秒以上，耳机将自动重置。

**如何配对**  
1. 取出耳机并取下耳罩，长按电源键5秒以上，耳机将进入配对模式。  
2. 打开手机蓝牙，搜索并连接耳机。

**如何充电/充电**  
取出耳机并取下耳罩，将耳机放入充电盒，长按电源键5秒以上，耳机将进入充电模式。

**如何充电/充电**  
取出耳机并取下耳罩，将耳机放入充电盒，长按电源键5秒以上，耳机将进入充电模式。

**如何给耳机充电**  
取出耳机并取下耳罩，将耳机放入充电盒，长按电源键5秒以上，耳机将进入充电模式。

**给充电仓充电**  
取出充电仓并取下盖子，将充电仓放入充电器，长按电源键5秒以上，充电仓将进入充电模式。

**Power on/off**  
1. Press the power button for 5 seconds to turn on the charging chamber for the first time.  
2. Press the power button for 5 seconds to turn off the charging chamber and it will start charging the headset.  
3. Press the power button for 5 seconds to turn on the headset and it will start charging the headset.

**How to reset**  
1. Remove the headset and take it out of the charging case.  
2. Press the power button for 5 seconds to reset the headset.

**How to pair**  
1. Remove the headset and take it out of the charging case.  
2. Press the power button for 5 seconds to enter the pairing mode.

**Comparison pairing method**  
1. Turn on the headset and take it out of the charging case.  
2. Press the power button for 5 seconds to enter the pairing mode.

**Power on/off**  
1. Press the power button for 5 seconds to turn on the charging chamber for the first time.  
2. Press the power button for 5 seconds to turn off the charging chamber and it will start charging the headset.  
3. Press the power button for 5 seconds to turn on the headset and it will start charging the headset.

**How to reset**  
1. Remove the headset and take it out of the charging case.  
2. Press the power button for 5 seconds to reset the headset.

**How to pair**  
1. Remove the headset and take it out of the charging case.  
2. Press the power button for 5 seconds to enter the pairing mode.

**Comparison pairing method**  
1. Turn on the headset and take it out of the charging case.  
2. Press the power button for 5 seconds to enter the pairing mode.

**How to charge the headset**  
1. Remove the headset and take it out of the charging case.  
2. Press the power button for 5 seconds to enter the charging mode.

**How to charge the headset**  
1. Remove the headset and take it out of the charging case.  
2. Press the power button for 5 seconds to enter the charging mode.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement. the device can be used in portable exposure condition without restriction