

The Destination Name Button. The Destination Name button shows your trip destination's name in Map View. Tapping the Destination Name button takes you to the item's Details / Route Planning / Options page. Tap the Close tab to return to the Destination Name button in Map View.


You can tap on the map to return the Destination icon



The Via Point Icon. The Via Point icon represents a programmed stop along your trip route in Map View. Tapping the Via Point icon once transforms it into the Via Point Name button. You can tap on the map to return the Via Point icon.

The Via Point Name Button. The Via Point Name button shows your trip Via Point's name in Map View. Tapping the Via Point Name button takes you to the item's Details / Route Planning / Options page. Tap the Close tab to return to the Via Point Name button in Map View. You can tap on the map to return the Via Point icon.

Additional Via Points Icon. The Additional Via Point icon represents additional programmed stops along your trip route in Map View. The numbers increase incrementally and chronologically as you add Via Points. Tapping the Via Point icon once transforms it into the Via Point Name button. You can tap on the map to return the Via Point icon.



The Map Selection Point Icon. The Map Selection Point icon represents a location you've chosen by tapping the Map Selection Point button in the Smart Orientation menu and pressing a point on the map in Map View. Tapping the Map Selection Point icon once transforms it into the Map Selection Point Name button. You can tap on the map to return the Map Selection Point icon.


The Map Selection Point Name Button. The Map Selection Point Name button displays the name and location of the map point you've chosen by tapping the Map Selection Point button in the Smart Orientation menu and pressing a point on the map in Map View. Tapping the Map Selection Point Name button takes you to the item's Details / Route Planning / Options page. Tap the Close tab to return to the Map Selection Point Name button in Map View. You can tap on the map to return the Map Selection Point Icon.



The Favorite Place Point Icon. The Favorite Place Point icon represents the location of a Favorite Place in Map View that has not yet been defined as Start Point, Destination, Via Point or Home. Tapping the Favorite Place Point icon once transforms it into the Favorite Place Point Name button. You can tap on the map to return the Favorite Place Point icon.

The Favorite Place Point Name Button. The Favorite Place Point Name button shows you the name and the location of the Favorite Place in Map View. Tapping the Favorite Place Point Name button takes you to the item's Details / Route Planning / Options page. Tap the Close tab to return to the Favorite Place Point Name button in Map View. You can tap on the map to return the Favorite Place Point icon.

If you choose any of the options in the Route Planning Bar (Navigate To, Add As Via Point, Add as Destination, Set As Start on the Details / Route Planning / Options page, the Favorite Place Point Name button will change into the corresponding type of button once you're back in Map View.




The Search Result Point Icon. The Search Result Point icon represents a search result's location in Map View that has not yet been defined as a start point, destination, via point or home. Tapping the Search Result Point icon once transforms it into the Search Result Point Name button. You can tap on the map to return the Search Result Point icon.

The Search Result Name Point Button

The Search Result Point Name button displays your search result's location and name in Map View. Tapping the Search Result Point Name button takes you to the search results's Location Details / Route Planning and Options page.

Tap the Close tab to return to the Search Result Point Name button in Map View. You can tap on the map to return the Search Result Point icon.



If you choose any of the options in the Route Planning Bar (Navigate To, Add As Via Point, Add as Destination, Set As Start on the search result's Location Details / Route Planning and Options page, the Search Result Point Name button will change into the corresponding type of button once you're back in Map View.

Page View Buttons and Icons



The Active Route Icon

The Active Route Icon

The Active Route icon on the Route Details bar indicates that your are currently, actively navigating that route (Active route details and options can be viewed by tapping the Route option in the Last Page Accessed field on the Control Bar in Map View or on the Main Menu page.)



The Inactive Route Icon


The Inactive Route Icon

The Inactive Route icon on the Route Details bar indicates that your are currently not navigating that route (Inactive route details and options can be viewed by tapping the Route option in the Last Page Accessed field on the Control Bar in Map View or on the Main Menu page.)



The Pause/Resume/Record Route Button.

Tapping the Pause/ Resume/Record Route button on the Trip Display bar lets you pause and resume a navigation session (The Trip Display bar can be viewed by tapping the Route button in the Last Page Accessed field on the Control Bar in Map View or on the Main Menu page.) You can record and save any route you drive by first exiting any navigation sessions, then Route ? Pause/Resume/Record Route.



The Favorite Place / Priority Favorite Place Button


The Favorite Place button appears as a blue-outlined star next to any address when viewing it's details. You can tap on the Favorite Place button next to the address to turn it into a Priority Favorite Place which is now represented by a solid yellow star. This means that the address will now be placed at the top of your Favorite Places list.

The Map Locator Button



The Map Locator Button

The Map Locator button is always displayed next to addresses, points of interest (POI) or GPS coordinates in both the summarized info and fully-detailed info display modes. Tap on the Map Locator button to instantly view that item's location in Map View.



The Home Icon


The Home Icon



The Home icon is located next to an address in both the summarized info and fully-detailed info display modes and it represents the item that you've designated as Home. This can be your actual home address, your work location, your hotel while on holiday, etc. You can set an address as home by tapping the Set as Home button on its Details / Route Planning / Options page. You need to have this option set to use the Take Me Home button in the Main Menu.


Part 2 Using the Application

Or What happens when I press this?

Using Search



 The Search button () is always present on the Control Bar no matter where you are in the app. Tap it from anywhere in the app to go directly to the Search page.



The Cancel Button (In Landscape)

To return to the Map View, tap Close button in the upper right corner.

Defining Search Categories




The Search Category is set by default to All. By tapping on the Search Category button, you can toggle between Streets, POI, Lon/Lat and all.

Selecting State




The default search state is the one your Map View is currently displaying. Tap the Select state button to go to the Select state page. Tap on the specific state you want to search. Tap the Close tab to save your selection and go back to the Search page.

Using the Letter/Number/Symbol Toggle Button




Tap the Letter / Number / Symbol Toggle button to toggle the keyboard inputs between letters, numbers and symbols.

Using the What Field




Tap in a name, street, address, POI or longitude coordinate in the What field using the keyboard. A suggested result will appear in the Suggested Result area automatically as you type.

Using the Where Field



Tap in a city or town or latitude coordinate in the Where field using the keyboard to narrow your search even further Delhi.

How to Delete a Single Space




Tap the Delete Space button to delete a single letter, number or space in either the What or Where fields.

How to Clear the Search Fields



Tap the Clear Field button (x) in the What or Where fields to delete the entire contents of either the What or Where field.

How to Get a Complete List of Search Results



Tap the Get Search Results button at any point in your search to hide the keyboard and display a complete list of search results.

How to Narrow Your Search Results and View Their Details



While viewing the results list, you can narrow your search even further by tapping the Search Category button to toggle between Streets, POI, Lon/Lat and All. Tapping directly on a Search Result will show its Location Details / Route Planning and Options page.

How to See a Search Result in Map View



Tap on the Map Locator button to instantly view your search result's location as a Search Result Name Point button in Map View.

How to Reveal the Keyboard



As your search results are being displayed, tap on the What or Where field to reveal the keyboard again.

How to Use the Location Details / Route Planning and Options Page

You Can Get to this Page in a Number of Ways

By tapping a Map View Location Name button or a Location Result on any page in the app, it will take you to the Location Details / Route Planning and Options page.

For example: From Map View: Location Icon® Location Name Button® Location Details / Route Planning and Options page or...



From the Search page: Search Result® Location Details / Route Planning and Options page or...

From Favorites: Main Menu/ Control Bar® Favorites® Location® Location Details / Route Planning and Options page... etc.

Using the Location Details Bar




The Location Details bar displays your location's full address, POI icon, GPS coordinates and other details (if available) like phone numbers. Map Locator® Location in Map View.

Using the Route Planning Bar




Depending on whether your selected location is undefined, previously defined (as a Destination, Start Point, Via Point or an undefined Search Result or Map Location Point), or if it is already part of a currently active or saved route, the Route Planning bar presents you with a variety of active and inactive buttons:

Navigate To: instantly begins guiding you to the selected location from your current GPS location. Remove from Trip: removes the selected location from your current route.


 This option appears only after the selected location has been set as a start point, via point or destination.


Add as Via Point: adds the selected location to your current route as a via point.

 This option appears only when you are adding a third (or higher) location to your trip route.

Add as Destination: sets the selected location as your destination or replaces a previous destination with the selected location.

Using the Via Point Order Bar



 This bar only appears on the Location Details / Route Planning and Options page when there are three or more locations on your trip route.

Move Before Previous: moves the selected location towards the beginning of your journey, i.e. just before the location preceding it.




Moving the selected location before your start point will make the selected location your new start point.

Move After Next: moves the selected location towards the end of your journey, i.e. just after the location following it.



Moving the selected location after your destination will make the selected location your new destination.

Using the Place Bar



Depending on whether your selected location is nameless, named, categorized, a favorite or set as home, the Place bar will be present with a number of buttons:

Find Closest POI: Find the closest Points Of Interest (POI) to your selected location. Find Closest POI @ Closest POI page - where nearby Points of Interest (hotels, petrol stations, restaurants, etc.) are automatically listed according to their proximity to your selected location. Tap on a POI Location to go to its Location Details / RoutePlanning and Options page. To further refine your POI results: Select

Category @ Select Category page where all POI are selected by default. Individually select and deselect or Deselect All categories. Close to go back to the, now modified, Closest POI page. Select Category will now reflect your POI selection preference (i.e. Petrol Station, Multiple, All, etc.)

Categories: Designate your selected location as Business, Family or friends



- You can select multiple categories, one or none.
- This option only appears after you've saved a location as a Favorite.

Add Name/ Rename: Add or rename and save a name for your selected location. Add Name or Rename → Input Keyboard → Tap in a new name → Save → Location Details / Route Planning and Options page. The new name appears in bold lettering as the top line of your selected favorite location.



This option appears only after you've saved a location as a Favorite.

Add to Favorites: Add the selected location to your list of Favorites. Remove from Favorites: Remove the selected location from your list of Favorites.



This option appears only after you've saved a location as a Favorite.


Set as Home: Set the selected location as Home.

Remove Home Address: Remove the Home designation from the selected location.



This option appears only after you've saved a location as Home.

Getting out of this Page



To exit the Location Details / Route Planning and Options page: Map Locator @ Map View or Close @ which takes you back to wherever it is that you came from (e.g., Route, History, Favorites, Map View, etc.)


Creating Smart Zoom Menu Presets

You can create up to three custom View Presets. First, in the Map View, zoom, tilt and pan the map view to your liking. Second, tap the Smart Zoom button twice to access the Multi-zoom Menu and press and hold the 100, 10 or 1 button for a few seconds.



The Save View bar will appear at the bottom of the screen asking you to confirm or disregard your choice. Tap the right sign button to confirm your choice or the Close button to exit without saving.

Restoring Defaults



The Restore Defaults Button:
To restore the default City, Area and Block Views go Settings → Restore Defaults → Yes


Selecting the Restore Defaults option will not only reset your Multi-zoom Menu, but will restore everything in the application to its original, factory setting.

Using the Main Menu:
How to Get to the Main Menu and Where I Can Go from There.




Open the Main Menu Page by tapping the Main Menu button (). From here you can continue to the five main menu buttons (Take Me Home, Route, Favorites, History & Settings) or tap the Map View, Search or Close Application buttons on the Control Bar to go the corresponding screens and pages.

Using Take Me Home




Go Main Menu → Take Me Home at any time to be guided from your current location to your previously designated Home location. If you are in an active navigation session, the Cancel Current Route window will appear. Select Yes to immediately start being guided to your Home location.

Using Route Options



The Trip page bars, buttons and displays covered in the Using Route Options section are described as they would look if you've previously set a route with a Start Point, Via Point and Destination. If you need to set a route and don't know how, follow the the Quick Start and Simple Navigation instructions


Getting to the Trip, Dashboard and Directions Page



Go Main Menu → Route → Trip page where you can view the Current Trip Status and Control bar, Current Route Details Display bar and the Route Options bar.


Go Main Menu → Route → Trip page → Left tab → Dashboard page Go Main Menu → Route → Trip page → Right tab → Directions page

Using the Current Trip Status and Control Bar



The Current Trip Status and Control bar on the Trip page displays your estimated travel time, estimated route distance, actual travel time and actual travel distance. You can pause your navigation session at any time by tapping the Pause / Resume / Record Route button. You can also use the Current Trip Status bar to record your driving when you are not in an active navigating session by tapping the Pause / Resume / Record Route button once. Tap it again to pause the recording of your drive.

Using the Current Route Details Display Bar




The Current Route Details Display bar on the Trip page shows you your start point, via points and destination. It also shows the estimated route distance and estimated travel time between each stop. The Active Navigation indicator shows whether your navigation route is active (yellow) or inactive (white).

By tapping the Map Locator button next a location you can instantly view the chosen location in the Map View.

By tapping the Map Locator button next to the Active Navigation indicator, Estimated Distance and Time Display, your entire route will be displayed as a 2D aerial map view.

Tap on any Location on the Trip Page to access its Location Details / Route Planning and Options page.

Using the Route Planning Bar




Here you can view your entire trip by stops and stages.


To see a location or portion of your route in Map View: Map Locator → Map View


Tap on any Location to view its Location Details / Route Planning and Options page to access the following.

ROUTE PLANNING



So, Location → Location Details / Route Planning and Options page Remove from Trip: removes the selected location from your current route.


 This option appears only after the selected location has been set as a start point, via point or destination. Add as Via Point: adds the selected location to your current route as a via point

 This option appears only when you are adding a third (or higher) location to your trip route.

Add as Destination: sets the selected location as your destination or replaces a previous destination with the selected location. Set as Start: sets the selected location as your start point.


Using the Via Point Order Bar

VIA POINT ORDER




OK, we're still on the Location Details / Route Planning and Options page. Scroll down to the Via Point Order bar.


Move Before Previous: moves the selected location towards the beginning of your journey, i.e. just before the location preceding it.

 Moving the selected location before your start point will make the selected location your new start point.

Move After Next: moves the selected location towards the end of your journey, i.e. just after the location following it.

 Moving the selected location after your destination will make the selected location your new destination.

Using the Place Bar





And we're still on the Location Details / Route Planning and Options page. Scroll down past the Via Point Order bar to the Place bar. Depending on whether your selected Location is nameless, named, categorized, a favorite or set as home, the Place bar will be present with a number of buttons:

Find Closest POI: Find the closest point of interest to your selected location. Find Closest POI → Closest POI page - where nearby Points of Interest (hotels, petrol stations, restaurants, etc.) are automatically listed according to their proximity to your selected location. Tap on POI Location to go to its Location Details / Route Planning and Options page.


To further refine your POI results: Select Category → Select Category Page where all POI are selected by default. Individually select and deselect or Deselect All categories. Close to go back to the, now modified, Closest POI page. Select Category will now reflect your POI selection preference (i.e. Petrol Station, Multiple, All, etc.)

Categories® Choose Categories page → Business, Family or Friends. Now close Location Details / Route Planning and Options page.


 This option appears only when you are adding a third (or higher) location to your trip route.

 This option only appears after you've saved a location as a Favorite.


Add Name/ Rename: Add or rename and save a name for your selected location. Add Name or Rename → Input Keyboard → Tap in a new name → Save → Location Details / Route Planning and Options page. The new name appears in bold lettering as the top line of your selected Favorite Location.

 This option only appears after you've saved a location as a Favorite.

Add to Favorites: Add the selected location to your list of Favorites. **Remove from Favorites:** Remove the selected location from your list of Favorites.

 This option only appears after you've saved a location as a Favorite.

Set as Home: Set the selected location as Home. **Remove Home Address:** Remove the Home designation from the selected location.

 This option only appears after you've saved a location as a Favorite.

Using the Route Options Bar

