
A02_QSG_iONE

展開尺寸: W320X H100 MM 折疊尺寸: W80X H100 MM 材質: 雙銅157g 顏色: 1C印刷 公差: + / - 0.5mm 裁切線: 折線: 料號:

正面



反面

START USING

WIRELESS MODE

RECHARGE Plug the [D. USB Charging Cable] (TYPE C) into the earphone and the other end (TYPE A) into the computer USB port to start charging. Let the battery is fully charged before its first use.

Low battery: Red light Blinking once for 2 seconds · Charging: Light will turn solid Red · Charging completed: Light will turn solid green

BLUETOOTH

 Turn on Bluetooth pairing mode (mobile phone): Press [G. Power Button] for 3.5 seconds, the red and green lights will switch blink twice in 1 seconds Pairing is complete: The green light will blink sixth

PHONE CALL

Receiving a call: Press the [H. Play Button] once Ending the call: Press and hold the [H. Play Button] for 1 second

Reject the call: Press and hold the [H. Play Butter] of Faceond (Incoming call during a call) Hold the call and answer the interrupted call: Press the

[H. Play Button] once (Incoming call during a call) Ending the call and return to the original call: Press and hold the [H. Play Button] for 1 second

(Incoming call during a call) Rejection of Interruption: Press the [H. Plav Button]

for 1 second Mute/Unmute the call: Press the [J. Volume Up Button] and [K. Volume Down Button]

at the same time

START THE VOICE CONTROL SERVICE

FCC

04

Federal Communications Commission (FCC) Statement You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

s device complies with Part 15 of the FCC Rules. Operation is subject to the following

two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation of the device.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

SRRC

不得擅自更改发射频率,增大发射功率(包括额外加装射频功率放大器),不得擅自自分割天 线或改用其他发射天线。 使用时不得对各种合法的无线电通信业务产生有害干扰;一旦发现有干扰现象时,应立即停

止使用,并采取措施消除于扰后方可继续使用。

使用微功率无线电设备,必须忍受各种无线电业务的干扰或工业,科学及医疗应用设备的辐 射干扰。 不得在飞机和机场附近使用。

NCC

取得審驗證明之低功率射頻器材,非經核准,公司、商號或使 用者均不得擅自變更頻率、加大 私情審報編如之記》中初時的子科加強的子科性化是一品的「同語系」的目分子「特益自要定現十一加入 對率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通 信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。前述合法通信,指 依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療 用電波輻射性電機設備之干擾。

POWER ON/OFF

Power on: Press [G. Power Button] for 2 seconds, the green light will blink twice
Power off: Press [G. Power Button] for 2 seconds, the red light will blink twice

PLAY

 Play/Pause: Press the [H. Play/Pause Button] once
Volume +/-: Press [J. Volume Up Button] once / Press [K. Volume Down Button] once · Previous song: Press and hold the [J. Volume Up Button] for 1 second Next song: Press and hold the [K. Volume Down Button] for 1 second

MODE

· Normal-ANC: In normal mode, press [I. Mode Button] once, the blue light will turn on for 5 seconds to enter the ANC mode

ANC-AMDient: In ANC mode, press [I. Mode Button] once, the white light will turn on for 5 seconds to enter the Ambient mode. Ambient--Normal: In the ambient mode, press the [I. Mode Button] once to enter the normal mode 03

Siri / Google assistant / Activate voice control: Press and hold [I. Mode Button] for 2 seconds

WIRED MODE

Plug [E. 3.5mm Audio Cable] into the headphone and the other end into the device to

% In wired mode, you can turn on the power to choose ANC or ambient mode but need to control play and volume by using your device (such as a computer)

-Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. is connected. -Consult the dealer or an experienced radio/TV technician for help

FCC RF Radiation Exposure Statement: The product comply with the FCC portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available.

WARNING

05

To avoid hearing damage and damage to the earphones, use the earphone at a comfortable, moderate volume level. Turn the volume up gradually until you reach a comfortable level. Earphones should keep away from fire, or in the situation with high temperature or

high pressure. Do not immerse the earphones into the water or place the earphones in high humidity

06

situation for long time. Stop using the earphones if you find liquid leakage, overheating or other

unusual conditions. Do not try to disassemble or short circuit the earphones.