

## User Manual

### Wireless Mini Camera



Protect your home and personal safety anytime

Dear friends,

Thank you for purchasing our camera. Please read and follow this user manual carefully and keep it in a safe place for future reference.

We consistently attach great importance to product quality and high customer satisfaction. We sincerely hope you can make a few suggestions during your use to help us improve our products. Your precious suggestions will help us shape our business to perfectly fit your standards.

We'll soon introduce series of new products for our valued customers, please share this with your friends.

Just let us know if you encounter any problem during your use. Our support team will provide you our best solution without any delay, by 1 year warranty.

You can find our contact information below:

Look forward to bringing you more great products in the future.

Kind regards,

Customer Support Team

After-sales Email:

### Contents

#### 1. Buttons instruction

#### 2. Steps for usage

- 1).Download the App
- 2).Charge
- 3).Power on
- 4).Connect camera
- 5).Add device
- 6).Wi-Fi config
- 7).Change camera password

#### 3. SD card recording

#### 4. Setting Instruction

#### 5. Camera info

#### 6. FAQs

#### 7. Package Content

#### 8. Safety Precautions

#### 9. Rapid after-sale online

### About iphone's IOS system




Due to the privacy policy of ios14 system, users need to access the local network permission when adding devices after installing app. Please allow app to use this permission when installing app and adding device,otherwise the device cannot be used normally.



### 1. Buttons Instruction


#### P1



#### P2



#### P4




#### P5



**2. Steps for usage**

**1) Download the App**

Scan QR code below or search "OUCCAM" in App Store (IOS)  
 "OUCCAM MAX" in Google Play Store (Android),then download the app:



**2) Charge**



Charge the device (DC 5V and below).  
 It is recommended to keep charged during use, the built-in battery is only for backup.

**3) Power on**

long press the power button 3s,the camera flash green after the camera is turned on;  
 The camera will automatically turn on when the charger is plugged in.

**4) Connect camera**

Open the "Wi-Fi setting" of your phone, search the camera's "hotspot" and click connect(image 1);








1. **Please confirm the current network status of camera to keep hotspot connected**

**5)Add device**







Enter the APP; the device will automatically connect, then the camera shows "online";

If the device does not appear you can click "+"(image 3) and add the device manually (the device ID and QR code can be found at the bottom of the device)(the default password 123)(image 4-6).

**6)Wi-Fi config**

Click Security Code enter the old password "123" and enter the new password you want to change.  
 (image8) enter your Wi-Fi password and click "Join"(image 9).  
 (image10) the Wi-Fi setting page to found the Wi-Fi router (image 11).  
 The Wi-Fi name and password only supports alphanumeric characters

7. **Please confirm the current network status of camera to keep hotspot connected**

8. **Please confirm the current network status of camera to keep hotspot connected**

9. **Please confirm the current network status of camera to keep hotspot connected**

10. **Please confirm the current network status of camera to keep hotspot connected**

11. **Please confirm the current network status of camera to keep hotspot connected**

12. **Please confirm the current network status of camera to keep hotspot connected**

**7)Change camera password**

Click Security Code enter the old password "123" and enter the new password you want to change.  
 To protect your privacy, please change the camera passworded in time!

**3. SD card recording**

If use the camera in a place where there is no internet, you can insert an SD card to record video(With the chip facing up, press the card firmly until it is fixed), the camera will automatically loop record video when power on,the latest footage will overwrite the oldest footage when the SD card is full.

You can select 24-hour recording or motion alarm recording mode via the phone APP.


The video will be saved every three minutes.  
 For your convenience, please set the time synchronization function on the phone APP when you start recording.

When inserting the SD card, please turn off the power, SD card: max 128GB, format: FAT32, suggest speed no less than Class 10, 24-hour recording folder name:"plan\_record\_dir"

Alarm recording folder name: "alarm\_record\_dir"

FUNC status	History playback	Real-time monitor	Photo shooting	Video shooting	Not returned
SD card	√	√	√	√	√
No SD card	×	√	√	√	×

**4. Setting instruction**



**5. Camera info**

Model	Full charging	Work time	Li-ion capacity	Night vision	WiFi type
P1	1.5-2h	60-90min	380mAh 3.7V	√	2.4G
P2	1.5-2h	70-100min	380mAh 3.7V	√	2.4G
PA	2.5-3h	300-420min	1480mAh 3.7V	√	2.4G
PM	2.5-3h	240-360min	380mAh 3.7V	√	2.4G

**6.FAQS**

**Q: What if I forget the camera password?**  
 A: If you forget the password, you can use the pin to reset the camera (Under "power on" status, use the pin to press the "reset hole" and release), the camera will restore the default password "123".

**Q: Why I can't find the camera's hotspot? and my phone often disconnects from the camera's hotspot?**  
 A: Before the camera is not connected to Wi-Fi, please make the camera and the phone as close as you can.

**Q: Why is my video often offline?**  
 A: Please make sure to place the camera where it can receive the Wi-Fi signal well, and keep the camera powered.

**Q: Can I only save videos via SD card and camera is not networked?**  
 A: No, you can record a video by your phone, just click the record shooting button on the video interface, the video will be saved in your phone.

**Q: How can I find the video I recorded with my phone?**  
 A: Enter the app, click "Local Image" at the bottom, you can click "Record" to find your recorded video.

**Q: How do I add multiple devices? How can I distinguish them after adding?**  
 A: After successfully connecting one device to the Wi-Fi, you can disconnect the camera's hotspot, and then repeat step 4 to another device until successfully connected to Wi-Fi. You can connect up to 18 devices at the same time. In order to better distinguish your device, you can click Settings to change the name of the camera.

**Q: I have followed the steps in the manual and still cannot use the camera. What should I do?**  
 A: Reset the camera and repeat the steps. If it still doesn't work, please contact customer service team to replace a new unit via app's support after-sales.

**7.Package Content**

- 1×Mini Spy camera
- 1×User manual
- 1×Power cable
- 1×Magnetic base (not include model: P5)
- 1×Reset pin


**8.Safety Precautions**

Do not use the camera outdoors, the camera is not waterproof.  
 Do not place the device in dusty, wet areas, or it will cause internal circuit faults.  
 Do not place the device in heater, flammable atmosphere, or it will cause explosion or fire-danger.  
 Install the camera far away from the metal devices and microwave oven to avoid signal interference.

**9.Rapid After-sales online**

In order to better solve the problems you encounter in the use of the product, customers submit product problems through the APP, and our customer service staff will get in touch with you within 12 hours

Tips: Get Bonus via App's Coupon&deals  
 More brand activities is waiting for you.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.