

Sports Smart Watch

User Manual



Thank you for choosing our smart band. You can read this manual thoroughly to understand the use of the equipment and how to do it simply. The Company reserves the right to make changes to the contents of this manual without prior notice without prior notice.

Product configuration:

1. Smart Watch * 1
2. Data cable* 1
3. Manual * 1

This product supports IP68 waterproof, so it's available to wear it while wash hands, swim, take a shower, etc.

Key Description:

A: Page up

B: Page down


C: Short press to confirm, long press to enter the sports mode

D: Short press to return, long press to boot.

E: Shortcut page up / down button



Charging Description: This product uses magnetic charger. Align the charging head at the back of the charging contact, will automatically adsorb the charge.




Please note that the two contacts of the charging cable can not touch the conductive object at the same time, otherwise it will cause short circuit combustion.

How to connect the phone:

(1) IOS, Android System Phone users:

Through the phone browser to scan the back of the QR code and select the first download.


Or sweep with a WeChat. When you open the interface, and then click the upper right option, select the mobile browser to open and download.



(2) Android Phone: download "Fundo" app from Google Play;

IOS phone: download "Fundo" app from App Store;


Open "Fundo" app and Bluetooth function from your phone after finish install, click "more" as below, then click "connect watch". And then point the upper right corner of the "search", search Smart Device and can be connected, When the upper left corner of the watch has a Bluetooth logo, on behalf of the connection is successful.



●Firmware upgrade: At normal Bluetooth connect ion status, enter FunDo, click More on the bottom right corner, find the firmware upgrade item, clic k it. If there is a new version, you will be prompte d to upgrade, click YES, there will be a progress ba r afre you click YES, the upgrade process will take 3-5 minutes. The device will automatically boot a nd connect with smartphone after the upgrade is complete. Please disconnect the device, then con nect again. Please note that if the progress bar is s

tuck, please do not do any thing, let the progress work slowly until it is complete.

Since there would be some difference of Bluetooth protocol for different smart phones, it may cause Bluetooth connection unstable sometimes. Turn off Bluetooth on the phone, then re-connect the and phone.



Main Features: (first to open the APP on the mobile phone and connect to, in order to achieve the following functions)

- Standby interface: Enter the main menu, dial function to replace, there are a variety of dial can

be replaced.

- Pedometer: display the number of steps in a day, save data at 12 o'clock every night and reset to 0.
- Distance: show the day's step distance, save data at 12 o'clock every night, and reset to 0
- Calories: show the calorie burned of the day, save data at 12 o'clock every night and reset to 0.
- Heart rate: press the enter key to test and scan the surface capillary of the skin by green light to get the heart rate data, switch to other menus to stop measuring, normal heart rate is generally 60-90 times / minute, professional athletes will be less than 60 times, when doing strenuous exercise will reach more than 200 times. Long term exercises can increase heart and lung.
- Sleep monitoring: the smart watch will open this function automatically from 9p.m to 9 a.m. every night. You can check the detailed data of sleep quality by connecting APP on the phone.
- Sports: Press Enter to enter multi-sport mode, press the touch key to select the sport mode. Selected a mode, press Enter to start the sport, short press Return to stop, the watch will save the

sport data automatically, then return to multi-sport mode. There are jogging, biking, swimming, basketball, table tennis, badminton, hiking, love and football modes in the multi-sport mode. Each exercise data has movement time, calories consumption, and heart rate (swimming mode without heart rate)

- Notifications: synchronous mobile phone end notification function, such as Facebook, WhatsApp and so on, if you want to display the notifies with content, need to setup to display the details of Facebook and WhatsApp notice function in the APP in the cellphone, it can show the latest 8 notifications, press the enter key to read, press the touch key to next message , short press return key to back. It will vibrate for incoming calls and messages.

- Tooling: Software version (check the Bluetooth address and name), Bluetooth camera (APP side to open the Bluetooth camera, watch side click to take pictures, long press to exit). Find the phone (find the bracelet) shutdown (select the shutdown, press long press).

- Language: support in English and Chinese display, the default is automatically synchronized, what language is the phone, the shows what language.
- Stopwatch: press the enter key to enter, then press again to pause.
- Alarm: Can set several alarm clocks through the APP on mobile phone.
- Data transmission: need to download FunDo APP on mobile phone, after the connection is successful, the date of Pedometer, heart rate, sleep quality, and multi-sport mode can be transmitted to the APP on the mobile phone. Some data needs to be manually synchronized.

Warranty

1. If it appears quality problems caused by manufacturing, materials, design within one year (since the day of purchase) , we will offer free warranty for. We will offer free warranty for battery and adapter within 6 months. Premise is using normally and correctly.

2. About the fault caused by the users personal reasons, we don't offer free warranty, as follows:

1). Disassemble or refit the product.

2). Caused by immodesty drop

3). All artificial damage or misuse (such as: make water into the host, the external force shatter, scratch damage of peripheral components, etc.), all these are beyond the scope of the warranty.

3. When ask for free warranty, you must provide a warranty card with the seal of purchase place and purchase date.

4. If you met problems during use, please contact the shop customer service which you bought from.

5. Please make the final products as the standard.

Date of purchase:

IMEI code:

Buy store:

Customer signature:

Clerk Signature:

Shop stamp:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.