
Panasonic[®]



Welcome to the Seekit Community

Getting Started

- Download Seekit app for Android or iOS.
- Long press physical Seekit button for 8 seconds till



- Connect Seekit by following in-app instructions
- Attach Seekit to your things & never worry about losing them again
- Keep the app on to know where your things are always

Use Cases





























Range of up to 100 ft

- H: Hear a separation alert as soon as your Seekit is outside
- L: Receive notifications only when the Seekit is outside range, switch to this with a push of a button, recommended use in secure surroundings.
- Pickpocket Mode: A more where you need to be more careful, like railway stations, metro stations, with your pet.
- DND: Because we understand, sometimes you just don't want to be disturbed.
- Wifi Safe Zone: Tell us your familiar Wi-fi networks, where you won't be disturbed once they're configured to Seekit App.

Device Spec - Edge



Model Edge [IC-BCWL01BK]

: 45*45*2.8 mm Size : 7.7 gms

Listed Range : Up to 100 feet : 80 decibels Loudness claimed

Android, iOS Compatibility

: 5.0 Bluetooth Version Operating Temperature: After CE Report

Smartphone Requirement

iOS devices (running version 9.0 or newer) with built in Bluetooth 4.0 Android devices (running version 4.4 or newer) with built in Bluetooth 4.0

Warranty Information

Seekit Edge has limited replacement warranty for 12 months (warranty not applicable on batteries)

Special Instruction

This product is intended as an item finder only, it is not a toy. It is not edible. Presence of metallic objects, telecommunication networks, mobile phone covers can adversely affect connection.

Tips for using this device can be found on our website, www.panasonicseekit.com

Warning: Do not open Seekit device.

Declaration of Conformity

This product is CE & FCC compliant.

Warning: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WEEE Directive & Product Disposal

At the end of its serviceable life, this product should not be treated as household or general waste.

It should be handed over to the applicable collection point for recycling of electrical and electronic equipment, or returned to supplier.

Panasonic is a Trademark of Panasonic Corporation ©Copyright 2017 Panasonic Corporation All Rights Reserved.

Panasonic Corporation reserves the right to alter material or technical specifications without prior notice.

Customer Assistance

For any queries related to the product you can contact us at Call Centre No: XXXXXX or visit us on www.seekit.panasonic.com