

CQL1659-B Bluetooth Speaker

Instruction Manual (Read before proceeding)

Power:

- Works on internal rechargeable Lithium battery. Please charge your speaker fully before first use.

To charge the battery :

Using a Micro USB cable (included), insert the jack into "Charging" jack located on the back of the unit and then plug the USB connector into the USB port on a computer for charging.

- A red light will indicate the charging situation. When battery is full, the red light will turn off automatically.

Bluetooth Speaker Operation

- Turn on the unit by pushing the switch on the back to "On" position (LED lights on) Or Middle(LED lights off) . A Blue light will start blinking quickly to indicate the speaker is in pairing mode and searching for your Bluetooth mobile device.
- Open the Bluetooth function on your device and search the speaker named "MVMT_SP3316". After selecting this speaker, your device will pair without a password. (If required, enter the password "0000" to finalize the pairing).The Blue light will begin to flashing slowly after pair is complete.
- Start playing music on your device. Keep your device within 33feet (10meter) of your speaker.
- Adjust the volume of your device to a comfortable level.
- Turn off the unit by sliding the switch to "Off" position when not in used.

Color Light Operation

- Turn on the color light by pushing the switch to "ON" position
- Translucent circle changes in 3 colors gradually.
- Turn off the color light by pushing the switch to Middle"." or "Off" position.

Qi wireless charging

- Turn on the unit by pushing the switch to Middle"." or "On" position
- Plug micro USB cable (included) into the USB wall adaptor (not incl., 5V,2.5A or above), insert the jack into "Charging" jack located on the back of the unit
- Put your mobile devices with wireless charging function on the top charging silicone pad, then it will automatically be charged.
- Turn off the unit by pushing the switch to "Off" position when not in used.

Caution:

- This is not a toy. Please keep away from small children.
- Please keep away from water / heat.
- Low power may cause poor connection even no working of Bluetooth.
- Do not over charge the battery.
- Battery pack shall not be exposed to excessive heat such as sunshine, fire or the like

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.