


**CQL1679-B Bluetooth Speaker with LED Clock
Instruction Manual (Read before proceeding)**



Power:

- Please charge your Bluetooth speaker fully before its first use.
To charge the battery:
- Using a Micro USB Charging Cable (included), insert the USB power cable into the micro USB port located **at the back** of the speaker. Connect the other end of the USB cord into a powered USB source such as a computer, laptop or USB AC adapter.
- When your Bluetooth speaker is charging, the indicator light will turn red.
- Once your Bluetooth speaker is fully charged, the red light will turn off.

Playing Music via Bluetooth

- Turn your Bluetooth speaker on by sliding the power switch located **at the back** of the speaker to **middle or "ON" position**. The Bluetooth indicator light will start flashing blue quickly.
- Make sure the Bluetooth function on your device is turned on.
- Search the speaker named, "SB-01".
- Once you have selected the speaker, your device will pair without a password. (If your device prompts for a password, enter the password "0000".)
- Once your speaker is paired, the blue indicator light will begin to flash slowly.
- Start playing music on your device. Make sure that you keep your device within a 33 feet range of your Bluetooth speaker.
- Adjust the volume of your device to a comfortable level.
- Turn off the unit when not in use.

Light Operation

- Push the On Off button to the "On" position to turn on the unit, the light will light up automatically.
- Play music on your mobile device, the light will dance to the music.
- Turn off the unit, the light will turn off accordingly.

Note: Switch the button to **middle** position will activate the Bluetooth function only, no light. Push the button to **ON** position will activate the Bluetooth and LED lights at the same

time.

Button Control for the LED Clock:



:

- Snooze for 5MIN.
- When the alarm starts, press this button to snooze for 5MINs and the alarm icon on the LED will start blinking. After 5MINs, the alarm will start again and repeat this process.



:

- Press this button, the alarm icon on the LED will light up. Press it one more time, the alarm icon on the LED will disappear.
- When the alarm starts, press this button to stop the alarm, press it again to make sure the alarm icon on the LED **disappear so that the alarm is totally turned off.**



:

- Long press this button, the hour digit will start blinking (press the right bottom button to change the digit)
- Press it one time again, the minute digit will start blinking (press the right bottom button to change the digit)
- Press it one time again, **the hour digit for the alarm time** will start blinking (press the right bottom button to change the digit)
- Press it one time again, **the minute digit for the alarm time** will start blinking (press the right bottom button to change the digit)



:

- Press it to increase the digit from **01-12** for hour digit and increase the digit from 00-59 for minute digit. This button is can only increase the digit and cannot decrease the digit.
- The display for time and alarm is AM and PM.

Note:

******The Bluetooth indicator light in the front will turn off automatically if the Bluetooth is not paired to the mobile phone for 5 MINS. To use the Bluetooth function again, please turn Off and On the switch again.**

******While you turn off the unit, the time has its memory as long as there is still battery left of the speaker.**

******If the speaker is with no battery inside at all, the time cannot memorize its track. The users need to charge the unit and reset the time again.**

Caution:

- This is not a toy. Please keep away from children.
- Please keep away from water / heat.
- Low power may cause poor connection even no working of Bluetooth.
- Do not overcharge the battery.
- Battery pack shall not be exposed to excessive heat such as sunshine, fire or the like.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.