

CQL1695-B Bluetooth Speaker
Instruction Manual (Read before proceeding)



Power:

- Please charge your Bluetooth speaker fully before its first use.
To charge the battery:
- Using a Micro USB Charging Cable (included), insert the USB power cable into the micro USB port located **at the back** of the speaker. Connect the other end of the USB cord into a powered USB source such as a computer, laptop or USB AC adapter.
- When your Bluetooth speaker is charging, **both indicator lights at the back of the unit will both turn solid red. The left red light in the back means the internal lithium battery inside the speaker is charging. Once your Bluetooth speaker is fully charged, this red light will turn off. The right red light in the back means the wireless charging function is enabled and ready for wireless charging.** Put your phone on the wireless charging pad of the speaker, if the phone is charging, **this light will turn solid blue**, white means the phone is in charging status.

Playing Music via Bluetooth

- Turn your Bluetooth speaker on by sliding the power switch located **at the back** of the speaker to **middle or "ON" position**. The Bluetooth indicator light **in the front of the speaker** will start flashing blue quickly.
- Make sure the Bluetooth function on your device is turned on.
- Search the speaker named, **"SB-01"**.
- Once you have selected the speaker, your device will pair without a password. (If your device prompts for a password, enter the password "0000".)
- Once your speaker is paired, the blue indicator light will begin to flash slowly.
- Start playing music on your device. Make sure that you keep your device within a 33 feet range of your Bluetooth speaker.
- Adjust the volume of your device to a comfortable level.
- Turn off the unit when not in use.

Light Operation [updated on March 5th]

- Push the On Off button to the "On" position to turn on the unit, the light will light up automatically. **The lights will slowly change between 7 colors before the music**

coming in.

- Play music on your mobile device, **the light will dance to the music.**
- Pause the music, **lights will slowly change between 7 colors.**
- Turn off the unit, the light will turn off accordingly.

Note: Switch the button to **middle** position will activate the Bluetooth function only, no light. Push the button to **ON** position will activate the Bluetooth and LED lights at the same time.

Button Control for the LED Clock:



:

- Snooze for 5MIN.
- When the alarm starts, press this button to snooze for 5MINs and the alarm icon on the LED will start blinking. After 5MINs, the alarm will start again and repeat this process.



:

- Press this button, the alarm icon on the LED will light up. Press it one more time, the alarm icon on the LED will disappear.
- When the alarm starts, press this button to stop the alarm, press it again to make sure the alarm icon on the LED **disappear so that the alarm is totally turned off.**



:

- **Long press** this button, the hour digit will start blinking (press the right bottom button to change the digit)
- Press it one time again, the minute digit will start blinking (press the right bottom

button to change the digit)

- Press it one time again, **the hour digit for the alarm time** will start blinking (press the right bottom button to change the digit)
- Press it one time again, **the minute digit for the alarm time** will start blinking (press the right bottom button to change the digit)

At night, when users cannot see the clock digits, **short press this button one time to turn the backlight on**, the the screen will be lighted up. After 10S, the backlight will turn off automatically.



:

- Press it to increase the digit from **01-12** for hour digit and increase the digit from 00-59 for minute digit. This button is can only increase the digit and cannot decrease the digit.
- The display for time and alarm is AM and PM.

Note:

****The Bluetooth indicator light in the front will turn off automatically if the Bluetooth is not paired to the mobile phone for 5 MINS. To use the Bluetooth function again, please turn Off and On the switch again.

****While you turn off the unit, the time has its memory as long as there is still battery left of the speaker.

****If the speaker is with no battery inside at all, the time cannot memorize its track. The users need to charge the unit and reset the time again.

Wireless Charing Function:

Charging the unit with a 5V 2A adaptor and USB cable. The **right side red light in the back will turn solid red**, meaning the wireless charging function is enabled, put your phone on the wireless charging pad of the speaker, if the phone is charging, **this light will turn solid blue**, white means the phone is in charging status.

Caution:

- This is not a toy. Please keep away from children.
- Please keep away from water / heat.
- Low power may cause poor connection even no working of Bluetooth.
- Do not overcharge the battery.
- Battery pack shall not be exposed to excessive heat such as sunshine, fire or the like.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.