

CQL1699-B Bluetooth Speaker

Instruction Manual (Read before proceeding)



Power:

- Works on internal rechargeable Lithium battery. Please charge your speaker fully before first use.
To charge the battery use the micro USB cable(included): insert the jack into "Charging" jack located on the back of the unit and then plug the USB connector of charging cable into the USB port on a computer for charging.
- A red light will indicate the charging situation. When battery is full, the red light will turn off automatically.
- Disconnect the USB cable when it is fully charged.

Playing Music Via Bluetooth

- Switch the volume button to the right to turn the product on. A tone will be heard.
- Make sure the On Off button in the back is in the On positon which means the Bluetooth function of the unit is enabled and it's NOT in the soothing sound mode.
- The blue indicator light in the back will flash quickly. This indicates that the speaker in pairing mode and searching for your Bluetooth device.
- Turn on the Bluetooth function on your device, search the speaker named "XXXX" and select it, your device will pair without a password. (If required, enter the password "0000" to finalize the paring).The Blue light will begin to flash slowly after pair is complete.
- Start playing music on your device. Keep your device within 33feet (10 meters) of your speaker.
- Adjust volume by turning the volume button in the front.
- Turn off the unit when not in used.

Enjoy Soothing sounds

- Switch the volume button to the right to turn the product on. A tone will be heard.
- Make sure the On Off button in the back is in the Off positon which means the Bluetooth function of the unit is turned off and it's in the soothing sound mode.

- Select one of the 5 soothing sounds.
- Adjust volume by turning the volume button in the front.
- Press the timer button to set the time as 15min, 30min, 60min and turn off (the three holes from left to right indicate 15min, 30min, 60min separately). After the time is set to continue one natural sound, when the time is up, the sound will stop.

Caution:

- This is not a toy. Please keep away from small children.
- Please keep away from water / heat.
- Low power may cause poor connection even no working of Bluetooth.
- Do not over-charge the battery.
- Battery pack shall not be exposed to excessive heat such as sunshine, fire or the like.

Note: Both the volume for the Bluetooth music and the soothing sound can be adjusted by the volume button in the front.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.