

CQL1811-B Bluetooth Karaoke LED Speaker

Instruction Manual (Read before proceeding)

Power:

- Insert the small connector of the supplied micro-USB power cable into the USB power port on the back of the speaker.
- Insert the large connector into the USB port on a computer or a 5V/1A USB adapter (not included) and plug into a wall socket
- The LED indicator will turn red when the speaker is connected to a power source.

Bluetooth Speaker Operation

- Slide the power switch to the “ON” position to power on.
- The LED light will turn on to indicate the speaker is in pairing mode and searching for your Bluetooth mobile device.
- Open the Bluetooth function on your device and search the speaker named “**XXX**”. After selecting this speaker, your device will pair without a password. (If required, enter the password “0000” to finalize the pairing). The Blue light will begin to flash slowly after pair is complete.
- Start playing music on your device. Keep your device within 33feet (10 meters) of your speaker.
- Adjust the volume of your device to a comfortable level.
- Turn off the unit when not in used.

Using the light

The light will automatically turn on and cycle through different colors when the speaker powered on.

Caution:

- This is not a toy. Please keep away from small children.
- Please keep away from water / heat.
- Low power may cause poor connection even no working of Bluetooth.
- Do not over-charge the battery.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.