

Product Overview



Instructions:

Red Light: Power charge indicator.

Red Light On: power charging.

Red light off and blue light on: power charge has finished.

Blue and red light flash alternately : Bluetooth is ready to pair.

Blue light flash(slow): Bluetooth connection successful.



+ Button:

1. quick click: next track
2. press and hold: increase volume



Call Button:

1. When turned off, long press: power on
2. When turned on, long press: power off
3. When turned on, double click: redial the call
4. Ringing phone, long press: reject call



- Button:

1. quick click: previous track
2. press and hold: reduce volume

Product Specification:

Speaker Unit: Ø10mm

Impedance: 32 ohms +/-10%

Frequency range: 110Hz- 20KHz

Bluetooth Version: 3.0

Range: 10 meters

Input: 5V  0.5A

Maximum power: 5mW

Battery type: Lithium battery (rechargeable)

Capacity: 3.7V 60mAh

Charging Integrated Battery:



DO NOT PLUG INTO A MAINS POWER SOURCE.

The Bluetooth earphones are powered by integrated rechargeable Lithium battery. Charge the battery as follows:

1. Insert the charging cable into the micro USB port on side of the Bluetooth earphone control panel. Connect the standard USB plug into a PC (Personal Computer) charging port or another device with a USB port.

The LED indicator turns red when the battery is charging.

2. The red LED light will turn off and blue light turn on while the battery is fully charged.

Pairing your wireless earphones:

Please make sure the earphones is in power on mode when you are trying to activate the pairing mode.

1. Turn on your mobile phone and activate the Bluetooth function.
2. Search for Bluetooth devices, FINDYOURMAGIC will show up.
3. Pair your device with FINDYOURMAGIC, after FINDYOURMAGIC is paired with your device, a sound will indicate that the speaker had connected with your device.

TIPS: Once this earphones are paired and connected to your mobile phone, next time when you switch the earphones on, it will connect to your mobile phone automatically as long as the Bluetooth in your mobile phone is enabled.

Troubleshooting

| Symptoms | Causes | Solutions |
|-----------------------------|-----------------------------------------------------------------|-------------------------------------------------------------------|
| Cannot switch the earphone | Battery empty | Charge the battery |
| Unable to pair the earphone | Earphone is already switched on, and it is not in pairing mode. | Refer to the section of "Pairing FINDYOURMAGIC" to mobile phone." |



Take care of your earphone

- Do not charge the earphones for longer than 4 hours. Avoid charging overnight or leaving the product unattended.
- Ensure that the USB cable is removed from the device after charging finishes.
- Do not use excessive force when inserting or removing the cable from the earphones to avoid damage to the socket or your devices.
- Do not modify, disassemble, open, drop, crush, puncture or shred the product.
- Keep the unit away from all metal objects (e.g. coins, keys, hair pins etc.) and terminals (e.g. such as a hairpin) as this could result in short circuiting the product internally.



Safety Instructions and Information

Please read all instructions prior to using this product for the first time.

Failure to read and follow these safety and usage instructions could result in fire, electric shock or other hazard that could potentially cause property damage or even fatal injury.

- Please use USB cable to charge this product. Using an incompatible cable could result in the product malfunctioning.
- Do not expose the device to liquids.
- Do not extend the earphone cord longer than it's given length. If forced, this may impact on the earphones future functionality.
- Keep the product away from any heat sources and direct sunlight to prevent heat build-up.
- Keep away from children and ensure that all persons who use the product read and follow these instructions and warnings
 - No naked flame sources, such as lighted candles should be placed on the apparatus;
 - CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
 - Battery shall not be exposed to excessive heat such as sunshine, fire or the like.
 - Attention should be drawn to the environmental aspects of battery disposal;
 - The use of apparatus in moderate climates.

FCC Statements:

FCC ID: 2APVC4083EARPHONES

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: Retain these instructions for future reference.

Mat code: 67507466

Date of manufacture: Jun 2018

Imported by: ASL USA, 5201 Blue Lagoon Drive, 9th Floor (Suite 974), Miami, Florida 33126, USA

Manufactured by: ASL HK, 26F, 88 Hing Fat Street, Causeway Bay, Hong Kong

Made in China