




## Test positions for body:

According to the antenna position, the Body SAR is tested at the following 6 test positions all with the distance =5mm between the EUT and the phantom bottom :




**Toward Phantom (5mm)** 



Toward Ground (5mm)




Toward Left (5mm)



Toward Right (5mm)



Toward Top (5mm)



Toward Bottom (5mm)