


Item: AED066
Name: Bambooin Bluetooth® Speaker
User Manual



It is recommended to read this user manual carefully and keep it for future reference.

Product Overview:



1. Microphone
2. ON/OFF Button
3. Micro SD Card slot
4. Micro USB Input
5. Controls

Specifications:

- Bluetooth version 3.0
- Charging voltage: 5V
- Lithium battery 300mAh 3.7V
- Working Time: 2-3h
- Charging Time: 2 hours
- Operating distance: up to 10 meters
- Frequency: 2.4-2.48GHz
- Impedance: 4ohms
- Power output: 3W
- THD: less than 10%
- SNR: 65dB
- Support to Micro SD Card: up to 64GB

Operation:

Switch the power button to position to power on the speaker. The blue indicator lights will start flashing to indicate that the device is ready to be paired.
 Switch the power button to the opposite position to power off the speaker.

Playing Music via Bluetooth:

From the Bluetooth menu of your device, search for new devices and select "32346" to pair. Once they are paired successfully, you will hear a notification sound and the lights will stay on.

Playing Music via Micro SD Card:

When you insert a micro SD card into the micro SD card, the music will automatically start playing.

FM Radio:

Connect the Micro USB cable into the Micro USB port to work as an antenna. Short press and the speaker will automatically search for radio channels. Short press < > to change the channel.

Charging:

Use the cable provided for charging. Connect the USB cable to computer / AC adapter. Connect the Micro USB end of this cable into the Micro USB port of your device.
 During charging, the red indicator light will stay on. When the speaker is fully charged the indicator light will turn off.

Controls:

	<ul style="list-style-type: none"> • Short-press the button to next song. • Long-press the button to increase the volume. (When maximum volume is reached, you will hear a notification sound)
	<ul style="list-style-type: none"> • Short-press the button to previous song • Long-press the button to decrease the volume. (When minimum volume is reached, you will hear a notification sound)
	<ul style="list-style-type: none"> • Short-press the button to answer/end a call • Short-press the button to play/pause the music. • Long press the button to reject an incoming call • Press twice the button to redial the last phone number.
	<ul style="list-style-type: none"> • Short press to change the function (Bluetooth / FM Radio / Micro SD card).

Troubleshooting:

Fault	Solution
Unable to pair with other devices.	<ol style="list-style-type: none"> 1. Check whether the speaker is in BT (Bluetooth) mode. 2. Turn on the speaker's Bluetooth function. 3. Turn on the other device's Bluetooth function. 4. Turn on the other device's "Pairing Mode".
The sound is low or distorted.	<ol style="list-style-type: none"> 1. Check the Bluetooth device volume and then adjust it to an appropriate level. 2. Recharge the battery.
Occasionally the music stops.	<ol style="list-style-type: none"> 1. Check whether the speaker's effective communication range is exceeded or if there is an obstacle between the speaker and other Bluetooth devices.

Warnings:
 Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
 This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
 This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

