
折页

真无线耳机 蓝牙音箱二合一 BT12



1. 产品描述


本品为半入耳式TWS蓝牙耳机+一体化挂扣组合音箱、小 巧轻便的人体工程学外观设计并内置低功耗高性能蓝牙5.1 版本芯片再配一体化蓝牙挂扣音箱充电仓。

可适应分享与私人等各种模式的听声场景。


小巧的机身支持箱包扣锁不论在户外攀登还是徒步旅 行均可随行携带。

2. 技术参数

- 音箱蓝牙名称 BT12
- 耳机蓝牙名称: F2
- 工作申流: 100mA
- 静态电流: 5UA
- 藍牙版本: V5.1 有效距离: 10米
- •信噪比: ≥85db 充电接口方式: Type-C
- 按键类型:按键
- 低电压提醒:有
- 音箱喇叭规格: 36内磁/3W 输入功率: 5V 500mA
- 充电仓电池规格 : 3.7V 300mAH
- 耳机电池规格: 3.7V 30mAH
- 音频范围 : 100²0KHz
- 音箱播放时间: 3-4小时 耳机播放时间: 24小时
- 支持协议: A2DP 1.0、AVRCP 1.5、AVDTP 1.0、 AVCTP 1.4, HFP 1.5, GAVDP 1.0



蓝牙耳机面



温鏧提示:

- 1. 使用前先把耳机放回充电仓,再次取出左右耳耳机后, 左右耳耳机会自动配对;或者左右耳分别按触摸键3秒, 开机后,自动配对。
- 2. 左右耳配对完成后再打开手机蓝牙。

3. 功能说明

TWS功能简要:

- 1. 当双耳耳机取出充电仓后,自动完成配对并伴随提示音。
- 2. 随后即可被手机搜索连接。
- 3. 完成连接后,双耳伴有成功提示音。
- 4. 此时可通过耳机触摸按键实现:
- 4.1 单击暂停或播放音乐。
- 4.2 双击右耳下一曲,双击左耳上一曲。
- 5. 来电时单击接听电话,通话时单击挂断电话。
- 6. 当耳机放回充电仓后耳机自动休眠并进入充电状态, 此时充电灯为红色,充满后熄灭。
- 7. 机舱电量由4位灯点显示,每个灯点表示25%电量。

音箱功能简要:

长按开关机键, 开机之后音箱即可被搜索连接, 无连接状态下等待5分钟后自动关机。


功能类别	功能名称	操作方式	
基本功能	开机	长按3秒开/关机键开机	
	关机	长按3秒开/关机键关机	
音箱功能	音箱连接蓝牙	打开手机蓝牙功能,搜索	蓝牙,连接蓝牙名BT12无需密码即可连接成功
	音箱暂停/播放	已连接对等设备,在播放	音乐的时候短按开/关机键进行播放暂停
	音箱TWS功能	在开机的状态下,按两下	开/关机键进行TWS配对
	音箱通话功能	在来电的状态下,短按开	/关机键进行接听电话
耳机功能	耳机连接蓝牙	打开手机蓝牙功能,搜索	蓝牙,连接蓝牙名E2无需密码即可连接成功
	耳机开机	打开充电仓自动开机(充	电盒必须有电)
	耳机关机	放回有电的充电盒盖上充	电仓关机
	左右耳机配对	从充电盒里拿起来左右耳	自动配对,配对成功主耳进入跟手机配对状态
	上一曲	双击左耳 2 秒切换到上	一曲
	下一曲	双击右耳 2 次切换到下	一曲
	暂停/播放	已连接对等设备, 在播放	音乐的时候单击左或右耳播放暂停
	语音助手	在连接手机后,任何模式	下三击功能键启动手机语音助手 (Siri等)
	清除配对	在开机状态未连接时, 丑	击功能键启动
电话功能	接听电话	在来电状态下,单击左耳	或右耳
	挂断电话	在通话中或去电中, 双击	左耳或者右耳
	来电拒接	在来电状态下,长按左耳	或右耳 2 秒不松手
	超距离回连	1. 开机前 10 秒主副耳回	连,开机 3 分钟后自动关机
		2. 通话、去电、来电、符	机、听音乐期间远离,设备(3分钟内)回到可连接范围

折痕 不印刷

4. 安全须知

为防止使用过程中出现危险情况, 请阅读该安全须知。

- 1. 请不要把产品放置在加热器, 微波炉, 电饭煲, 高压 锅等加热设备附近,防止造成产品过热并引发火灾。
- 2. 请不要摔跌、撞击产品、避免产品出现爆炸情况。
- 3. 儿童使用时,请在成人监护下确保正常操作。
- 4. 请勿在低温潮湿的环境下使用,正常使用环境0-50℃。
- 5, 请勿擅自拆卸, 维修产品。
- 6. 请勿把产品放在离医疗设备20cm以内的范围, 防止 出现设备干扰现象。
- 7. 在不使用的情况下,请把产品充电器从插座上拔除, 避免消耗电池使用寿命或造成损坏。



1. Product Description

This product is an half in ear TWS Bluetooth Earbuds+integrated hanging buckle combination speaker, with compact and lightweight ergonomic design and built-in low-power high-performance Bluetooth version 5.1 chip and integrated Bluetooth hanging buckle speaker charging compartment.

It can adapt to various modes of listening scenes such as sharing and private.


The compact body supports the luggage buckle lock, which can be carried with you regardless of outdoor climbing or hiking.

2. Technical parameters

- Working current: 100mA
- Bluetooth version: V5.1
 SNR: >=85db
- Effective distance: 10 meters
 Charging port: Type-C
- Key type: Button
- Low voltage reminder: Yes
- Audio range: 100-20Khz
- Input power: 5V 500mA

Quiescent current: 5UA

- Speaker specifications: 36 Internal magnetic/3W
- Rechargeable battery specification: 3.7V 300mAH
- Headsets battery specification: 3.7V 30mAH
- Speaker playing time: 3-4 hours Headsets playing time: 24 hours
- Support protocol: A2DP1.0, AVRCP1.5, AVDTP1.0, AVCTP1.4, HFP1.5. GAVDP1.0





Tips:

- 1. Put the earphones back into the charging case before use, and when take out the earbuds again, "L" and "R" earbuds will start pairing automatically. Or press the touch buttons of the "L" and "R" earbuds for 3 seconds, earbuds will automatically pair after power on.
- Turn on the Bluetooth of the mobile phone after "L" and "R" earbuds pairing successfully.

3. Function description

Brief Introduction of TWS Earbuds Function:

- When the binaural earbuds are taken out of the charging case,
- they will automatically complete the pairing with a prompt sound.

 2. Then it can be searched and connected by the mobile phone.
- After the connection is completed, there will be a success tone in both ears.
- 4. At this time, it can be realized through the earbuds touch button
- 4.1 Click to pause or play music.
- 4.2 Double-click on the left ear to the previous song, and double-click on the right ear to the next song.
- Click to answer the call when there is an incoming call, and click to end the call when in a call.
- When put the earbuds back into the charging case, automatically sleep and start charging, the charging light turn to red and will turn off after fully charged.
- Battery indicator consists of 4 LED lights, each light point represents 25% power.

Brief Introduction of speaker function:

Long press the power button, the speaker can be searched for connection after power on, and it will automatically power off after 5 minutes without connection.

Function category	Function name		Operating
Basic functions	Power on	Long press the switch button for	3 seconds to turn on
	Power off	Long press the switch button for	3 seconds to turn off
Speaker functions	Speaker connected to Bluetooth	Turn on the Bluetooth of the mot without a password	ile phone to search the Bluetooth name "BT12"and connect it success fully
	Speaker pause/play	Connected to the equivalent dev	ce, short press the switch button to play/pause when playing music
	TWS function of Speaker	In the power-on state, press the	on/off button twice to pair with TWS, and press twice to disconnect
	Call function of speaker	In the state of an incoming call,	short press the switch button to answer the call
Headsets functions	Headsets connected to Bluetooth	Turn on the Bluetooth of the mot without a password	ile phone to search the Bluetooth name "E2"and connect it success fully
	Headsets power on	Be automatically turn on when ta (The charging case must have e	ke it out of charging case ectricity)
	Headsets power off	Be automatically turn off when p	5 5
	Headsets pairing	Take it out of the charging case, enters the pairing state with the	the "L"and "R" ears are automatically paired, and the main ear nobile phone after the pairing is successful
	Up track	Double click "L"ear touch button	
	Next track	Double click "R"ear touch button	
	Pause/play	Connected to the equivalent dev playing music	ce, press the touch button of "L"or "R"ear to play/pause when
	Voice assistant	After connecting the mobile phor assistant (siri, etc.)	ne, three-click the touch button in any mode to start the mobile voice
	Clear pairing	In the state of power on but not of	connect, 5-click the touch button to start
Phone functions	Answer call	In the incoming call state, click "l	or "R" ear
	Hang up call	During a call or outgoing call, do	uble-click the "L" or "R"ear
	Refuse call	In the incoming call state, long p	ress the "L"or "R"ear for 2 seconds without letting go
	Over-distance connection	after 3 minutes of power on wit	
		 Stay away from the device (will outgoing calls, incoming calls, 	hin 3 minutes) and then return to the connectable range during calls, standby, and listening to music

折痕 不印刷

4. Safety Instructions

To prevent dangerous situations during use, please read the safety instructions.

- 1. Please do not place the product near heaters, microwave ovens,
- rice cookers, pressure cookers and other heating equipment to
- prevent the product from overeating and causing a fire.
- 2. Please do not drop or hit the product to avoid explosion.
- When used by children, please ensure normal operation under adult supervision.
- Do not use in a low temperature and humid environment, the normal use environment is 0-50 C.
- Do not disassemble or repair the product without authorization.
- Do not place the product within 20cm of medical equipment to prevent equipment interference.
- 7. When not in use, please unplug the product charger from the
- socket to avoid consuming the battery life or causing damage.
- NOTE: This equipment has been tested and found to comply with the limits for sclass B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if nor installated and used in accordance with the instructions may cause harmful
- interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and
- on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

 Gonnect the equipment into an outlet on a circuit different from that to which the
- receiver is connected
- -Consult the dealer or an experienced radio/TV technician for help
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation