
Colorful Bluetooth

Dear customer, thank you for purchasing this product. Please read this manual to learn all the functions of this device and ensure its correct and safe use. Product model number: R2



Sower button. Answer and hang up button.

Pause button.

Light effect switch button; when music is playing, longpress this buttonto Bluetooth disconnected.

+Volume up.

1ume down.

One: Features

- (1) Supports iphone, ipad, htc, oppo, vivo, huawei and other devices with Bluetooth function.
- (2) Built-in high-capacity battery (3.7V/5200mAh), can be charged with various models of adapters or directly with the computer USB interface.
- (3) Built-in dual voice coil high-quality speakers. Clear bright top notes, mellow medium-tone, deep bass notes, offering you the perfect music enjoyment.
- (4) 3.5mm AUX audio interface, can be connected to MP3, computer, tablet and other external audio signals with 3.5mm stereo port.
- (5) This devicehas a dazzling color change and lighting effect. The perfect combination of sound and lights, bringing you an unparalleled audio-visual feast.
- (6) The machine supports wireless charging. If your mobile phone supports wireless charging, you can use the machine for emergency wireless charging.

Two: packing list

After purchasing the product, please carefully check the content of the package including the accessories:

USB charging cable: 1PCS

manual: 1PCS

Three: specifications

Bluetooth version: 4.2

Bluetooth distance: 10 meters

Charging power supply: USB DC 5.0V

Product net weight: 620g Product size: ø85*195mm

Four: telephone hands-free function

When you receive a call on your phone, pressthe button to answer the call. At this point, you can talk to the other party through the audio, and end the call with short press on Press and holdthe button.

to hang up the incoming call directly. Using the audio to answer the call will automatically transfer the call to your phone. Since the automatic transfer might vary according to the different phone brands it is also possible to do this operation directly on the phone.

Five: General problems and solutions

- 1. Bluetooth cannot be connected: Make sure the Bluetooth audio is in search mode, and check whether the Bluetooth function on the connected device has been turned on normally or if the Bluetooth audio is out of power.
- 2, Bluetooth audio is silent: Check if the audio is turned to the minimum volume, check whether the volume of the connected device is turned on, and whether the Bluetooth audio is fully charged.
- 3, Bluetooth audio cannot be turned on: charge the Bluetooth audio, observe the indicator status.

Six: Charging instructions and wireless charging instructions

- 1, This machine is suitable for 5V voltage charger
- 2, The charging indicator light is red when the power is below 70%, light yellow when the power is between 70% and 90%, and green when the power is above 90%.
- 3, In the state of power off, plug in the charger and you can use the wireless charging normally. In the state of power on, you can use the wireless charging immediately whether you plug in the charger or not.
- 4, Tips: in order to save power, the machine will be shut down automatically if it is not used for a long time.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure: A distance of 15 cm shall be maintained between the antenna and users, and the transmitter may not be co-located with any other transmitter or antenna.