


# Wireless Charging

## Instruction Manual

### WD22



1. A smartphone
2. Wireless Charging Pad
3. Built-in Wireless Charger
4. Power Indicator
5. Charging Input Port

### What's included:

- 1 x Wireless Charging Pad
- 1 x USB to Micro-USB charging cable
- 1 x Instruction Manual

### Tech Specifications

- Input power: DC 5V/1500 mA
- Output power: 5W
- Product size: 69 x 9 mm
- 30cm standard white color Micro-USB cable

### Instructions:

1. Use a certified USB adapter, connect the
  - a. provided Micro-USB cable to the USB adapter.
  - b. Use Micro-USB tip to connect to the input port on the charging pad.
2. Charging mobile devices:
  - a. Check your phone or tablet supporting with wireless charging, it will be listed in the manufacturer's specifications.
  - b. Simply place the enabled device atop the wireless charging pad. Your device should show the charging indication.
  - c. When completely charged, remove the device from the charging pad.

\* Note: In order to charge devices, use only the accessory cable or the cable included with your own device by the manufacturer.

### SAFETY PRECAUTIONS:

1. **WARNING**—When using this product, basic precautions should always be followed, including the following:
2. Read all the instructions before using the product.
3. To reduce the risk of injury, close supervision is necessary when the product is used near children.
4. Do not expose the device to moisture.
5. Do not use the device in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury.
6. Do not use the device if damaged or modified.
7. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.

8. Do not disassemble the device. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury.
9. Do not expose the device to fire or excessive temperature. Exposure to fire or temperatures above 212°F may cause explosion.
10. Have servicing performed by a qualified repair person using only identical replacement parts.
11. This will ensure that the safety of the product is maintained.
12. Do not overcharge phone. Unit may get hot with excessive use. Remove phone when it is fully charged. Never charge for more than 7 hours at a time.
13. Attachments on the back of your phone can impede the effectiveness of the wireless charger, and lead to overheating. Please remove attachments from the phone before charging on this device.

\* Caution: Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment. The device has been evaluated to meet general RF exposure requirement. The distance between user and products should be no less than 20cm.