

Instruction  
Of  
Bluetooth hat

Dear Customer,  
Thank you for buying our product.  
In order to help you operating this device properly,  
Please read this instruction carefully before use.










**Notes:**

Please store this item in a room temperature after use;  
Do not expose this item to a rain or humid environment;  
Do not heavily throw it, or it might be damaged;  
Do not disassemble, repair or modify this product.  
Please take off the earphone device from the hat before washing.

**Features:**

- \* compatible with most devices with BT function;
- \*The beanie itself is made of soft & warm knitted fabric, make the beanie comfortable to wear;
- \*Stylish beanie design;
- \*Built-in microphone, provide a hands-free phone calls and music/audio enjoyment;
- \*Built-in Li-ion rechargeable battery, make charging the music hat easily;
- \*Long standby time;
- \*The speaker device can be taken off from the hat, make the hat itself washable;
- \*Suitable for traveling, jogging, sports, waiting for bus or any other occasions in a cold weather.

#### How to use:

1. Press the  button to turn on the earphone of the hat, when turned on, the blue&red light flashes.
2. Find the BT named "CALL ME" on your cellphone or tablet, and pairing to the device. Then start your music on your cellphone.
3. Play/Pause: press the  button to play or pause a song.
4. Next/Previous songs: Transitory press the  or  button to switch to next or previous songs.
5. Volume increase/decrease: Long press the  button to increase the volume; long press the  button to decrease the volume.
6. Answer/hung up a phone calls: when a phone call comes in, transitory press the  button once to answer it, when finished call, transitory press  to hung up.
7. Call back: transitory press the  button twice to call back, only available for the last phone call.

#### FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.