

H604D说明书

版本:2.0

料号:807-0003-00543

折叠尺寸:105×145 (mm)

展开尺寸:210×145 (mm)

材质:80G书页纸

工艺:单色印刷

折叠方式:骑马钉

页数:20页





# User Manual

Model: H604D

Govee DreamView G1S Gaming Light

**English**

**01**

**Français**

**08**

## Safety Instructions

Read and follow all the safety instructions:

- This product is not waterproof. Avoid exposing its components to splashes, water drops, or every high-humidity environments.
- Be careful of static electricity during installation and usage and keep away from sharp objects and strong corrosive chemicals.
- When bending the light strip during installation, avoid folding its component as this may affect its service life.
- The internal light sources cannot be replaced. If they sustain damage, the product should be replaced.
- External dimmers cannot be used with this product.
- Avoid installing the light strip near potentially dangerous sources (e.g., candles, liquid-filled objects.)


## Introduction

Thanks for choosing Govee DreamView G1S Gaming Light. The gaming camera can automatically detect onscreen colors and project them on the wall behind via neon light strip. The real-time lighting effects will be synced perfectly with your movies, TV shows, sports, and gaming world, bringing you another level of immersive experience to your daily entertainment. It's also supports intelligent voice control for hands-free access to your gaming lighting.

## What You Get

Neon Light Strip	1
Gaming Camera	1
Power Adapter	1
Headphone Linking Cable	1
Foam Stickers	8
Mounting Clips	10
User Manual	1
Quick Start Guide	1
Positioning Card	2


## At a Glance



Gaming Camera

Power Button

Press to turn on and off.



# Pairing Your Device with Govee Home App

## What You Need:

- A Wi-Fi router supporting 2.4GHz and 802.11 b/g/n bands. 5GHz is not supported.


## Pairing Instructions:

- ❶ Download Govee Home App from the App Store (iOS) or Google Play (Android).
- ❷ Open Govee Home App, tap the “+” icon in the top right corner and search for “H604D”.
- ❸ Tap the device icon and follow the onscreen instructions to complete pairing.




# Calibrating the Camera Using Govee Home App

1. Ensure the camera is positioned at the top-center of the screen.




2. Gently place the provided foam stickers to the 7 position points on the screen as shown in the image here.




3. Open Govee Home App, go to the "Device Settings" page and click "Calibration". Follow the onscreen instructions to complete calibrating.

**Tips:**

- Drag the position points in the calibration image to the foam stickers located on the screen.



- The image may be warped due to the nature of the fish-eye camera. Make sure the calibration points match up correctly. Note that the calibration lines should not overlap or cross.



● Camera    ■ Position Points

## Specifications

Power Input(Adapter)	AC 100 - 240V
Power Input(Light)	12VDC 2A
Light Displaying Technology	RGBIC
Camera Pixel	1080P
Working Temperature	-10°C to 40°C/14°F to 104°F



# Troubleshooting

- ❶ Cannot connect to Wi-Fi.
  - Power on the device to check if it can function properly.
  - Do not skip connecting to Wi-Fi during pairing process.
  - Ensure your Wi-Fi router is 2.4GHz capable (5GHz is not supported).
  - Ensure you entered the correct Wi-Fi password during the Wi-Fi connection process.
  - Use another smartphone to pair with the device to check if your Wi-Fi network is working.
  - Shorten the distance between the device and the Wi-Fi router to less than 50ft, then try reconnecting.
- ❷ In video mode, the light color is not consistent with the color onscreen.
  - Ensure there are no strong external light sources interfering with the camera.
  - Ensure the camera is installed at the top-center of the screen.
  - Calibrate the camera again by following the instructions previously provided.
- ❸ Calibration has failed.
  - Check the stability of the Wi-Fi connection. A stable connection is required for successful calibration.
  - Follow the app instructions to calibrate.
- ❹ Cannot pair or connect with Alexa or Google Assistant.
  - Ensure the stability of the Wi-Fi connection.
  - Go to the “Device Settings” page and click “User Guide” to follow the instructions to pair the device again.
- ❺ The synchronization effect for Music mode is not working properly.
  - Ensure the camera is close to the music source, which will help the mic pick up sounds better.

- Try switching the mic source to the smartphone.
  - Make sure your headphones are fully plugged into the camera.
- ⑥ The mounting clip is not sticking properly
- Wipe the installation surface fully to ensure it is dry and clean.
  - Press the mounting clip firmly against the surface for a few seconds to ensure it is fully secured.
- ⑦ Only one user can control the device.
- Each device can only be controlled by one account.
  - If multiple users wish to control the same device, ensure they are using the same account.

## Customer Service

 Warranty: 12-Month Limited Warranty

 Support: Lifetime Technical Support

 Email: support@govee.com

 Official Website: [www.govee.com](http://www.govee.com)

 @Govee    @govee\_official    @govee.official

 @Goveeofficial    @Govee.smarthome

## Consignes de sécurité

Lisez et suivez les consignes de sécurité ci-dessous :

- Ce produit n'est pas étanche. Veuillez à ne pas l'exposer à des éclaboussures, gouttes d'eau ou tout autre environnement humide.
- Veuillez faire attention à l'électricité statique pendant l'installation et utilisation et maintenez-le éloigné d'objets tranchants et produits chimiques hautement corrosifs.
- Lorsque vous pliez la bande lumineuse pendant l'installation, éviter de pliez ses composants car cela peut affecter sa durée de vie.
- Les sources de lumière internes ne peuvent pas être remplacées. Si les sources de lumière sont endommagées, le produit doit être remplacé.
- Les variateurs externes ne peuvent être utilisés avec ce produit.
- Veuillez ne pas installer ce produit près de sources de dangers (ex. : bougies, objets remplis de liquides).

## Introduction

Merci d'avoir choisi Govee DreamView G1S Gaming Light. Cette caméra de jeu détecte automatiquement les couleurs à l'écran et les projette au mur derrière via la bande lumineuse néon. Les effets d'éclairage en temps réel se synchronisent parfaitement avec vos films, séries TV, sport et votre univers de jeu, offrant une expérience immersive d'un tout autre niveau pour vos loisirs quotidiens. Ce produit prend aussi en charge les commandes vocales pour un accès mains libres à votre éclairage de jeu.

## Contenu

Bande lumineuse néon	1
Caméra de jeu	1
Adaptateur secteur	1
Câble de liaison de casque	1
Autocollant en mousse	8
Clips d'installation	10
Guide d'utilisateur	1
Guide de démarrage rapide	1
Cartes de positionnement	2


## Aperçu



Caméra de jeu

Bouton d'alimentation

Appuyez pour allumer/éteindre



# Appairage de l'appareil à l'application Govee Home

## Ce dont vous avez besoin

- Un routeur Wi-Fi prenant en charge les bandes de fréquence 2,4 GHz et 802,11 b/g/n. La bande de fréquence 5 GHz n'est pas prise en charge.


## Instructions d'appairage

- 1 Téléchargez l'application Govee Home sur l'App Store (iOS) ou Google Play (Android).
- 2 Ouvrez l'application Govee Home, appuyez sur l'icône « + » en haut à droite et recherchez « H604D ».
- 3 Appuyez sur l'icône de l'appareil et suivez les instructions à l'écran pour terminer l'appairage.




## Étalonnage de la caméra dans l'application Govee Home

1. Assurez-vous que la caméra est placée au centre en haut de l'écran.




2. Installez les autocollants en mousse minutieusement sur les 7 points à l'écran comme indiqué sur l'image.




3. Ouvrez l'application Govee Home, allez dans les Paramètres puis appuyez sur « Étalonnage ». Suivez les instructions à l'écran pour effectuer l'étalonnage.

**Astuces :**

- Faites glisser les points de position de l'image d'étalonnage vers les autocollants en mousse à l'écran.



- L'image peut être déformée à cause de caméra très grand angle. Assurez-vous que les points d'étalonnage sont correctement alignés. Remarque : les lignes d'étalonnage ne doivent pas se superposer ou se croiser.



## Caractéristiques techniques

Entrée alimentation (Adaptateur)	AC 100 - 240V
Entrée alimentation (lumière)	12VDC 2A
Technologie d'affichage de lumière	RGBIC
Pixels de caméra	1080P
Température de fonctionnement	-10°C à 40°C/14 à 104°F

# Options de dépannage

## ❶ Connexion au Wi-Fi impossible.

- Mettez l'appareil sous tension pour vérifier qu'il fonctionne correctement.
- N'ignorez pas l'étape de connexion au Wi-Fi lors de l'appairage.
- Assurez-vous que le routeur Wi-Fi prend en charge la fréquence 2,4 GHz (la fréquence 5 GHz n'est pas prise en charge).
- Assurez-vous d'avoir saisi le bon mot de passe Wi-Fi lors de la connexion au Wi-Fi.
- Utilisez un autre smartphone pour appairer l'appareil et vérifier que le réseau Wi-Fi fonctionne.
- Réduisez la distance entre l'appareil et le routeur Wi-Fi à moins de 50 ft, puis réessayez de vous connecter.

## ❷ En mode vidéo, la couleur des lumières n'est pas cohérente avec la couleur à l'écran.

- Assurez-vous qu'il n'y ait pas de fortes sources de lumières provoquant des interférences avec la caméra.
- Assurez-vous que la caméra est installée au centre en haut de l'écran.
- Étalonnez de nouveau la caméra en suivant les instructions fournies précédemment.

## ❸ L'Étalonnage a échoué.

- Vérifiez la stabilité de la connexion Wi-Fi. Une connexion stable est nécessaire pour un étalonnage réussi.
- Suivez les instructions de l'application pour l'étalonnage.

## ❹ Appairage ou connexion avec Alexa ou Google Assistant impossible.

- Assurez la stabilité de la connexion Wi-Fi.
- Allez dans « Paramètres de l'appareil » et cliquez sur « Guide d'utilisateur » et suivez les instructions pour appairer de nouveau l'appareil.



- 5 L'effet de synchronisation pour le mode Musique ne fonctionne pas correctement.
- Assurez-vous que la caméra est proche de la source de musique, ce qui facilitera la détection des sons par le micro.
  - Essayez aussi de changer de source du micro sur le smartphone.
  - Assurez-vous que votre casque est correctement branché à la caméra.
- 6 Le clip d'installation n'adhère pas correctement.
- Nettoyez la surface d'installation pour s'assurer qu'elle est sèche et propre.
  - Pressez fermement le clip d'installation contre la surface pendant quelques secondes pour assurer sa bonne fixation.
- 7 Un seul utilisateur peut contrôler l'appareil.
- Chaque appareil ne peut être contrôlé que par un compte.
  - Si plusieurs utilisateurs souhaitent contrôler le même appareil, assurez-vous que le contrôle soit à partir du même compte.

## Service Clientèle

 Garantie : Garantie limitée de 12 mois

 Support : Technique de support à vie

 Email : support@govee.com

 Site officiel : [www.govee.com](http://www.govee.com)

 @Govee    @govee\_official    @govee.official

 @Goveeofficial    @Govee.smarthome

# FCC and ISED Canada Statement

This device complies with Part 15 of the FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil n' doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-005.

Cet appareil numérique de la classe B est conforme à la norme NMB-005 du Canada.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Shenzhen Intellirocks Tech. Co., Ltd. is under license.

Govee is a trademark of Shenzhen Intellirocks Tech. Co., Ltd.

Copyright ©2021 Shenzhen Intellirocks Tech.Co., Ltd. All Rights Reserved.

# FCC and IC Radiation Exposure Statement

This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

la distance entre l'utilisation et l'appareil ne doit pas être inférieure à 20 cm.

This device uses a non-replaceable light source. When the light source reaches the end of its life cycle, this device should be replaced. Not intended for illumination. Only used for creating ambiance.

- 1.Do not connect the rope light to the supply while it is in the packing or wound onto a reel;
- 2.Do not use the rope light when covered or recessed into a surface;
- 3.Do not open or cut the rope light ;

## **Responsible party :**

Name: GOVEE MOMENTS(US) TRADING LIMITED

Address: 2501 Chatham Rd Suite R Springfield IL 62704

Email: [support@govee.com](mailto:support@govee.com)

Contact information: <https://www.govee.com/support>



FOR INDOOR USE ONLY

POUR UNE UTILISATION EN INTÉRIEUR UNIQUEMENT



Govee Home App

For FAQs and more information,  
please visit: [www.govee.com](http://www.govee.com)